




# BreezeMAX<sup>®</sup> PRO 6000

## Product Manual

Release Number: 1.5  
July 2012  
P/N 216035





## Document History

Changed Item	Description	Date
This is the document's first publication.		May 2012
Accessing the Web Management Interface <a href="#">Section 3.2.1</a>	Corrected IP addresses	July 2012
Service Line <a href="#">Section 9.4</a>	Default for Enable DSCP spoofing is not selected (DSCP spoofing disabled).  Certain configuration rules are applicable only when working with DSCP Spoofing enabled.	



## Legal Rights

© Copyright 2012 Alvarion Ltd. All rights reserved.

The material contained herein is proprietary, privileged, and confidential and owned by Alvarion or its third party licensors. No disclosure thereof shall be made to third parties without the express written permission of Alvarion Ltd.

Alvarion Ltd. reserves the right to alter the equipment specifications and descriptions in this publication without prior notice. No part of this publication shall be deemed to be part of any contract or warranty unless specifically incorporated by reference into such contract or warranty.

## Trade Names

Alvarion<sup>®</sup>, BreezeCOM<sup>®</sup>, WALKair<sup>®</sup>, WALKnet<sup>®</sup>, BreezeNET<sup>®</sup>, BreezeACCESS<sup>®</sup>, BreezeMAX<sup>®</sup>, BreezeLITE<sup>®</sup>, 4Motion<sup>®</sup>, and/or other products and/or services referenced here in are either registered trademarks, trademarks or service marks of Alvarion Ltd.

All other names are or may be the trademarks of their respective owners.

“WiMAX Forum” is a registered trademark of the WiMAX Forum. “WiMAX”, the WiMAX Forum logo, “WiMAX Forum Certified”, and the WiMAX Forum Certified logo are trademarks of the WiMAX Forum.

## Statement of Conditions

The information contained in this manual is subject to change without notice. Alvarion Ltd. shall not be liable for errors contained herein or for incidental or consequential damages in connection with the furnishing, performance, or use of this manual or equipment supplied with it.

## Warranties and Disclaimers

All Alvarion Ltd. (“Alvarion”) products purchased from Alvarion or through any of Alvarion's authorized resellers are subject to the following warranty and product liability terms and conditions.

### Exclusive Warranty

(a) Alvarion warrants that the Product hardware it supplies and the tangible media on which any software is installed, under normal use and conditions, will be free from significant defects in materials and workmanship for a period of fourteen (14) months from the date of shipment of a given Product to Purchaser (the “Warranty Period”). Alvarion will, at its sole option and as Purchaser's sole remedy, repair or replace any defective Product in accordance with Alvarion' standard R&R procedure.

(b) With respect to the Firmware, Alvarion warrants the correct functionality according to the attached documentation, for a period of fourteen (14) month from invoice date (the “Warranty Period”). During the Warranty Period, Alvarion may release to its Customers firmware updates, which include additional performance improvements and/or bug fixes, upon availability (the “Warranty”). Bug fixes, temporary patches and/or workarounds may be supplied as Firmware updates.

Additional hardware, if required, to install or use Firmware updates must be purchased by the Customer. Alvarion will be obligated to support solely the two (2) most recent Software major releases.

ALVARION SHALL NOT BE LIABLE UNDER THIS WARRANTY IF ITS TESTING AND EXAMINATION DISCLOSE THAT THE ALLEGED DEFECT IN THE PRODUCT DOES NOT EXIST OR WAS CAUSED BY PURCHASER'S OR ANY THIRD PERSON'S MISUSE, NEGLIGENCE, IMPROPER INSTALLATION OR IMPROPER TESTING, UNAUTHORIZED ATTEMPTS TO REPAIR, OR ANY OTHER CAUSE BEYOND THE RANGE OF THE INTENDED USE, OR BY ACCIDENT, FIRE, LIGHTNING OR OTHER HAZARD.



## Disclaimer

(a) THE SOFTWARE IS SOLD ON AN "AS IS" BASIS. ALVARION, ITS AFFILIATES OR ITS LICENSORS MAKE NO WARRANTIES, WHATSOEVER, WHETHER EXPRESS OR IMPLIED, WITH RESPECT TO THE SOFTWARE AND THE ACCOMPANYING DOCUMENTATION. ALVARION SPECIFICALLY DISCLAIMS ALL IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE AND NON-INFRINGEMENT WITH RESPECT TO THE SOFTWARE. UNITS OF PRODUCT (INCLUDING ALL THE SOFTWARE) DELIVERED TO PURCHASER HEREUNDER ARE NOT FAULT-TOLERANT AND ARE NOT DESIGNED, MANUFACTURED OR INTENDED FOR USE OR RESALE IN APPLICATIONS WHERE THE FAILURE, MALFUNCTION OR INACCURACY OF PRODUCTS CARRIES A RISK OF DEATH OR BODILY INJURY OR SEVERE PHYSICAL OR ENVIRONMENTAL DAMAGE ("HIGH RISK ACTIVITIES"). HIGH RISK ACTIVITIES MAY INCLUDE, BUT ARE NOT LIMITED TO, USE AS PART OF ON-LINE CONTROL SYSTEMS IN HAZARDOUS ENVIRONMENTS REQUIRING FAIL-SAFE PERFORMANCE, SUCH AS IN THE OPERATION OF NUCLEAR FACILITIES, AIRCRAFT NAVIGATION OR COMMUNICATION SYSTEMS, AIR TRAFFIC CONTROL, LIFE SUPPORT MACHINES, WEAPONS SYSTEMS OR OTHER APPLICATIONS REPRESENTING A SIMILAR DEGREE OF POTENTIAL HAZARD. ALVARION SPECIFICALLY DISCLAIMS ANY EXPRESS OR IMPLIED WARRANTY OF FITNESS FOR HIGH RISK ACTIVITIES.

(b) PURCHASER'S SOLE REMEDY FOR BREACH OF THE EXPRESS WARRANTIES ABOVE SHALL BE REPLACEMENT OR REFUND OF THE PURCHASE PRICE AS SPECIFIED ABOVE, AT ALVARION'S OPTION. TO THE FULLEST EXTENT ALLOWED BY LAW, THE WARRANTIES AND REMEDIES SET FORTH IN THIS AGREEMENT ARE EXCLUSIVE AND IN LIEU OF ALL OTHER WARRANTIES OR CONDITIONS, EXPRESS OR IMPLIED, EITHER IN FACT OR BY OPERATION OF LAW, STATUTORY OR OTHERWISE, INCLUDING BUT NOT LIMITED TO WARRANTIES, TERMS OR CONDITIONS OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, SATISFACTORY QUALITY, CORRESPONDENCE WITH DESCRIPTION, NON-INFRINGEMENT, AND ACCURACY OF INFORMATION GENERATED. ALL OF WHICH ARE EXPRESSLY DISCLAIMED. ALVARION' WARRANTIES HEREIN RUN ONLY TO PURCHASER, AND ARE NOT EXTENDED TO ANY THIRD PARTIES. ALVARION NEITHER ASSUMES NOR AUTHORIZES ANY OTHER PERSON TO ASSUME FOR IT ANY OTHER LIABILITY IN CONNECTION WITH THE SALE, INSTALLATION, MAINTENANCE OR USE OF ITS PRODUCTS.

## Limitation of Liability

(a) ALVARION SHALL NOT BE LIABLE TO THE PURCHASER OR TO ANY THIRD PARTY, FOR ANY LOSS OF PROFITS, LOSS OF USE, INTERRUPTION OF BUSINESS OR FOR ANY INDIRECT, SPECIAL, INCIDENTAL, PUNITIVE OR CONSEQUENTIAL DAMAGES OF ANY KIND, WHETHER ARISING UNDER BREACH OF CONTRACT, TORT (INCLUDING NEGLIGENCE), STRICT LIABILITY OR OTHERWISE AND WHETHER BASED ON THIS AGREEMENT OR OTHERWISE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

(b) TO THE EXTENT PERMITTED BY APPLICABLE LAW, IN NO EVENT SHALL THE LIABILITY FOR DAMAGES HEREUNDER OF ALVARION OR ITS EMPLOYEES OR AGENTS EXCEED THE PURCHASE PRICE PAID FOR THE PRODUCT BY PURCHASER, NOR SHALL THE AGGREGATE LIABILITY FOR DAMAGES TO ALL PARTIES REGARDING ANY PRODUCT EXCEED THE PURCHASE PRICE PAID FOR THAT PRODUCT BY THAT PARTY (EXCEPT IN THE CASE OF A BREACH OF A PARTY'S CONFIDENTIALITY OBLIGATIONS).

## Federal Communication Commission (FCC) Interference Statement

This equipment has been tested and found to comply with RSS-192 and 197 of the Industry Canada Rules. This equipment also complies with the limits for a class B digital device, pursuant to ETSI EN 301 489-1 and Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:



- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:  
(1) This device may not cause harmful interference, and  
(2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

## Europe - EU Declaration of Conformity

This device complies with the essential requirements of the R&TTE Directive 1999/5/EC. The following test methods have been applied in order to prove presumption of conformity with the essential requirements of the R&TTE Directive 1999/5/EC:

- EN 60950-1:2006 + A11:2009 + A1:2010 + A12: 2011
- EN 302 326-2 V1.2.2: 2007
- EN 302 326-3 V1.3.1 : 2008
- EN50385 : 2002
- EN 301 489-1 V1.8.1 (2008-04)
- EN 301 489-4 V1.4.1: 2009

## Industry Canada Statement

This device complies with RSS-192 & RSS-197 of the Industry Canada Rules. Operation is subject to the following two conditions:

- 1) This device may not cause harmful interference, and
- 2) this device must accept any interference received, including interference that may cause undesired operation.

Ce dispositif est conforme à la norme CNR-192 & CNR-197 d'Industrie Canada applicable aux appareils radio exempts de licence. Son fonctionnement est sujet aux deux conditions suivantes: (1) le dispositif ne



doit pas produire de brouillage préjudiciable, et (2) ce dispositif doit accepter tout brouillage reçu, y compris un brouillage susceptible de provoquer un fonctionnement indésirable.

**NOTE!**



Radiation Exposure Statement:

This equipment complies with Canada radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 60 cm between the radiator & your body.

Français

Pour l'utilisation de dispositifs mobiles

Déclaration d'exposition aux radiations:

Cet équipement est conforme aux limites d'exposition aux rayonnements IC établies pour un environnement non contrôlé. Cet équipement doit être installé et utilisé avec un minimum de 60 cm de distance entre la source de rayonnement et votre corps.

### Safety Considerations - General

For the following safety considerations, "Instrument" means the BreezeMAX units' components and their cables.

#### Caution

To avoid electrical shock, do not perform any servicing unless you are qualified to do so.

#### Line Voltage

Before connecting this instrument to the power line, make sure that the voltage of the power source matches the requirements of the instrument.

#### Radio

The instrument transmits radio energy during normal operation. To avoid possible harmful exposure to this energy, do not stand or work for extended periods of time in front of its antenna. The long-term characteristics or the possible physiological effects of radio frequency electromagnetic fields have not been yet fully investigated.

### Outdoor Units and Antennas Installation and Grounding

Ensure that outdoor units, antennas and supporting structures are properly installed to eliminate any physical hazard to either people or property. Make sure that the installation of the outdoor unit, antenna and cables is performed in accordance with all relevant national and local building and safety codes. Even where grounding is not mandatory according to applicable regulation and national codes, it is highly recommended to ensure that the outdoor unit and the antenna mast (when using external antenna) are grounded and suitable lightning protection devices are used so as to provide protection against voltage surges and static charges. In any event, Alvarion is not liable for any injury, damage or regulation violations associated with or caused by installation, grounding or lightning protection.

### Outdoor Units Environmental Evaluation and Exposure Limit

According to FCC part 1, 1.1307, 1.1310:

The limit for power density for general population/uncontrolled exposure is 1(mW/cm<sup>2</sup>) or 10 (W/m<sup>2</sup>).

The power density calculation is  $S = (Pt \cdot DC) / 4\pi r^2$



Where:

- » Pt - The average transmitted power (EIRP) (mW)
- » r - The distance from the unit. (cm)
- » DC -maximum transmitter duty-cycle

The limit  $1(mW/cm^2)$  can be calculated from the above based on the following data:

- » Pt- the transmitted power which is equal to the output power 27dBm plus internal antenna gain 15 dBi and 30% Duty-cycle.
- » The maximum average EIRP = 36.8 dBm = 4755 mW
- » Maximum allowed distance "r", where RF exposure limit may not be exceeded, =  $SQRT(4755/4\pi)$ . This distance is at least 19.45 cm from the antenna (for the installer). For the public this distance is 50 cm.

## Disposal of Electronic and Electrical Waste



### Disposal of Electronic and Electrical Waste

Pursuant to the WEEE EU Directive electronic and electrical waste must not be disposed of with unsorted waste. Please contact your local recycling authority for disposal of this product.

《电子信息产品污染控制管理办法》 (第39号) (又名中国RoHS)						
产品内含有害物质揭露表						
零部件名称	有害物质项目					
	铅 (Pb)	镉 (Cd)	汞 (Hg)	六价铬 (Cr <sup>6+</sup> )	PBB (多溴联苯)	PBDE (多溴二苯乙醚)
含铜线材	×	○	○	○	○	○
连接器	×	○	○	○	○	○
变压器	×	○	○	○	○	○
陶瓷电容	×	○	○	○	○	○
高温锡材	×	○	○	○	○	○
○: 表示此部件使用的所有同类材料中此种有毒或有害物质的含量均低于 SJ/T11363-2006 规定的限制要求。 ×: 表示此部件使用的至少一种同类材料中, 此种有毒或有害物质的含量高于 SJ/T11363-2006 规定的限制要求。						
The above table provides information required under the following Chinese legislation: Management methods for Controlling Pollution by Electronic Information Products(No.39) (also known as China RoHS)						



## Important Notice

This user manual is delivered subject to the following conditions and restrictions:

- This manual contains proprietary information belonging to Alvarion Ltd. Such information is supplied solely for the purpose of assisting properly authorized users of the respective Alvarion products.
- No part of its contents may be used for any other purpose, disclosed to any person or firm or reproduced by any means, electronic and mechanical, without the express prior written permission of Alvarion Ltd.
- The text and graphics are for the purpose of illustration and reference only. The specifications on which they are based are subject to change without notice.
- The software described in this document is furnished under a license. The software may be used or copied only in accordance with the terms of that license.
- Information in this document is subject to change without notice. Corporate and individual names and data used in examples herein are fictitious unless otherwise noted.
- Alvarion Ltd. reserves the right to alter the equipment specifications and descriptions in this publication without prior notice. No part of this publication shall be deemed to be part of any contract or warranty unless specifically incorporated by reference into such contract or warranty.
- The information contained herein is merely descriptive in nature, and does not constitute an offer for the sale of the product described herein.
- Any changes or modifications of equipment, including opening of the equipment not expressly approved by Alvarion Ltd. will void equipment warranty and any repair thereafter shall be charged for. It could also void the user's authority to operate the equipment.





# About This Manual

This document describes and explains how to install and manage the BreezeMAX PRO 6000 CPE. .

This document contains the following chapters:

This manual is intended for operators responsible for installing, setting and operating the system, and for system administrators and product experts responsible for managing the system.

This manual contains the following chapters and appendices:

- Chapter 1 - Product Description - Describes the BreezeMAX PRO 6000 unit and its functionality.
- Chapter 2 - CPE Installation - Describes how to install the BreezeMAX PRO 6000 and how to connect to subscriber's equipment.
- Chapter 3 - Commissioning - Describes how to initially configure the BreezeMAX PRO 6000 in order to test basic link operation.
- Chapter 4 - Configuring Setup Parameters - Describes how to configure general parameters of the BreezeMAX PRO 6000.
- Chapter 5 - Configuring Local Address Parameters - Describes how to configure DHCP server and leasing parameters.
- Chapter 6 - Setting Advanced Parameters - Describes how to configure advanced parameters, such as: Authentication, security, Firewall, filters, and port forwarding/trigging parameters.
- Chapter 7 - Displaying Status Details - Describes how to view and understand the device status parameters.
- Chapter 8 - Configuring Telephony Parameters - Describes how to configure VoIP parameters
- Chapter 9- Engineering (for Operator only)
- Glossary - Terms used in this manual.

# Contents

<b>Chapter 1 - Product Description</b> .....	<b>1</b>
<b>1.1 Introducing the BreezeMAX PRO 6000</b> .....	<b>2</b>
<b>1.2 BreezeMAX PRO 6000 CPE Specifications</b> .....	<b>3</b>
1.2.1 General .....	3
1.2.2 WiMAX Radio.....	3
1.2.3 Power Specification .....	5
1.2.4 Environmental Specifications.....	5
1.2.5 Regulatory Specifications .....	5
1.2.6 Reliability Specifications .....	6
<b>Chapter 2 - Installation</b> .....	<b>7</b>
<b>2.1 Installation Requirements</b> .....	<b>8</b>
2.1.1 Package Content.....	8
2.1.2 Additional Installation Requirements.....	8
2.1.3 Guidelines for Positioning the ODU .....	9
2.1.4 IDU-ODU Cables .....	9
<b>2.2 Pole Mounting the ODU</b> .....	<b>11</b>
2.2.1 Pole Mounting the ODU .....	11
<b>2.3 Connecting the ODU Cables</b> .....	<b>13</b>
2.3.1 The PRO 6000 CPE Connectors .....	13
2.3.2 Connecting the Grounding Cable .....	14
2.3.3 Connecting and Sealing the IDU-ODU PoE Cable .....	14
2.3.4 Installing the Power Injector IDU .....	16
<b>2.4 Checking for Proper Operation</b> .....	<b>19</b>
<b>Chapter 3 - Commissioning</b> .....	<b>21</b>
<b>3.1 Introduction</b> .....	<b>22</b>
<b>3.2 Configuring the Unit Using the Web Management Interface</b> .....	<b>23</b>
3.2.1 Accessing the Web Management Interface .....	23

3.2.2 Applying Changes and Using Help.....	25
<b>3.3 Configuring the Unit Using the WiMAX Modem Application CD.....</b>	<b>26</b>
<b>3.4 Configuring the CPE Using the IPKG Upgrade .....</b>	<b>30</b>
<b>3.5 Creating a Default Configuration File .....</b>	<b>31</b>
<b>3.6 Operation Verification.....</b>	<b>34</b>
<b>Chapter 4 - Configuring Setup Parameters .....</b>	<b>35</b>
4.1 Introduction.....	36
4.2 Setting Basic Parameters.....	37
4.3 Setting Password .....	40
4.4 Setting Device Time Zone .....	41
4.5 Setting Device Name .....	42
4.6 Restore to Factory Default Configuration .....	43
<b>Chapter 5 - Configuring Local Address Parameters .....</b>	<b>44</b>
5.1 Introduction.....	45
5.2 DHCP Server.....	46
5.3 Lease Status .....	47
5.4 Lease Reservation .....	48
<b>Chapter 6 - Setting Advanced Parameters .....</b>	<b>49</b>
6.1 Introduction.....	50
6.2 Authentication .....	51
6.3 Security .....	53
6.4 Firewall.....	55
6.5 MAC Filter .....	57
6.6 IP Filter .....	58
6.7 Port Forwarding/Trigger.....	59
6.7.1 Port Forwarding.....	59

6.7.2 Port Trigger .....	60
6.8 Dynamic DNS .....	62
<b>Chapter 7 - Displaying Status Details .....</b>	<b>63</b>
7.1 Introduction .....	64
7.2 Device Status .....	65
7.3 WiMAX Status .....	67
7.4 Software Status .....	72
7.5 Telephony Status .....	73
7.6 Certificate Status .....	74
7.7 About .....	76
<b>Chapter 8 - Configuring Telephony Parameters .....</b>	<b>77</b>
8.1 Introduction .....	78
8.2 VoIP Parameters .....	79
<b>Chapter 9 - Engineering .....</b>	<b>81</b>
9.1 Introduction .....	82
9.2 WiMAX Configuration .....	83
9.3 VoIP Configuration .....	87
9.4 Service Line .....	96
9.5 Device Configuration .....	100
9.6 DM (Device Management) Settings .....	101
9.6.1 TR-069 .....	101
9.6.2 OMA Device Management Parameters .....	102
9.7 Function Settings .....	106
9.8 UI Settings .....	107

# Figures

Figure 1-1: BreezeMAX PRO 6000.....	2
Figure 2-1: Mounting the ODU on the Pole .....	11
Figure 2-2: ODU Pole Installation Using the Tilt Accessory, Vertical Polarization.....	12
Figure 2-3: CPE Connections.....	13
Figure 2-4: Rear View of the ODU .....	14
Figure 2-5: Ethernet Connector Pin Assignments.....	15
Figure 2-6: Inserting the Cable into the Sealing Cap .....	15
Figure 2-7: Sealing Gland Fastening Tool.....	16
Figure 2-8: Cold Shrink Tubing.....	16
Figure 2-9: IDU-ODU PoE port ("TO/FROM ODU PoE (RJ45)") .....	17
Figure 2-10: Data Equipment and Telephone Ports.....	18
Figure 2-11: LEDs.....	20
Figure 3-1: Login Window .....	23
Figure 3-2: Main Window (Device Status).....	24
Figure 3-3: Installation Setup Wizard Window.....	26
Figure 3-4: Choose Your ISP Window.....	27
Figure 3-5: Ready To Install Window .....	27
Figure 3-6: Installing Window .....	28
Figure 3-7: Installation Succeeded .....	28
Figure 3-8: Installation Complete .....	29
Figure 3-9: Status - Software Page .....	30
Figure 3-10: Engineering - Dev Config Page .....	31
Figure 3-11: Generate IPKG Tool .....	32
Figure 3-12: Generation Results.....	33
Figure 4-1: Setup - Basic Parameters .....	37
Figure 4-2: Setup - Password .....	40
Figure 4-3: Setup - Device Time.....	41

Figure 4-4: Setup - Device Name .....	42
Figure 4-5: Setup - Restore to Factory Warning.....	43
Figure 5-1: DHCP Server.....	46
Figure 5-2: Lease Status .....	47
Figure 5-3: Lease Reservation .....	48
Figure 6-1: Advanced - Authentication.....	51
Figure 6-2: Advanced - Security.....	53
Figure 6-3: Advance - Firewall .....	55
Figure 6-4: Advance - MAC Filter .....	57
Figure 6-5: Advance - IP Filter.....	58
Figure 6-6: Advance - Port Forwarding.....	59
Figure 6-7: Advance - Port Trigger.....	60
Figure 6-8: Advanced - Dynamic DNS .....	62
Figure 7-1: Status - Device Status .....	65
Figure 7-2: Status - WiMAX Status .....	67
Figure 7-3: Status - Software .....	72
Figure 7-4: Status - Telephony Status .....	73
Figure 7-5: Status - Certificate .....	74
Figure 7-6: Status - About .....	76
Figure 8-1: Telephony - VoIP Parameters .....	79
Figure 9-1: Engineering - WMAX Config.....	83
Figure 9-2: Engineering - VoIP .....	87
Figure 9-3: Engineering - VoIP (continued).....	88
Figure 9-4: Engineering - Service Line (ETHCS and IP-CS).....	97
Figure 9-5: Engineering - DEV Config.....	100
Figure 9-6: Engineering - DM Settings (TR-069) .....	101
Figure 9-7: Engineering - DM Settings (OMA).....	103
Figure 9-8: Engineering - Function Settings .....	106
Figure 9-9: Engineering - UI Settings .....	107

# Tables

Table 1-1: PRO 6000 CPE General Specifications .....	3
Table 1-2: PRO 6000 CPE WiMAX Radio Specifications .....	3
Table 1-3: PRO 6000 CPE Power Specification .....	5
Table 1-4: PRO 6000 CPE Environmental Specifications .....	5
Table 1-5: PRO 6000 CPE Regulatory Specifications .....	5
Table 1-6: PRO 6000 CPE Reliability Specifications .....	6
Table 2-1: Approved Category 5E Ethernet Cables .....	10
Table 2-2: LED Functionality .....	19
Table 3-1: Basic Parameters .....	22
Table 4-1: Basic Parameters .....	37
Table 7-1: Device Status Parameters .....	65
Table 7-2: WiMAX System Parameters .....	68
Table 9-1: WMAX Config. Settings .....	84
Table 9-2: VoIP Settings .....	89
Table 9-3: Service Line Parameters .....	98
Table 9-4: DM Settings - TR-069 .....	101
Table 9-5: DM Settings - OMA .....	103
Table 9-6: Function Settings .....	106
Table 9-7: UI Settings Parameters .....	107

# Chapter 1 - Product Description

## In This Chapter:

- [“Introducing the BreezeMAX PRO 6000” on page 2](#)
- [“BreezeMAX PRO 6000 CPE Specifications” on page 3](#)




## 1.1 Introducing the BreezeMAX PRO 6000

The PRO 6000 CPE comprises an Outdoor Unit (ODU) and an Indoor Unit (IDU).

The ODU includes the modem, radio, data processing, management and voice gateway components of the Subscriber Unit (SU). It also includes an integral high-gain flat antenna. The ODU connects to the IDU and to the user's equipment through a 10/100 BaseT Ethernet port.

The IDU is powered from the mains and connects to the ODU via a Category 5E Ethernet cable carrying the Ethernet data between the two units, as well as power (56 VDC) and control signals to the ODU and status indications from the ODU.



ODU



IDU

**Figure 1-1: BreezeMAX PRO 6000**



## 1.2 BreezeMAX PRO 6000 CPE Specifications

### 1.2.1 General

Table 1-1: PRO 6000 CPE General Specifications

Feature	Description
Flash ROM	32MB
Ethernet LAN port	One RJ-45 port 10/100 auto-sensing, auto-MDX
Channel Step Size	In 250 kHz steps
POTS	One RJ-11
Power supply	Input: Universal range 100~240VAC Output: 56 VDC Frequency: 50Hz to 60Hz Current: 0.8A
WiMAX SoC	BCS5350 and Dual Core 300MHz
RF IC	BCSR-200 / Dual Band 1T/2R RFIC
RAM	64MB

### 1.2.2 WiMAX Radio

Table 1-2: PRO 6000 CPE WiMAX Radio Specifications

Item	Description
Radio Type	IEEE 802.16e 2005 WAVE 2
Frequency Band	3.3 - 3.7 GHz (range will be increased to 3.3 - 3.8 GHz in future release)
Antenna Type	Two WiMAX antennas
Channel Bandwidth	5.00, 7.00, and 10.00 MHz
Modulation Technique	<ul style="list-style-type: none"><li>■ Scalable OFDMA employing Time-Division Duplex (TDD) mechanism</li><li>■ PRBS subcarrier randomization</li><li>■ Contains pilot, preamble, and ranging modulation</li></ul>

**Table 1-2: PRO 6000 CPE WiMAX Radio Specifications**

Item	Description
FEC Coding Rates	<ul style="list-style-type: none"> <li>■ Up Link and Down Link: QPSK, 16 QAM, 64 QAM</li> <li>■ QPSK and 16QAM - 1/2 and 3/4</li> <li>■ 64QAM - 1/2, 2/3, 3/4, 5/6</li> </ul>
TPL (Transmit Power Level)	27 dBm typical (maximum)
Channel Step Size	In 250 kHz steps
Synchronization	Referenced to the WiMAX BTS Timing Module
Frequency Accuracy	MRCT Compliant
Air Interface	IEEE 802.16e Wireless MAN-OFDMA
TDD Duty Cycle (Tx/Rx)	Rx up to 75% , Tx up to 50%
SISO or MIMO	MIMO (1TX, 2RX)
Regulatory Compliance	<ul style="list-style-type: none"> <li>■ FCC parts 15, 25, 27, 90</li> <li>■ RSS 192, 197</li> </ul>
Frame Duration	5 msec.
<b>RF Transmitter Specifications</b>	
RF dynamic range	45dB minimum
Transmit Power Control Relative Accuracy	mRCT compliant
Transmit and Receive Switching Gap	50 μS
<b>RF Receiver Specifications</b>	
Impedance	50 ohms nominal
Input return loss	10dBi
RX Sensitivity	Typical 3dB better than mRCT in SISO mode, and 6 dB better in MRC or MIMO mode. -94.5 dBm maximum.
Adjacent Channel Rejection	4 dB min. Receive signal 64QAM-3/4, 3dB above sensitivity level.
Non-Adjacent Channel Rejection	23 dB min Receive signal 64QAM-3/4, 3dB above sensitivity level.
<b>Antenna Specifications</b>	
Antenna Gain	Typical 15 dBi
Antenna Connectors	None. Embedded IPEX



## 1.2.3 Power Specification

Table 1-3: PRO 6000 CPE Power Specification

Item	Details
Power Consumptions	Outdoor CPE: 16W Maximum
Power Adapter	Input of 100 VAC - 240 VAC 50 Hz to 60 Hz
Power over Ethernet	56 VDC

## 1.2.4 Environmental Specifications

Table 1-4: PRO 6000 CPE Environmental Specifications

Item	Details
Operating Temperature	-40°C ~ 60°C
Storage Temperature	-40°C ~ 70°C
Operating and Storage Humidity	5% - 95%

## 1.2.5 Regulatory Specifications

Standards for all frequency bands:

Table 1-5: PRO 6000 CPE Regulatory Specifications

Standard	Specification	Applicable to
FCC	Part 15	ODU
	Part 90, Subpart Z	
ETSI	ETSI EN 302 326	ODU
WiMAX	IEEE-802.16-2005.	ODU
Environmental	ETSI 300 019-2-4 Class T4.1E	ODU
	ETSI 300 019-2-3 Class T3.2.	PoE (+PS)
Transportation & Storage	ETSI 300 019-2-2 Class T2.3.	System
	ETSI 300 019-2-1 Class T1.2.	
EU EMC	ETSI EN 301 489-1/4	System
US EMC	FCC part 15 Subpart B (Emission test)	System
Immunity	Surge (Lightning protection), ITU-T K.21	System



**Table 1-5: PRO 6000 CPE Regulatory Specifications**

Standard	Specification	Applicable to
Safety	UL/CUL 60950-1 (USA+Canada)	System
	EN60950 (Europe)	
	IEC-60950-1	
	AS-3260 (Australia)	
Canadian standards	IC RSS-192 – 3450-3650MHz	ODU
	SRSP-303.4 Issue 3 - 3475-3650 MHz	
	IC RSS-197 - 3650-3700 MHz	
	SRSP-303.65 Issue 1	
	ICES-003 - Digital Apparatus	

## 1.2.6 Reliability Specifications

**Table 1-6: PRO 6000 CPE Reliability Specifications**

Item	Details
MTBF	The MTBF for CPE is not less than 300,000 hours.

# Chapter 2 - Installation

## In This Chapter:

- "Installation Requirements" on page 8
- "Pole Mounting the ODU" on page 11
- "Connecting the ODU Cables" on page 13
- "Checking for Proper Operation" on page 19



## 2.1 Installation Requirements

The BreezeMAX PRO 6000 CPE is installed by the operator's installation technicians.

### CAUTION



ONLY experienced installation professionals who are familiar with local building and safety codes and, wherever applicable, are licensed by the appropriate government regulatory authorities should install outdoor units and antennas.

Failure to do so may void the product warranty and may expose the end user or Service Provider to legal and financial liabilities. Alvarion and its resellers or distributors are not liable for injury, damage or regulation violations associated with the installation of Outdoor Units or antennas.

Français

SEULS les installateurs professionnels expérimentés qui sont familiers avec les codes locaux des bâtiments et de la sécurité et, lorsque cela s'applique, qui sont autorisés par les autorités gouvernementales de régulation, doivent installer les unités extérieures et les antennes. Le non-respect de cette clause peut invalider la garantie du produit et exposer l'utilisateur final ou le prestataire de services à des responsabilités légales et financières. Le fabricant et ses revendeurs ou distributeurs ne sont pas responsables pour toute blessure, dommage ou violation de la réglementation associée à l'installation d'unités extérieures ou d'antennes.

Italiano

ATTENZIONE: SOLO professionisti esperti che hanno familiarità con le norme di costruzione locali e coi codici di sicurezza e, ove applicabile, sono autorizzati dalle autorità governative competenti possono installare unità esterne ed antenne. Assicurarsi che le unità esterne, antenne e strutture di supporto siano installate correttamente per eliminare ogni pericolo fisico a persone o cose. In caso contrario, ciò può invalidare la garanzia del prodotto e può esporre l'utente finale o il fornitore di servizi a responsabilità legali ed economiche. Anche quando la messa a terra non è obbligatoria in base alla normativa regolatoria applicabile e ai codici nazionali, è obbligatorio garantire che l'unità esterna e il palo dell'antenna siano messi a terra e idonei dispositivi di protezione contro i fulmini siano utilizzati in modo da fornire protezione contro le sovratensioni e le scariche statiche. In ogni caso, il Fornitore e i suoi rivenditori non sono responsabili per eventuali danni fisici, danni ad oggetti o violazioni del regolamento associati con o causati dall'installazione, la messa a terra o di protezione contro i fulmini.

### 2.1.1 Package Content

Make sure that each package contains the items listed below:

- BreezeMAX PRO 6000 Outdoor Unit (ODU)
- Indoor power supply unit (IDU) Power Over Ethernet 802.3af compliant
- Crossed Ethernet cable with two RJ-45 connectors for connecting the IDU power injector to a PC/HUB/switch.
- Pole mounting kit
- Optional - Tilt Accessory kit (ordered separately)
- Quick Installation Guide

### 2.1.2 Additional Installation Requirements

- Indoor-to-outdoor Category 5E PoE Ethernet cable with two shielded RJ-45 connectors\* and an RJ-45 connectors crimping tool. For details on approved cables and maximum length, refer to [Section 2.1.4](#).



- Mains plug adapter or termination plug (if the power plug on the supplied AC power cord does not fit local power outlets).
- Grounding cable with an appropriate termination
- Sealing gland fastening tool\*
- Installation tools and materials
- Sealing materials: mastic tape (Scotchfil™ Electrical Insulation Putty), Cold Shrink sealing kit.

**INFORMATION**

Items marked with an asterisk (\*) are available from Alvarion.

### 2.1.3 Guidelines for Positioning the ODU

This section provides guidelines for selecting the optimal installation locations for the ODU.

Select the optimal locations for the equipment using the following guidelines:

- The ODU should be mounted on a 1" - 4" pole. Its location should enable easy access to the unit and its connectors for installation and testing.
- Place the ODU as high as possible to achieve the best possible link quality.
- Place the ODU away from power and telephone lines.
- Avoid placing the ODU too close to any metallic reflective surfaces.
- Be sure to ground the ODU with an appropriate grounding wire (not included) by attaching it to the grounding screw on the unit and to a good ground connection.
- An optional Tilt accessory for the ODU providing a tilt range of  $\pm 15^\circ$  is available from Alvarion. The tilt option might be necessary to either improve the link conditions or, if the ODU is too close to the BTS, to reduce the receive signals strength. As a rule of thumb, if the ODU is located at a distance of less than 300 meters from the BTS, it is recommended to up-tilt the antenna by approximately  $10^\circ$  to  $15^\circ$  (especially in line-of-sight conditions) to avoid saturation of the receivers by too strong signals.

### 2.1.4 IDU-ODU Cables

**INFORMATION**

The length of the Indoor-to-Outdoor cable should not exceed 90 meters. The length of the Indoor-to-Outdoor cable, together with the length of the Ethernet cable connecting the CPE-IDU-1D to the data equipment, should not exceed 100 meters.

Use only Category 5E PoE Ethernet cables from either Alvarion or any of the approved manufacturers, listed in [Table 2-1](#) below. Consult with Alvarion's specialists on the suitability of other cables.





**Table 2-1: Approved Category 5E Ethernet Cables**

Manufacturer	Part Number
UNIXSTAR <a href="http://www.unixtar.com.tw">www.unixtar.com.tw</a>	C5ES4P24
WESTERN <a href="http://www.westernwire.org">www.westernwire.org</a>	KF804E1D

In case of missing information in the manufacturer's WEB site (product specifications, ordering issues, etc.), it is highly recommended to contact the manufacturer's sales representative directly.

## 2.2 Pole Mounting the ODU

### 2.2.1 Pole Mounting the ODU

The ODU can be mounted on a 1" to 4" pole using one of the following options:

- A pole mounting kit is supplied with each unit. The kit includes a special clamp and a pair of threaded rods, flat washers, spring washers and nuts. There are two pairs of threaded holes on the back of the unit, enabling to use the mounting kit for installing the unit using either vertical or horizontal polarization. The clamp enables installing the unit on diverse pole diameters from 1" to 4".
- A Tilt Pole Mounting kit, providing a tilt range of  $\pm 15^\circ$  is available from Alvarion. The Tilt kit can be attached to the ODU and be mounted on a 1" to 4" pole using two 9/16" wide metal bands.



#### To mount the ODU using the clamp:

- 1 Thread the M10\*100 mm bolt through the M10 spring washer, M10 nut, and the bracket holes.
- 2 With the connector facing downward, attach the ODU to a 1" - 4" pole.
- 3 Attach the bracket to the other side of the pole.
- 4 Thread the M10\*100 mm bolts through both holes on either side. Tighten the nuts.





Figure 2-1: Mounting the ODU on the Pole

**to mount the ODU using the Tilt accessory:**

- 1** Attach the Tilt accessory to the ODU using the two pairs of flat washers, spring washers and nuts supplied in the Tilt kit.
- 2** Mount the Tilt accessory on a 1" to 4" pole using two 9/16" metal bands.
- 3** Slightly release the Tilt Control Screw, tilt the ODU downward/upward as required, and re-tighten the screw.




**Figure 2-2: ODU Pole Installation Using the Tilt Accessory, Vertical Polarization**

## 2.3 Connecting the ODU Cables

### 2.3.1 The PRO 6000 CPE Connectors

The PRO 6000 CPE has the following connectors:

- One RJ-45 connector for connecting to the power injector indoor unit (ODU PoE .
- One Indoor /Outdoor connector (connects to GPS or used for distribution automation) (I / O, currently not applicable)
- A grounding screw on the rear panel.

The following figure illustrates the CPE connections:




Figure 2-3: CPE Connections

## 2.3.2 Connecting the Grounding Cable

The Grounding screw (marked  $\text{T}$ ) is located on the rear panel of the ODU.




Figure 2-4: Rear View of the ODU



### To connect the grounding cable:

- 1 Connect one end of a grounding cable to the grounding screw and tighten the grounding screw firmly.
- 2 Connect the other end of the grounding cable to a good ground (earth) connection.

## 2.3.3 Connecting and Sealing the IDU-ODU PoE Cable

### CAUTION



Use only Category 5E 4x2x24# FTP outdoor cables from an approved manufacturer. See list of approved cables in [Table 2-1](#). The length of the Indoor-to-Outdoor cable should not exceed 90 meters. The length of the Indoor-to-Outdoor cable, together with the length of the Ethernet cable connecting the IDU to the data equipment, should not exceed 100 meters.



### To prepare the IDU-ODU cable:

Use a crimp tool for RJ-45 connectors to prepare the wires. Insert them into the appropriate pins and use the tool to crimp the connector. Make sure to do the following:

- Remove as small a length as possible of the external jacket. Verify that the external jacket is well inside the sealing cover when connected to the unit, to ensure good sealing.
- Pull back the shield drain wire before inserting the cable into the RJ-45 connector to ensure a good connection with the connector's shield after crimping.

The IDU-ODU cable provides pin-to-pin connection on both ends.

The following figure shows the required wire pair connections. The color codes used in standard cables supplied by Alvarion are as listed in the table.

Wire color	Pin
Blue	1
Blue/white	2
Orange	3
Orange/white	6
Brown	4
Brown/white	5
Green	7
Green/white	8





Figure 2-5: Ethernet Connector Pin Assignments



#### To connect and seal the IDU-ODU cable:

- 1 Remove the sealing gland plug from the gland nut.
- 2 Open the sealing gland nut and remove it. *Do not* disassemble the gland base from the bracket.
- 3 Insert the cable into the sealing gland base and connect it to the RJ-45 connector at the bottom of the CPE, labeled . Make sure that the connector is completely inserted and tightened.
- 4 Insert the rubber bushing on the cable into the gland base.






Figure 2-6: Inserting the Cable into the Sealing Cap

- 5 Tighten the gland nut. Use the dedicated tool for fastening the sealing glands.



**Figure 2-7: Sealing Gland Fastening Tool**

- 6 Attach the mastic tape (Scotchfil™ Electrical Insulation Putty) and wrap it around the connector butting up against the connector. Do not over stretch.
- 7 Squeeze to tighten the mastic sealer. Make sure there are no air bubbles.
- 8 Slide the cold shrink sleeve on top of the connector. Make sure that the sleeve covers both cable connector and unit connector.



**Figure 2-8: Cold Shrink Tubing**

- 9 Pull the cord slowly to shrink the sleeve.
- 10 Route the cable to the location selected for the indoor equipment.
- 11 Assemble an RJ-45 connector with a protective cover on the indoor end of the IDU-ODU cable. Refer to the pin assignment and color codes in standard cables described above.

### 2.3.4 Installing the Power Injector IDU

The unit can be placed on a desktop or a shelf, or it may be wall-mounted.

**INFORMATION**

The length of the Ethernet cable connecting CPE to the user's equipment, together with the length of the IDU-ODU cable, should not exceed 100 meters.

**To install and connect the Power Injector IDU:**

- 1 It is assumed that the IDU-ODU cable is already connected to the ODU. Assemble an RJ-45 connector with a protective cover on the indoor end of the IDU-ODU cable. Refer to [Section 2.3.3](#) for instructions on preparing the cable.
- 2 Connect the IDU-ODU cable to the single port, labeled "TO/FROM ODU PoE (RJ45)" ([Figure 2-9](#)).



**Figure 2-9: IDU-ODU PoE port ("TO/FROM ODU PoE (RJ45)")**

- 3 Connect one end of the supplied Ethernet cable to a PC/Hub/Switch.
- 4 Connect the other end of the Ethernet cable to the RJ-45 IDU port, labeled with a computer illustration (see [Figure 2-10](#)).
- 5 Use a telephone cable to connect a phone to the RJ-11 IDU port labeled with a telephone illustration (see [Figure 2-10](#)).
- 6 Connect the indoor unit to the AC mains using the power cable supplied with the unit.





**Figure 2-10: Data Equipment and Telephone Ports**

**CAUTION**



Do *not* connect the data equipment to the PoE port on the IDU, as it supplies DC power to the ODU, and this may harm other equipment connected to it.




## 2.4 Checking for Proper Operation

- 1 Verify data connectivity by sending a ping command to the BTS or by connecting to the Internet.
- 2 Check the LED functionality according to the following table:

**Table 2-2: LED Functionality**

Description	Color	Functionality
Fault + Eth indication LED	Red	<ul style="list-style-type: none"> <li>■ Lights at start up</li> <li>■ During the built-in test (BIT) blinks (300ms on, 300ms off).</li> <li>■ Off/On - If BIT finished successfully. If BIT is failed it will continue lightning.</li> <li>■ On - If fatal error/critical alarm appears during run time.</li> <li>■ Blinking - If PoE Eth connected and no errors found (1sec on, 3sec off).</li> </ul>
WiMax W/L link availability LED	Green	<ul style="list-style-type: none"> <li>■ Lights at start up</li> <li>■ Off - upon BIT completion</li> <li>■ Blinking - the CPE is synchronized to the BS and <math>5 &gt; \text{SNR} \geq 3\text{dB}</math>.</li> <li>■ On - when the CPE is synchronized to the BS and the <math>\text{SNR} \geq 5\text{dB}</math></li> </ul>
3 x WiMax link signal strength LEDs	Green	<ul style="list-style-type: none"> <li>■ Lights at start up.</li> <li>■ Off - upon BIT completion</li> </ul> <p>Signal strength display:</p> <ul style="list-style-type: none"> <li>■ LED1 blinks when <math>12 &gt; \text{SNR} \geq 8\text{dB}</math></li> <li>■ LED1 lights when <math>\text{SNR} \geq 12\text{dB}</math></li> <li>■ LED2 blinks when <math>18 &gt; \text{SNR} \geq 15\text{dB}</math></li> <li>■ LED 2 lights when <math>\text{SNR} \geq 18\text{dB}</math></li> <li>■ LED3 (right side) blinks when <math>25 &gt; \text{SNR} \geq 20\text{dB}</math></li> <li>■ LED3 (right side) lights when <math>\text{SNR} \geq 25\text{dB}</math></li> </ul>



**Figure 2-11: LEDs**

# Chapter 3 - Commissioning

## In This Chapter:

- "Introduction" on page 22
- "Configuring the Unit Using the Web Management Interface" on page 23
- "Configuring the Unit Using the WiMAX Modem Application CD" on page 26
- "Configuring the CPE Using the IPKG Upgrade" on page 30
- "Creating a Default Configuration File" on page 31
- "Operation Verification" on page 34



## 3.1 Introduction

After completing the installation process, as described in the preceding chapter, several actions should be performed to ensure connectivity with a base station (BS) and provisioning of services. After the subscriber unit is connected with a BS, it can be fully managed via the wireless link:

- 1 The basic parameters must be configured to ensure that the unit operates correctly and can communicate with a BS.
- 2 Proper operation should be verified, including data connectivity.
- 3 The unit must be positioned correctly to ensure optimal performance of the wireless link.

The following methods are available for configuring the unit:

- The web-based management interface - accessed using a PC/Notebook with a web browser (see [“Configuring the Unit Using the Web Management Interface” on page 23](#)).
- An automatic configuration tool provided on a CDROM for the subscribers (see [“Configuring the Unit Using the WiMAX Modem Application CD” on page 26](#)).
- Upgrading the CPE using an auto-configuration file, or IPKG (in \*.ipk format) (see [“Configuring the CPE Using the IPKG Upgrade” on page 30](#)).

The device may be delivered with the operator’s default settings already configured in the FLASH memory.

The following parameters must be configured in order for a link to be established.

**Table 3-1: Basic Parameters**

Item	Default Value	Comment
User Name (WiMAX)	WAN mac address and WiMax.com realm, e.g: 0026824EE12C@WiMax.com	Should be supplied by system administrator. Configured in the Advanced> Authentication window
WiMAX Password	quickyokynyoky	
Domain	wimax.com (also Eng > WiMAX Config > Realm)	
Frequency	Full Scan	Should be supplied by system administrator.
Telephony - SIP Server, phone number, authentication, enable the phone	Disabled	Optional VoIP is disabled by default and should be enabled by the operator
WiFi	Enabled	Enabled by default



## 3.2 Configuring the Unit Using the Web Management Interface

The BreezeMAX PRO 6000 supports multi-user permissions: Operator and Subscriber modes are available by downloading different configuration files (IPKGs) from the web and upgrading the unit. Each level has different permissions to access various pages for configuration.

### 3.2.1 Accessing the Web Management Interface

By default, the BreezeMAX PRO 6000 enables a DHCP server and computers, or network devices connected to a LAN port, to automatically get an IP address from the unit. If the unit's DHCP server is disabled, you can set in the PC the IP address, netmask, and gateway manually using the following values:

IP address: 192.168.254.x ( $1 \leq x \leq 253$ , excluding 251)

Netmask: 255.255.255.0

Gateway: 192.168.254.251



#### To log in:

- 1 Open a web browser and enter the Gateway IP address: `http://192.168.254.251`. The web browser displays the login page.




Figure 3-1: Login Window

- 2 Enter the user name and password, and click **Login**.

The system supports multi-level user login: Operator and Subscriber, and Debug modes are available. Each level has different permissions to access various pages for configuration.



- Subscriber:
  - » Username: admin
  - » Password: admin
- Operator:
  - » Username: operator
  - » Password: wimax

After successful login, the Status - Device Status page is displayed.




Figure 3-2: Main Window (Device Status)

The Web Management Interface consists of a number of menu links (to the left). Clicking on each of them will display the configuration/status page for the selected menu item, with the applicable content (configurable parameters/options or status information) in the main area. Several pages include a page selection bar at the top of the page, enabling selection between several pages related to the same menu item. The displayed pages may vary depending on user privileges.

Use the Main Menu items and the specific sub-items in the menu-bar at the top of the window to configure settings for the current operating mode. The menus and configuration steps are described in the next chapters of this manual.



In Operator mode only, additional parameters are available in the Engineering menu item, for more detailed configuration. The Engineering features are available in a software package, and can only be activated after uploading it to the system from the Status page See "[Software Status](#)" on page 72.

## 3.2.2 Applying Changes and Using Help

There are common buttons that appear in most of the interface pages. Use these buttons as follows:

- **Apply** - Click this button to save the changes you have made in each page of the device system. For changes that require device reset, the device will automatically initiate reset after clicking the Apply button.
- **Undo** - Click this button to clear the input data in the specific window.
- **Reboot** - Click this button to restart your unit. The device returns to the last applied settings.
- **Reconnect** - Click this button to attempt reconnecting the device to the Base Station. This step is normally not required, unless suspecting that connection is problematic.
- **Help** - Click this button to open context-sensitive on-line help.



### 3.3 Configuring the Unit Using the WiMAX Modem Application CD

This section explains how to use the automatic configuration tool, delivered on a CDROM with the unit, to automatically configure a CPE. This procedure is usually performed by the subscriber.



#### To configure the unit using the Auto-Configuration tool:

- 1 From the CDROM supplied with the unit, run the CPE Auto Configuration Tool: CPEAutoConfigTool.exe; The Installation Setup Wizard window is displayed.






Figure 3-3: Installation Setup Wizard Window

- 2 Click **Next** to continue; The Choose Your ISP window is displayed.



**Figure 3-4: Choose Your ISP Window**


- 3 Choose the ISP (Internet Service Provider) ConfigFile from the list and click **Next**. The Ready To Install window is displayed.



**Figure 3-5: Ready To Install Window**


- 4 Click **Install**. If your CPE is powered up, click **OK** for performing system reboot. If not, power on the CPE and click **OK**.

The tool starts the auto-configuration process of the unit settings. It will change default settings by using the \*.ipk file, and then run "reset to factory default" by using default configuration in the file.



**Figure 3-6: Installing Window**

- 5 When the installation is complete, an Installation Success window is displayed. Click **OK**.



**Figure 3-7: Installation Succeeded**

- 6 Click **Finish**. The CPE is now configured with the parameters from the ConfigFile.




Figure 3-8: Installation Complete

## 3.4 Configuring the CPE Using the IPKG Upgrade

This section explains how to use the IPKG (ITSY Package Management System), provided by the operator, to automatically configure a CPE and sometimes upgrade its features. Subscribers should use this procedure upon specific instruction from the operator.



### To upgrade the unit using the IPKG:

- 1 From the main menu at the left pane select **Status** and open the **Software** page (Figure 3-9).
- 2 Click **Browse** to upload the \*.ipk file provided for this unit.
- 3 Click **Upgrade** to apply all the parameters in the IPKG file to this unit.



Figure 3-9: Status - Software Page

## 3.5 Creating a Default Configuration File

This section explains how to create a default configuration file (\*.ipk) for automatic configuration. When applying this file to CPEs, all the parameters will automatically be configured with the values from the file. When resetting the unit to factory defaults - this file is reloaded, overriding any configuration changes you may have performed on the CPE.

Creating a configuration file involves converting a \*.tar file into an \*.ipk file.

When the \*.ipk file is ready, copy it onto a CDROM along with the subscriber documentation and include it in the CPE package.



### To create a configuration \*.tar file:

- 1 Choose a CPE from which to create the default configuration file.
- 2 Configure the settings of the CPE as described in this manual.
- 3 Select **Engineering** from the main menu and open the **Dev Config** page (Figure 3-10).
- 4 Click **Export**. A \*.tar file is created and you can save it for later auto-configuration of additional CPEs.






Figure 3-10: Engineering - Dev Config Page

**To generate an ipk file:**

- 1 Create a new folder and copy the following files into it:
  - » Generate\_Provision\_V2.0.rar (provided on a CDROM)
  - » The \*.tar file created previously.
- 2 Extract the Generate\_Provision\_V2.0.rar and run the CPE Auto Configuration Tool: generate\_provision\_2.0exe; The Generate IPKG Tool window is displayed.

**Figure 3-11: Generate IPKG Tool**

- 3 Click **Import** and select the tar file you created previously.
- 4 Select the type of IPKG to generate:
  - » For Internet Service Provider (ISP) - the package will override the default configuration file.
  - » For User - the package will update the local subscriber configuration file only.
- 5 Click **Generate IPKG** and save the file as \*.ipk file. A green circle appears next to "Generate result" at the end of the ipk generation process.



**Figure 3-12: Generation Results**

- 6 Use the ipkg file to configure CPEs, and/or include it in a CDROM for the subscriber.





## 3.6 Operation Verification

To verify proper operation of the unit, examine the LED indicators on the front panel.

To verify data connectivity, from the end-user's PC or from a portable PC connected to the unit, ping a known device in the network, or connect to a known internet site (e.g [www.Alvarion.com](http://www.Alvarion.com)). This site can be reached by clicking the Alvarion logo on the top of any page in the GUI.

Operation can also be verified from Web GUI (Status > Device Status page, see [Figure 3-2](#))











# Chapter 4 - Configuring Setup Parameters

## In This Chapter:

- "Introduction" on page 36
- "Setting Basic Parameters" on page 37
- "Setting Password" on page 40
- "Setting Device Time Zone" on page 41
- "Setting Device Name" on page 42
- "Restore to Factory Default Configuration" on page 43



## 4.1 Introduction

The BreezeMAX PRO 6000's Setup menu allows you to implement general management functions for the unit, including setting connection modes, the system time zone, configuring the device name and access password, and restore settings to factory defaults.

---

**INFORMATION**

You can use the web browser interface to access the WAN IP address only if the unit already has an IP address that is reachable through your network.

The default LAN IP address of the BreezeMAX PRO 6000 is 192.168.254.251. The unit operates by default in DHCP mode.

---

When you make a configuration change in the Setup pages, the following message is displayed after clicking Apply: "Configuration setting". After the configuration is applied, a "Prepare for Reboot" message is displayed. The system performs a reboot and counts 60 seconds.

When applying Factory Defaults, a "Restore to factory default settings" message appears and then a Rebooting message and 60 seconds countdown are displayed.





## 4.2 Setting Basic Parameters

The Basic Setup allows you to configure the main system parameters.



Do not change parameters in this page unless specifically instructed by your service provider. Doing so may cause your internet/VoIP connection to fail, and you will need to reset the unit to default parameter values.




Figure 4-1: Setup - Basic Parameters

The following table describes the configurable Basic parameters:

Table 4-1: Basic Parameters

Parameter	Description	Default	Possible Values
<b>Operation Mode</b>			
Operation Mode	Specifies the mode for forwarding data packets from the service provider's WiMAX network to the local network.	Router	<ul style="list-style-type: none"> <li>■ Router (the only option, unless differently configured by Alvarion)</li> <li>■ Bridge IPCS</li> <li>■ Bridge ETHCS</li> </ul>

Table 4-1: Basic Parameters (Continued)

Parameter	Description	Default	Possible Values
<b>Internal Management/VoIP Connection Mode</b>			
Management Connection Mode	<p>Sets the forwarding mode for sending management packets to the WiMAX network:</p> <ul style="list-style-type: none"> <li>■ Bridge mode - forwards packets based on Layer 2 MAC addresses. Bridge mode means that management connection has a different IP than data connection. This IP is used for communication with the management server, for web access from WAN, ping, etc.</li> <li>■ Router mode - forwards packets based on Layer 3 IP addresses. Uses data interface for Management communication.</li> </ul>	Router	<ul style="list-style-type: none"> <li>■ Bridge</li> <li>■ Router</li> </ul>
VoIP Connection Mode	<p>Sets the forwarding mode for sending VoIP packets to the WiMAX network:</p> <ul style="list-style-type: none"> <li>■ Bridge mode forwards packets based on Layer 2 MAC addresses. Bridge mode means that voice connection has a different IP than data or management connections. This IP is used only for SIP/RTCP and RTP messages sent and received by the device's POTS (plain old telephone service) lines.</li> <li>■ Router mode forwards packets based on Layer 3 IP addresses. Uses data interface for VoIP communication.</li> <li>■ None - No forwarding. VoIP interface is not available.</li> </ul>	Router	<ul style="list-style-type: none"> <li>■ Bridge</li> <li>■ Router</li> <li>■ None</li> </ul>

Table 4-1: Basic Parameters (Continued)

Parameter	Description	Default	Possible Values
<b>Connection Mode</b>			
Connection Mode	<p>Sets the connection type for the unit:</p> <ul style="list-style-type: none"> <li>■ DHCP - The system will assign IP addresses to the unit on the wide area network (WAN).</li> <li>■ Static - The IP address is predefined and fixed. When you select this option, new menu items are displayed for configuration: <ul style="list-style-type: none"> <li>» WAN IP Address</li> <li>» WAN Subnet Mask</li> <li>» WAN Gateway Address</li> <li>» DNS1- Domain Name System</li> <li>» DNS2</li> </ul> </li> </ul>	DHCP	<ul style="list-style-type: none"> <li>■ DHCP</li> <li>■ Static</li> </ul>
<b>WAN MTU</b>			
WAN MTU	<p>Sets the WAN maximum transmission unit (MTU) size in bytes</p> <ul style="list-style-type: none"> <li>■ Auto (1400) - transmission unit size is 1400 (maximum) bytes</li> <li>■ Manual - enter the value for transmission unit size (Range: 576-1500)</li> </ul>	Auto (1400)	<ul style="list-style-type: none"> <li>■ Auto (1400)</li> <li>■ Manual</li> </ul>

**INFORMATION**

Static IP is not supported by 4Motion equipment.



## 4.3 Setting Password

The Password page enables you to change the default password for remote and local access to the Graphical User Interface (GUI).

**INFORMATION**



It is strongly recommended that you configure your own password. If a password is not configured, the management interface is not protected and your network security may be compromised since the default password is not secure.

Keep a record of the password in a safe place, in case you will need to restore it.

Basic **Password** Device Time Device Name Restore To Factory

New Login Password

Confirm New Login Password

Undo Apply Help

Figure 4-2: Setup - Password



**To change the login password:**

- 1 Enter a new login password (up to 19 characters).
- 2 Enter the new password again for verification.
- 3 Click **Apply**.

## 4.4 Setting Device Time Zone

The BreezeMAX PRO 6000 uses the Simple Network Time Protocol (SNTP) to set its internal clock based on periodic updates from a time server. Maintaining an accurate time on the device enables the system log to record meaningful dates and times for event entries. This time value may also be passed to telephone handsets connected to the unit's phone line connections, depending on the capabilities of your phone.

The screenshot shows the 'Device Time' configuration page. At the top, there are navigation tabs: 'Basic', 'Password', 'Device Time' (which is highlighted), 'Device Name', and 'Restore To Factory'. Below the tabs, the page displays the following information:

- Current Local Time: 2:24:28
- Time Zone: A dropdown menu showing '(GMT-06:00) Central Time (USA & Canada)'
- Auto Adjust for Daylight Saving Time: A checked checkbox.

At the bottom of the page, there are three buttons: 'Undo', 'Apply', and 'Help'.

**Figure 4-3: Setup - Device Time**

The Device Time page displays the following information:

- **Current Local Time (hh:mm:ss)** – Displays the current time of the system clock.
- **Time Zone** – SNTP uses Greenwich Mean Time, or GMT (also known as Universal Time Coordinated, or UTC) based on the time at the Earth's prime meridian, zero degrees longitude. To display a time corresponding to your local time, select your time zone from the pull-down list. The default is GMT-6, for Central Time (USA and Canada.)
- **Auto Adjust for Daylight Saving Time** - Select this check-box to set the daylight saving time if the unit operates in a region that observes daylight saving time. The default is Enabled.

## 4.5 Setting Device Name

This page allows you to define a name that identifies your unit. Using an easy-to-remember name instead of the default one will simplify access to the unit's GUI Setup menu. You can type the device name, followed by a dot(.) in the address bar of the Web browser to login from LAN (for example: *http://mycpe.*).



The screenshot shows a web interface for configuring the device name. At the top, there are navigation tabs: [Basic](#), [Password](#), [Device Time](#), **Device Name**, and [Restore To Factory](#). The main content area displays the following information:

- Current Device Name: WiMaxCPE
- New Device Name:

At the bottom of the form, there are three buttons: **Undo**, **Apply**, and **Help**.

**Figure 4-4: Setup - Device Name**

The Device Name page displays the following information:

- **Current Device Name** - Displays the current name of the unit (Default: BMAX6000)
- **New Device Name** - Enter a new name for your device (up to 20 ASCII printable characters) and click **Apply**.



## 4.6 Restore to Factory Default Configuration

This page resets the unit to its factory default settings. When returning to factory defaults, the default configuration file (IPKG) is reloaded, resetting all the parameters to those defined in this file.

All the changes from the default factory settings will be lost, including voice. Essential Voice service settings will be restored automatically within a short period of time by the network once the device is operational after the reboot. You need to manually restore any parameter changes, such as voice settings that you have made, since these settings will not exist after the unit reboots following the default restoration.

**NOTE!**



Do not change parameters in this page unless specifically instructed by your service provider.



**Figure 4-5: Setup - Restore to Factory Warning**

To restore settings to factory defaults, select the checkbox on this page and click **Apply** to confirm the action. After applying factory defaults, the unit reboots.





# Chapter 5 - Configuring Local Address Parameters

## In this chapter:

- ["Introduction" on page 45](#)
- ["DHCP Server" on page 46](#)
- ["Lease Status" on page 47](#)
- ["Lease Reservation" on page 48](#)



## 5.1 Introduction

This chapter describes how to configure internal unit parameters such as DHCP server details and leasing parameters.

### INFORMATION



Any changes to this section should only be carried out by a network administrator familiar with the functionality of these settings.

## 5.2 DHCP Server

The unit has a built-in DHCP server that can be used for managing the distribution of IP addresses for the devices connected to the local Ethernet ports. In the DHCP Server page you set DHCP parameters for dynamic IP assignment.

Figure 5-1: DHCP Server

- **Enable DHCP Server** - Select this check-box dynamically assign a leased IP address to clients that connect to the device from the local network. This option is applicable to IP CS modes only. For Bridge IPCS and Bridge ETHCS this option is disabled.
- **DHCP Server IP Address** - Enter a DHCP server IP address. The default address is 192.168.254.251.
- **DHCP Starting IP Address** - Enter the first IP address assigned by the DHCP server. The default address is 192.168.254.1.
- **DHCP Ending IP Address** - Enter the last IP address assigned by the DHCP server. The default address is 192.168.254.5.
- **DHCP Lease Time** - Set the time for renewing the IP Lease. Default: 15 minutes.

## 5.3 Lease Status

The Lease Status page displays information regarding the leased IP address(es):

- Client Host PC Name
- Host PC MAC Address
- IP Address
- Remaining Lease Duration (seconds)

Client Host Name	MAC Address	IP Address	Remaining Lease Duration
Michalz-xplap	00:1C:25:10:75:AB	192.168.15.245	2634 second

**Figure 5-2: Lease Status**

Click **Refresh** to display the updated information of the client host PC.

Click **Auto** to refresh the information automatically.

## 5.4 Lease Reservation

The Lease Reservation page displays information on reserved IP addresses for leasing. In this page you assign the specific IP addresses to the specific client device connected to the Ethernet ports. You can also add, delete, or modify the reservation settings.

Select	Host Name	MAC Address	IP Address	Enabled
<input type="checkbox"/>	<input type="text"/>	<input type="text"/> : <input type="text"/> : <input type="text"/> : <input type="text"/> : <input type="text"/>	<input type="text"/> . <input type="text"/> . <input type="text"/> . <input type="text"/>	<input checked="" type="checkbox"/>

**Figure 5-3: Lease Reservation**

- **Select** - Choose an IP to delete.
- **Host Name** - Enter a name to the host
- **MAC Address** - Add a device MAC address
- **IP Address** - Specify a reservation IP address for a specified MAC address
- **Enabled** - Select if to enable or disable a specified IP setting.

Use the **Add** or **Delete** buttons to add or clear reserved IPs for leasing. Click **Apply** to activate your changes.



# Chapter 6 - Setting Advanced Parameters

## In this chapter:

- "Introduction" on page 50
- "Authentication" on page 51
- "Security" on page 53
- "Firewall" on page 55
- "MAC Filter" on page 57
- "IP Filter" on page 58
- "Port Forwarding/Trigger" on page 59
- "Dynamic DNS" on page 62



## 6.1 Introduction

This chapter describes how to configure advanced parameters, such as: Firewall protection, authentication methods, security parameters, filters for blocking the access of unauthorized clients, port forwarding and triggering, and also the Dynamic DNS (Domain Name System) provider.





## 6.2 Authentication

The Authentication page allows you to set the parameters for the authentication method in order to gain access to the WiMAX network.

**NOTE!**



Do not change parameters in this page unless specifically instructed by your service provider.

**Authentication** [Security](#) [Firewall](#) [MAC Filter](#) [IP Filter](#) [Port Forwarding/Trigger](#) [Dynamic DNS](#)

Setup

WiFi

Local Address

**Advanced**

Status

Telephony

REBOOT

RECONNECT

Authentication Method

User Name

Password

Password Confirmation

**Figure 6-1: Advanced - Authentication**

The Authentication page includes the following parameters:

- **Authentication Method** - Select one of the following WiMAX security methods:
  - » None - Authentication is disabled
  - » EAP-TTLS-MSCHAPV2 (Default) - EAP-Tunneled Transport Layer Security, supporting the Microsoft version of the Challenge-handshake authentication protocol, version 2.
  - » EAP TLS - EAP-Transport Layer Security (available only if enabled by the operator)

When Authentication is enabled, set the following parameters:



- **User Name** - Enter the user name supplied by the service provider (Default: CPE MAC address@WiMAX.com, e.g. 0026824EE12C@WiMAX.com).
- **Password** - Enter the user password (supplied by the service provider). Default: quickynikynyoky
- **Password Confirmation** - Re-enter the user password to confirm it.




## 6.3 Security

The Security page enables to configure the firewall feature. The firewall feature can be used to block unauthorized access while allowing only authorized communications from the Internet network. This feature also allows the device to be managed over the Internet by authorized personnel.

**NOTE!**



Do not change parameters in this page unless specifically instructed by your service provider.



**Figure 6-2: Advanced - Security**

The Security page includes the following parameters:

- **Enable Web login from Internet** - Select this check-box to access the device from other networks. When web login is enabled and a port is defined, you can access the device from another network Simply by opening a browser and entering the address of the device (Default: Enabled)
- **Web Login Port from Internet** - Define a specific port number for security access control (the default port number is 8080). Available only if Web Login from Internet is enabled.
- **Enable ping from Internet** - Enables to set the unit to respond to ping commands for troubleshooting purposes (Default: Disabled).



**INFORMATION**



The Enable Ping From Internet option is used for testing, therefore it is recommended to keep it disabled during normal operation.

You can ping and receive a replay from the LAN network while ping is disabled. However, when this option is disabled, you cannot ping from WAN to the unit.

To issue a Ping command, enter the destination address and click **Ping**. The response will be displayed in the area below the Ping button.

To access the unit from WAN, use [https://CPE\\_WAN\\_IP\\_Address:8080](https://CPE_WAN_IP_Address:8080).

## 6.4 Firewall

The BreezeMAX PRO 6000 provides extensive firewall protection by restricting connection parameters to limit the risk of intrusion and defending against a wide array of common hacker attacks. However, for applications that require unrestricted access to the Internet, you can configure a specific client/server as a demilitarized zone (DMZ).

**NOTE!**

Changes made on this page may affect your internet connection. If you notice an undesirable change in your internet service after making a change to the firewall, you may want to return to the previous setting.

Section	Parameter	Value
Firewall	Enable Firewall	<input checked="" type="checkbox"/>
	Block Anonymous Internet Requests	<input type="checkbox"/>
	Filter Multicast	<input type="checkbox"/>
	Filter Internet NAT	<input checked="" type="checkbox"/>
	Filter IDENT (Port 113)	<input type="checkbox"/>
DMZ	Enable DMZ	<input type="checkbox"/>
	DMZ IP Address	192.168.209.
UPnP	Enable UPnP IGD	<input type="checkbox"/>
VPN Passthrough	Enable IPSec pass-through	<input checked="" type="checkbox"/>
	Enable PPTP pass-through	<input checked="" type="checkbox"/>
	Enable L2TP pass-through	<input checked="" type="checkbox"/>

**Figure 6-3: Advance - Firewall**

The following configuration parameters are available:



### ■ Firewall settings

- » **Enable Firewall** - Select this check-box to enable or disable firewall.
- » **Block Anonymous Internet Requests** - Select this check-box to reject anonymous Internet requests.
- » **Filter Multicast** - Select this check-box to filter out multicast packets.
- » **Filter Internet NAT Redirection** - NAT Redirection is used to block access to the local server from the local PC via unit's WAN IP. If this feature is enabled, local PC can only access the local server via unit's LAN IP.
- » **Filter IDENT (Port 113)** - Select this check-box to drop incoming packets from the unit WAN side with destination port 113.

### ■ DMZ ("Demilitarized Zone")

- » **Enable DMZ** - Set a server that acts as a "neutral zone" and separates an internal network from a public one in order to prevent outside access to private data. The DMZ forwards the network traffic to specific hosts based on the protocol and port number.
- » **DMZ** - DMZ IP Address.

- **UPnP - Enable UPnP IGD** - Select this check-box to enable/disable Universal Plug and Play Internet Gateway Device - a protocol that simplifies device connection and network implementation. When this option is enabled, certain Windows applications would setup the port forwarding rule dynamically.

- **VPN Passthrough** - Select one of the following security protocols to define the Virtual Private Network traffic sessions.

#### NOTE!



Do not change parameters in this page unless specifically instructed by your service provider.

- » **Enable IPSec pass-through** - Internet Protocol Security. IPSec provides encrypted security services at the IP layer, and enables to use encrypted tunnels /traffic between two hosts.
- » **Enable PPTP pass-through** - Point to Point Tunneling Protocol. This protocol enables the transfer of data packets of TCP / IP through a foreign network that is not based on these protocols (by marking the packet with an address suited to the foreign network)
- » **Enable L2TP pass-through** - Layer 2 Tunneling Protocol, an open standard with multivendor interoperability and acceptance.



## 6.5 MAC Filter

You can block access to the Internet from clients on the local network by MAC addresses. In the MAC Filter page you set MAC addresses to be filtered out by the security system. You can add addresses to the filtered group or delete them, and also enable or disable filtering at different times.




Figure 6-4: Advance - MAC Filter

The following configuration parameters are available:

- **Select** - Select this check-box to delete this entry.
- **MAC** - Enter the MAC address to be filtered.
- **Enabled** - Select this check-box to enable/disable filter for the specific MAC address.

Use the **Add** or **Del** buttons to add the address to the filtered group or clear it from the group. Click **Apply** to activate your changes.

## 6.6 IP Filter

You can block access to the Internet from clients on the local network by specifying IP addresses and TCP/UDP port numbers. You can configure up to five IP filters on the unit.

In the IP Filter page you set IP addresses to be filtered out by the security system. You can add addresses to the filtered group or delete them. You can also enable or disable filtering at different times.

[Authentication](#)
[Security](#)
[Firewall](#)
[MAC Filter](#)
[IP Filter](#)
[Port Forwarding/Trigger](#)
[Dynamic DNS](#)

Select	IP Range	Port Range	Protocol	Enabled
<input type="checkbox"/>	192.168.254. <input type="text"/> ~ <input type="text"/>	<input type="text"/> ~ <input type="text"/>	TCP	<input checked="" type="checkbox"/>
<input type="checkbox"/>	192.168.254. <input type="text"/> ~ <input type="text"/>	<input type="text"/> ~ <input type="text"/>	TCP	<input checked="" type="checkbox"/>

**Figure 6-5: Advance - IP Filter**

The following configuration parameters are available:

- **Select** - Select this check-box to delete this entry.
- **IP Range** - Specify an IP address or range on the local network. (Range: 192.168.254.1 to 192.168.254.254)
- **Port Range** - Enter the port range to be filtered
- **Protocol** - set the protocol to be filtered: TCP (default) or UDP.
- **Enabled** - Select this check-box to enable (default) or disable filtering for the specific table entry.

Use the **Add** or **Del** buttons to add the address to the filtered group or clear it from the group. Click **Apply** to activate your changes.



## 6.7 Port Forwarding/Trigger

### 6.7.1 Port Forwarding

Port Forwarding instructs the router to which computer on the local area network to send data. According to the port forwarding rules or setup, the router sends the data from the external IP address: port number to an internal IP address: port number. Port Forwarding rules are created per port.

The Port Forwarding page enables managing and setup of the rules for Port Forwarding.

The screenshot shows the 'Port Forwarding / Port Trigger' configuration page. At the top, there are navigation links: 'tion', 'Security', 'Firewall', 'MAC Filter', 'IP Filter', 'Port Forwarding/Trigger', and 'Dynamic DNS'. The main content area is titled 'Port Forwarding / Port Trigger' and contains a table with the following structure:

Select	Protocol	WAN Port		LAN IP	Enabled
		Begin	End		
<input type="checkbox"/>	TCP				<input checked="" type="checkbox"/>

Below the table, there are five buttons: 'Add', 'Del', 'Undo', 'Apply', and 'Help'.

**Figure 6-6: Advance - Port Forwarding**

The following configuration parameters are available:

- **Select** - Select this check-box to delete this entry.
- **Protocol** - Set the protocol for port forwarding: TCP or UDP.
- **WAN Port** - Enter the range (begin and end ports) for the WAN.
- **LAN IP** - Enter the IP address of the computer from LAN network for which you open ports in "Port forwarding".
- **Enabled** - Select this check-box to enable/disable port forwarding for the specific IP

Use the **Add** or **Del** buttons to add a rule to the port forwarding group or clear it from the group. Click **Apply** to activate your changes.

## 6.7.2 Port Trigger

Port forwarding redirects incoming network traffic from a pre-defined WAN port range to a pre-defined LAN IP Address and LAN port range. Port triggering is a way to automate port forwarding: outbound traffic on predefined ports ('triggering ports') causes inbound traffic to specific incoming ports to be dynamically forwarded to the initiating host, while the outbound ports are in use. This allows computers behind a NAT-enabled router on a local network to provide services that would normally require the computer to have a fixed address on the local network. Port triggering triggers can open an incoming port when a client on the local network makes an outgoing connection on a predetermined port or range of ports.

In the Port Trigger page you can specify up to 15 rules with parameters for Port Triggering.

Port Forwarding / **Port Trigger**

Select	No.	Application Name	Triggered Range	Forwarded Range	Enabled
<input type="checkbox"/>	1	<input type="text"/>	<input type="text"/> ~ <input type="text"/>	<input type="text"/> ~ <input type="text"/>	<input checked="" type="checkbox"/>

**Figure 6-7: Advance - Port Trigger**

The following configuration parameters are available:

- **Select** - Select this check-box to delete this entry.
- **No.** - Display the number of the port trigger rule
- **Application Name** - Enter a name for identifying this port trigger protocol.
- **Triggered Range** - Enter the trigger range (1~65535)
- **Forwarded Range** - Enter the forwarded range (1~65535)
- **Enabled** - Select this check-box to enable/disable port trigger for the specific application



Use the **Add** or **Del** buttons to add a rule to the port triggering group or clear it from the group. Click **Apply** to activate your changes.

## 6.8 Dynamic DNS

Dynamic Domain Name System (DNS) is a mechanism used for translating host names for network nodes into IP addresses in real-time. This page allows enabling the Dynamic DNS and selecting the service provider.

The screenshot shows a web interface for configuring Dynamic DNS. At the top, there is a navigation menu with the following items: Authentication, Security, Firewall, MAC Filter, IP Filter, Port Forwarding/Trigger, and Dynamic DNS. The 'Dynamic DNS' item is highlighted in blue. Below the navigation menu, there is a main content area with a light green background. In the center of this area, there are two settings: 'Enable DDNS' with an unchecked checkbox, and 'DDNS Service Provider' with a dropdown menu showing 'www.dyndns.org'. At the bottom of the content area, there are three buttons: 'Undo', 'Apply', and 'Help'.

**Figure 6-8: Advanced - Dynamic DNS**

The Dynamic DNS page includes the following parameters:

- **Enable DDNS** - Select this check-box if the unit has a non-static IP address to keep the domain name associated with an ever-changing IP address.

When DDNS is enabled, configure the following parameters:

- » DDNS User Name
  - » DDNS Password
  - » DDNS Host Name
- **DDNS Service Provider** - Select the DDNS service provider from the drop-down list (Default: www.dyndns.org).

# Chapter 7 - Displaying Status Details

## In this chapter

- "Introduction" on page 64
- "Device Status" on page 65
- "WiMAX Status" on page 67
- "Software Status" on page 72
- "Telephony Status" on page 73
- "Certificate Status" on page 74
- "About" on page 76



## 7.1 Introduction

This chapter describes how to view and understand the various parameters that are currently set on your unit. The Status menu item includes pages containing information on all the features of the device, such as the device currently used software, the Telephony status, WiMAX parameters, certification information, etc.

## 7.2 Device Status

This page displays the status of the unit such as system uptime and WAN information.

**Figure 7-1: Status - Device Status**

- Click **Refresh** to display the current device status.
- Click **Auto** to update the status information periodically.
- The following information is displayed:

**Table 7-1: Device Status Parameters**

Item	Description
Operation Mode	The mode for forwarding data packets from the service provider's WiMAX network to the local network, as defined in " <a href="#">Setting Basic Parameters</a> " on <a href="#">page 37</a> . Available option: Router.
Connection Mode	Connection type for the unit, as defined in " <a href="#">Setting Basic Parameters</a> " on <a href="#">page 37</a> . Available options: DHCP, Static
IP Address	WAN IP address, if the Static connection mode was selected, as defined in " <a href="#">Setting Basic Parameters</a> " on <a href="#">page 37</a> . For DHCP mode - IP address acquired on the WAN interface is displayed. Otherwise it is 0.0.0.0
MAC	WAN MAC Address for data interface

**Table 7-1: Device Status Parameters (Continued)**

Item	Description
IP Subnet Mask	The IP subnet mask, if the Static connection mode was selected, as defined in <a href="#">"Setting Basic Parameters" on page 37</a> , For DHCP mode - IP Subnet Mask acquired on the WAN interface is displayed. Otherwise it is 0.0.0.0
IP Default Gateway	The IP Default Gateway, if the Static connection mode was selected, as defined in <a href="#">"Setting Basic Parameters" on page 37</a> . For DHCP mode - IP Default Gateway acquired on the WAN interface is displayed. Otherwise it is 0.0.0.0
IP Default Connection	IP is connected to the network (On/Off)
Firewall	Firewall enabled or disabled (on/off), as set in <a href="#">"Firewall" on page 55</a> .
Lease Obtained-Data	Date of obtaining the device leasing.
Lease Expires-Data	Date of device leasing expiration.
DNS Server	The Domain Name Server address
Time Server	The NTP (Network Time Protocol) server address
Device Up Time	Duration of device function (xdays yhours zminutes)
Device Restart Reason	The reason for last device reboot (e.g. Software Upgrade)
Serving BSID	Base Station ID number (e.g. 00:01:21:00:03:5A)
RSSI	Currently received signal strength indication (e.g. -70 dBm)
CINR	Carrier to Interference-plus-Noise Ratio [in decibels (dB)] (e.g. 13 dB). This value should be maximized for best signal quality.



## 7.3 WiMAX Status

The WiMAX Status displays a summary of the WiMAX network connection parameters.

The screenshot displays the WiMAX Status page with the following sections and data:

**Device Status** | **WiMAX Status** | Software | Telephony Status | Certificate | About

**WiMAX SYSTEM**

State : <u>SCAN</u>	Scan Type : <u>CAPL</u>
BSID : <u>N/A</u>	RSSI : <u>N/A</u>
CINR : <u>N/A</u>	Temperature : <u>49 °C / 120 °F</u>
Security : <u>UNAUTHORIZED</u>	Overheat : <u>none</u>
Bandwidth : <u>N/A</u>	TxPwr : <u>N/A</u>
Max Tx Power : <u>N/A</u>	Min Tx Power : <u>N/A</u>
Max RSSI : <u>N/A</u>	Min RSSI : <u>N/A</u>
Max CINR : <u>N/A</u>	Min CINR : <u>N/A</u>
Connection Time : <u>0_secs</u>	Center Frequency : <u>N/A</u>

**WiMAX RX**

Data Rate : <u>N/A</u>
Packets : <u>N/A</u>
BE bytes : <u>N/A</u>
UGS bytes : <u>N/A</u>
ERTPS bytes : <u>N/A</u>
RX bytes : <u>N/A</u>

**WiMAX TX**

Data Rate : <u>N/A</u>
Packets : <u>N/A</u>
BE bytes : <u>N/A</u>
UGS bytes : <u>N/A</u>
ERTPS bytes : <u>N/A</u>
TX bytes : <u>N/A</u>

**WiMAX PHY :**

DL Mode : <u>SISO</u>	UL max mcs : <u>QPSK-1/2</u>
DL max mcs : <u>QPSK-1/2</u>	UL min mcs : <u>QPSK-1/2</u>
DL min mcs : <u>QPSK-1/2</u>	UL mcs : <u>QPSK-1/2</u>
DL mcs : <u>QPSK-1/2</u>	

QPSK 1/2 DL PDUs : <u>827</u>	QPSK 1/2 UL PDUs : <u>123</u>
QPSK 3/4 DL PDUs : <u>0</u>	QPSK 3/4 UL PDUs : <u>0</u>

16QAM 1/2 DL PDUs : <u>0</u>	16QAM 1/2 UL PDUs : <u>0</u>
16QAM 3/4 DL PDUs : <u>0</u>	16QAM 3/4 UL PDUs : <u>0</u>
64QAM 1/2 DL PDUs : <u>0</u>	64QAM 1/2 UL PDUs : <u>0</u>
64QAM 2/3 DL PDUs : <u>0</u>	64QAM 2/3 UL PDUs : <u>0</u>
64QAM 3/4 DL PDUs : <u>0</u>	64QAM 3/4 UL PDUs : <u>0</u>
64QAM 5/6 DL PDUs : <u>0</u>	64QAM 5/6 UL PDUs : <u>0</u>

**TX Service Flow :**

Type	SFID	CID	DropPackets	DropBytes
------	------	-----	-------------	-----------

**RX Service Flow :**

Type	SFID	CID
------	------	-----

**Refresh** **Auto**

**Figure 7-2: Status - WiMAX Status**

- Click **Refresh** to display the current WiMAX connection status.
- Click **Auto** to update the status information periodically (every 3 seconds)

The following table describes the WiMAX Status parameters:

Table 7-2: WiMAX System Parameters

Parameter	Description	Possible values
<b>WiMAX System</b>		
State	The status of WiMAX connection.	<ul style="list-style-type: none"> <li>■ Network Entry - the unit has just been connected to the network</li> <li>■ Operational - the unit is functional</li> <li>■ Scan - the unit scans the network</li> <li>■ Idle - the unit is de-registered from the network, however will continue to scan the network and keep track of its location</li> </ul>
BSID	The Base Station ID	Depends on the BS to which the unit is connected
CINR	Carrier to Interference-plus-Noise Ratio [in decibels (dB)] - a measurement of signal effectiveness. A greater value will improve the connection speed.	0-35 dB
Security	The network security technologies and protocols status	<ul style="list-style-type: none"> <li>■ Authorized - has authentication settings</li> <li>■ Unauthorized - without authentication setting. Unauthorized also appears for units set with authentication, when they are not linked to a BS and successfully authenticated.</li> </ul>
Bandwidth	Device operation bandwidth	Depending on unit model: 5000, 7000, or 10000 KHz
Max Tx Power	The maximum uplink transmit power	
Max RSSI	The maximum signal strength indication value used since the last reboot	-35 to -100 dBm
Max CINR	The maximum Carrier to Interference-plus-Noise Ratio value used since the last reboot	
Connection Time	Time (in seconds) during which the unit is connected to the BS	

Table 7-2: WiMAX System Parameters (Continued)

Parameter	Description	Possible values
Scan Type	The method by which the network is scanned	<ul style="list-style-type: none"> <li>■ Fullband - The system will try to scan the whole frequency band.</li> <li>■ CAPL - Channel Allocation Priority Level. The system allocates priority to channels for scanning order.</li> <li>■ Neighbor - The system will try to scan the neighbor BS to the previous BS defined in "Last good BS". The neighbor BS details will appear in the table of this section.</li> <li>■ History - The system will try to scan with the previous good BS to speed up the scan duration. A "good BS" is defined as one with which the unit can get an IP address.</li> </ul>
RSSI	Currently received signal strength indication	-35 to -100 dBm
Temperature	Unit's temperature	
Overheat	Indication of temperature higher than 40°	
TxPwr	Current uplink transmit power	
Min Tx Power	Minimum uplink transmit power	
Min RSSI	The minimum signal strength indication value used since the last reboot	
Min CINR	Minimum Carrier to Interference-plus-Noise Ratio value used since the last reboot	
Center Frequency	The middle frequency of the bandwidth of a channel. The unit is synchronised on this frequency.	
<b>WiMAX TX Uplink Statistics</b>		
Data Rate	Shows the current throughput in uplink direction. The level of available data throughput that can actually be provided to an end-user.	
Packets	The number of carried blocks of data	

**Table 7-2: WiMAX System Parameters (Continued)**

Parameter	Description	Possible values
BE bytes	Total number of bytes sent on Best Effort connection	
UGS bytes	Total number of bytes sent on Unsolicited Grant Service connection	
ERTPS bytes	Total number of bytes sent on ERTPS - Extended Real-time Polling Service data packets.	
TX bytes	Total of uplink transmitted bytes	
<b>WiMAX RX Downlink Statistic</b>		
Data Rate	Shows the current throughput in downlink direction. The level of available data throughput that can actually be provided to an end-user.	
Packets	Number of carried blocks of data	
BE bytes	Total number of bytes sent on Best Effort data packets	
UGS bytes	Total number of bytes sent on Unsolicited Grant Service data packets	
ERTPS bytes	Total number of bytes sent on Extended Real-time Polling Service data packets	
RX bytes	Total of downlink transmitted bytes	
<b>WiMAX PHY</b>		
DL Mode	Downlink connection mode	SISO, MIMO, MiMO A, MIMO B
DL max mcs	The maximum modulation reached	
DL min mcs	The minimum modulation reached	
DL mcs	Current modulation	
UL max mcs	The maximum modulation reached	
UL min mcs	The minimum modulation reached	
UL mcs	The current modulation	

Table 7-2: WiMAX System Parameters (Continued)

Parameter	Description	Possible values
List of various modulations: <ul style="list-style-type: none"> <li>■ QPSK DL/UL PDUs</li> <li>■ 16QAM DL/UL PDUs</li> <li>■ 64QAM DL/UL PDUs</li> </ul>	Number of packets in this modulation	
<b>TX Service Flow / Rx Service Flow</b>		
Type	The service flow type	Best effort, ERT, NRT, UGS
SFID	Service flow ID	
CID	Connection ID	
DropPackets (Tx only)	Number of packets that were dropped	
DropBytes (Tx only)	Number of bytes that were dropped	




## 7.4 Software Status

The Software page enables installing or removing IPKGs (Itsy Package Management System) - lightweight package management systems that allows for dynamic installation/removal of packages on a running system.

**INFORMATION**



Use this page only upon instructions from Alvarion.



**Figure 7-3: Status - Software**


- To install an IPKG - Click **Browse** to load and install an Itsy Package Management System and click **Upgrade**.
- To remove an IPKG - Click **Remove** next to the component to be deleted.

The page also displays the current software items installed by the operator on the device. These are read-only items that cannot be edited/removed



## 7.5 Telephony Status

This page displays information on the telephone line status.



**Figure 7-4: Status - Telephony Status**

The information displayed in this window is:

- **SIP User IP address** - IP address of the Session Initiation Protocol, an application-layer control protocol that can establish, modify, and terminate multimedia sessions such as Internet telephony calls (VOIP).
- **Line 1 Status** - Registered or De-registered in the SIP server.
- **DSP Version** - current version of the voice chip in the Data Signal Processor (DSP).
- Click **Refresh** to display the current telephony status.
- Click **Auto** to update the status information periodically (every 3 seconds).

## 7.6 Certificate Status

The Certificate page displays available certificates information, such as serial number, issuer of certificate, type and expiration date. Root CA certificates can be added or deleted using this page.

**NOTE!**



Do not change parameters in this page unless specifically instructed by your service provider.

The screenshot shows a web interface with a navigation menu at the top: [Device Status](#), [WiMAX Status](#), [Software](#), [Telephony Status](#), **Certificate**, and [About](#). Below the menu, there are two main sections:

**Device Certificate**

Serial Number

Issued to

Issued by

Expiry Date

Certificate Import Path

**Root CA Certificate**

Serial Number	Issued to	Issued by	Expiry-Date	Type	Edit
01A5A658F8D3456	WiMAX Forum(R)	WiMAX Forum(R)	12/31/2010	factory	-
15EAF256B321990	WiMAX Forum(R)	WiMAX Forum(R)	12/31/2049	factory	-
6306729A728CBD6	WiMAX Forum(R)	WiMAX Forum(R)	12/31/2049	factory	-
C58DE6DCAA7297A	WiMAX Forum(R)	WiMAX Forum(R)	01/03/2053	factory	-

At the bottom of the page, there is a

**Figure 7-5: Status - Certificate**

The page displays the following information in a table:

- Certificate Serial Number
- Issued to
- Issued by
- Expiry Date - the date for certificate expiration. The format is mm/dd/yyyy.
- Certificate type
- Edit - option to remove a certificate from the list (only if the Remove option appears in this column)





**INFORMATION**



The table displays only part of the information (e.g. part of the serial number). To view the entire string, hover the mouse over the cell to display a tool-tip with the entire string.

- To add a certificate, click **Browse** and select the file to load. Click **Import** to add the certificate to the list.
- To remove an editable certificate, click **Remove** next to the certificate to be deleted. Some certificates are read-only and cannot be deleted.



## 7.7 About

This page displays the current information about the unit. The information is set by the manufacturer as the factory defaults.

The information includes:

- Service Provider
- Product Name
- WAN MAC
- LAN MAC
- Model ID
- Hardware Version
- Serial Number




Figure 7-6: Status - About

# Chapter 8 - Configuring Telephony Parameters

## In this chapter

- ["Introduction" on page 78](#)
- ["VoIP Parameters" on page 79](#)



## 8.1 Introduction

This chapter describes how to configure VoIP parameters.

Voice over Internet Protocol (VoIP) technology is a way of using the Internet to make phone calls. You can make VoIP calls by connecting a regular phone to one of the unit's Phone ports.

Before using the VoIP Phone ports on the unit, you must have an account with a SIP service provider that includes one voice line. Setup of the modem is automatic and you will not need to make any changes to this page to have your voice service enabled, however you may want to change some of the features that are listed below. The modem allows the Phone port to be configured separately with different settings.

---

**NOTE!**



Modifying the user name, password, or user account settings is not required. These attributes are automatically populated when the modem is configured after connection. If you are having trouble with your voice service, contact Customer Service for support. Do not make changes to these items in an attempt to restore your service.

---

## 8.2 VoIP Parameters

VoIP

Line1

User Name:

PassWord:

Confirm PassWord:

User Account:

Display Name:

Call Waiting:

Call Waiting TimeOut:  seconds

Call Block

No	Incoming	Outgoing
1	<input type="text"/>	<input type="text"/>
2	<input type="text"/>	<input type="text"/>
3	<input type="text"/>	<input type="text"/>
4	<input type="text"/>	<input type="text"/>
5	<input type="text"/>	<input type="text"/>
6	<input type="text"/>	<input type="text"/>
7	<input type="text"/>	<input type="text"/>
8	<input type="text"/>	<input type="text"/>
9	<input type="text"/>	<input type="text"/>
10	<input type="text"/>	<input type="text"/>
11	<input type="text"/>	<input type="text"/>
12	<input type="text"/>	<input type="text"/>

**Figure 8-1: Telephony - VoIP Parameters**

The VoIP page includes the following parameters:

- **User Name** - The SIP (Session Initiation Protocol) User name. Its format depends on the Sip Server
- **Password** and **Confirm Password** - The SIP user Password
- **User Account** - The SIP Account. Its format depends on the Sip Server.
- **Display Name** - Enter a name that will be displayed on the Caller ID Display Name of the receiving party (if supported by the network)



- **Call Waiting** - Select this check-box to enable/disable suspending the current telephone call and switch to a new incoming call (Default: Disabled).
- **Call Waiting Timeout** - enter a number of seconds after which the call waiting is timed out (Default: 30 seconds).
- **Call Block** list - set up the numbers as follows:
  - » Incoming - blocks incoming calls from the listed numbers (up to 50 digits).
  - » Outcoming - blocks outgoing calls from the listed numbers (up to 50 digits).

# Chapter 9 - Engineering

## In this chapter:

- "Introduction" on page 82
- "WiMAX Configuration" on page 83
- "VoIP Configuration" on page 87
- "Service Line" on page 96
- "Device Configuration" on page 100
- "DM (Device Management) Settings" on page 101
- "Function Settings" on page 106
- "UI Settings" on page 107



## 9.1 Introduction

The Engineering menu item is accessible to the Operator only and provides advanced CPE configuration parameters. The Engineering mode is available in a software package that is uploaded from the Status page; See [“WiMAX Status” on page 67](#)).

For detailed description of terms and abbreviations, refer to the [“Glossary” on page 109](#).





# 9.2 WiMAX Configuration

In this page the operator defines WiMAX parameters for the CPE WiMAX connection functionality.

**WMX Config** [VoIP](#) [Service Line](#) [DEV Config](#) [DM Settings](#) [Function Settings](#) [UI Settings](#)

**Common Setting**

Enable Idle Mode

Enable Handover

Enable WiMAX Supplicant Root CA

Enable WiMAX Supplicant Random ID

Enable WiMAX Supplicant Anonymous ID

WiMAX Supplicant Anonymous ID

Realm

Enable WiMAX NAP Filter

Enable prefer BSID

Prefer BSID

Prefer BSID mask

---

**Last Good BS Scan** clear

Enable Last Good BS Scan

Enable Hold On Last Good BS

Hold on timeout value

---

**Neighbor BSs Scan**

Enable Neighbor BSs Scan

---

**CAPL Scan**

Enable CAPL Scan


CAPL Scan List

NAPID	priority:1				
1	AB	CD	EF	HG	BC
	FH	BRS-1	A	B	C
	D	BRS-2	E	F	G
	H				

Channel Plan clear

RefID	First Freq/KHz	Last Freq/KHz	Step/KHz	Bandwidth/KHz	Select <input type="checkbox"/>
AB	-1	-1	-1	-1	<input type="checkbox"/>
CD	-1	-1	-1	-1	<input type="checkbox"/>
FF	-1	-1	-1	-1	<input type="checkbox"/>

Figure 9-1: Engineering - WMAX Config.



**Figure 9-1: Engineering - WMAX Config. (Continued)**

The following table describes the WMAX Configuration parameters:

**Table 9-1: WMAX Config. Settings**

Parameter	Description	Default	Possible Values
<b>Common Settings</b>			
Enable Idle Mode	Select this check-box to enable Idle Mode -the CPE is completely deregistered from the network, however will continue to scan the network and keep track of its location	Enable	Enable/disable
Enable Handover	Select this check-box to enable Handover - transfer to another BS during mobility	Enable	Enable/disable
Enable WiMAX Supplicant Root CA	IOT AAA root certificates are predefined in the CPE. Select this check-box to allow the CPE to verify BS's certification.	Disable	Enable/disable
Enable WiMAX Supplicant Random ID	Select this check-box to assign a random ID to the Supplicant. If disabled - the ID is the MAC_Address@realm.	Enable	Enable/disable



Table 9-1: WMAX Config. Settings (Continued)

Parameter	Description	Default	Possible Values
Enable WiMAX Supplicant Anonymous ID	If enabled, the unit will use "WiMAX Supplicant Anonymous ID" as anonymous identity, else the unit will use MAC_Address@realm instead.	Disable	Enable/disable
WiMAX Supplicant Anonymous ID	Enter the WiMAX Supplicant Anonymous ID to be used.	anonymous_identity	Up to 128 characters
Realm	The WiMAX domain	WiMax.com	
Enable WiMAX NAP Filter	Enables filtering Network Access Provider. If it is enabled - network provider ID will be checked for network entry.	Disable	Enable/disable
Enable Prefer BSID	When enabled, the CPE will connect to the preferred BS, whose details (ID and mask) are defined below.	Disable	Enable/disable
Prefer BSID	Enter an ID of the preferred base station.	N/A	
Prefer BSID mask	Enter a mask for the preferred base station.	N/A	
<b>Last Good BS Scan</b>			
Table of Last Good BSs	<ul style="list-style-type: none"> <li>■ BSID -Base Station ID</li> <li>■ CF/KHz - Channel Frequency</li> <li>■ BW/KHz - Bandwidth in KHz</li> <li>■ PreambleID - The Preamble ID of the BS</li> </ul> <p>Use the <b>Clear</b> button to delete a saved last good BS from the list.</p>	N/A	N/A
Enable Last Good BSs Scan	The system will try to scan with the previous good BS to speed up the scan duration. A "good BS" is defined as one with which the CPE can get an IP address.	Enable	Enable/disable
Enable Hold On Last Good BS	The system will try to connect to the last good BS for the specified time defined below.	Enable	Enable/disable



Table 9-1: WMAX Config. Settings (Continued)

Parameter	Description	Default	Possible Values
Hold on timeout value	Enter the period of time (in milliseconds) to keep referring to this BS as the Last Good BS when connection is not optimal.	300,000	50~900,000 ms
<b>Neighbor BS Scan</b>			
Enable Neighbor BS Scan	The system will try to scan the neighbor BS to the previous BS defined in "Last good BS". The neighbor BS details will appear in the table of this section.	Enable	Enable/disable
<b>CAPL BS Scan (Channel Allocation Priority Level)</b>			
NAPID	Sequential number of NAP	N/A	
Enable CAPL BS Scan	Channel Allocation Priority Level - The CAPL scan list is defined by the customer provisioned list. Priority is the customer defined priority scan order. Higher priority will be scanned first.	Disable	Enable/disable
Channel Plan	Define the channel plan by adding the Ref IDs, in order to map the IDs into a scan list.	N/A	
<b>Fullband Scan</b>			
Enable Fullband Scan	The system will try to scan the whole frequency band (250 kHz for the frequency step) with user specified bandwidth (5 MHz, 7 MHz, 10 MHz)	Enable	Enable/disable

## 9.3 VoIP Configuration

The BreezeMAX PRO 6000 CPE uses Session Initiation Protocol (SIP) as the control mechanism that sets up, initiates, and terminates calls between a caller and a called party. The SIP messaging makes use of "Proxy," "Redirect," and "Registration" servers to process call requests and find the location of called parties across the Internet. When SIP has set up a call between two parties, the actual voice communication is a direct peer-to-peer connection using the standard Real-Time Protocol (RTP), which streams the encoded voice data across the network.

Before using the VoIP Phone port on the unit, the user must have an account with a SIP service provider and configure the required parameters through the web interface.

The screenshot displays the VoIP configuration page with the following sections and fields:

- Global Setting:**
  - user Domain:
  - registrar Address:
  - outbound Proxy Address:
  - RTP Port Range Start:
  - DSP Nation:
  - G711 Fax Codec:
  - Hook Flash Max Timer:  ms
  - Registration Expire:  seconds
  - registrar Port:
  - outbound Proxy Port:
  - RTP Port Range End:
  - Caller ID:
  - Modem Call Codec:
  - Hook Flash Min Timer:  ms
  - Enable Telmex FQDN:
- Known SIP Provider:**
  - Enable WiMAX QoS For known SIP Provider:
  - Insert:
  - Table with columns: No., SIP Proxy Address, SIP Proxy PORT, Delete
- Customized Tone Settings:** (Section header)

At the bottom of the form are **Undo** and **Apply** buttons.

Figure 9-2: Engineering - VoIP

Customized Tone Settings

Default Dialtone: Default Callwaiting tone: Default MWI tone: 

Line 1 Setting

Common Setting

<p>Enable Line 1 <input checked="" type="checkbox"/></p> <p>DTMF Method: <input type="text" value="InBand"/></p> <p>callForward Unconditional: <input type="checkbox"/></p> <p>callForward Busy: <input type="checkbox"/></p> <p>callForward NoReply: <input type="checkbox"/></p> <p>Call Forwarding No Reply Timeout: <input type="text" value="30"/> seconds</p> <p>Caller ID Block: <input type="checkbox"/></p> <p>E911: <input type="text"/></p> <p>Redial: <input type="text"/></p> <p>Inter-digit T/O: <input type="text" value="3"/> seconds</p> <p>DialPlan: <input type="text" value="*xx xx.T"/></p> <p>Flash Timeout: <input type="text" value="15"/></p> <p>Enable Hold Tone: <input type="text" value="check"/></p>	<p>CallHold: <input checked="" type="checkbox"/></p> <p>callForward Unconditional Number: <input type="text"/></p> <p>callForward Busy Number: <input type="text"/></p> <p>callForward NoReply Number: <input type="text"/></p> <p>Do Not Disturb(DND): <input type="checkbox"/></p> <p>Anonymous Call Reject: <input type="checkbox"/></p> <p>Automatic Recall: <input type="text"/></p> <p>Automatic Call Back: <input type="text"/></p> <p>Call Switching: <input type="text"/></p> <p>Date Mode: <input type="text" value="Date Header"/></p> <p>CLIR per-call: <input type="text"/></p>
--	--

Codec Setting

g711u Codec Enable:  g711u Priority:  Codec G711u ptime:  ms

g711a Codec Enable:  g711a Priority:  Codec G711a ptime:  ms

g729 Codec Enable:  g729 Priority:  Codec G729 ptime:  ms

DSP Setting

Enable VAD:

Enable RTCP:  EC Length:  ms

JB Delay Max:  ms

JB DelayInit:  ms

Tx Gain:  db Rx Gain  db

T.38 Enable:

Undo
Apply

Figure 9-3: Engineering - VoIP (continued)

The following table describes the VoIP Settings parameters:

**Table 9-2: VoIP Settings**

Parameter	Description	Default	Possible Values
<b>Global Settings</b>			
user Domain	The host portion of the SIP Uniform Resource Identifiers (URIs) that are assigned to users in a network. The SIP domain name can sometimes be different from the internal network domain name.	N/A	Up to 256 characters
registrar Address	The IP address of the SIP registrar server. A registrar is a server that accepts SIP register requests and places the information it receives in those requests into the location service for the domain it handles.	N/A	Up to 256 characters
registrar Port	The TCP port number used by the VoIP service provider's register server.	5060	Range: 1030 to 65535
outbound Proxy Address	Address of the VoIP service provider SIP proxy server.	N/A	Up to 256 characters
outbound Proxy Port	The TCP port number used by the VoIP service provider's SIP proxy server.	5060	Range: 1030 to 65535
RTP Port Range Start	Enter the port Start and End to define the range that Real-time Transport Protocol will use	8000	Range: 1030 to 65535
RTP Port Range End		8015	
DSP Nation	National protocol definition	Customized	
Caller ID	<ul style="list-style-type: none"> <li>■ Select the standard by which the caller is identified:</li> <li>■ British TelecomDual-tone multi-frequency signaling standard</li> </ul>	US	
G711 Fax Codec	Select the codec to convert fax signals into digital data to be transmitted over the Internet.	g711a	g711u g711a
Modem Call Codec	Select the codec to be used for modem calls; when a modem call is detected, this codec will be used	g711u	g711u g711a

Table 9-2: VoIP Settings (Continued)

Parameter	Description	Default	Possible Values
Hook Flash Max/Min. Timer	Enter a value (in milliseconds) to define how long should the hook be pressed as to be considered as flash (hook should be pressed for a time between min. and max. values)	Max: 0.9 ms Min: 0.1 ms	100 - 1550 ms
Registration Expire	Enter a value (in seconds) to define the time by which the CPE has to renew its subscription to the SIP server	3600 seconds	1 - 99999 seconds
Enable Telmex FQDN	Enable Request for Comments (RFC) 3263 "Locating SIP Servers" functionality. The Session Initiation Protocol (SIP) uses DNS procedures to allow a client to resolve a SIP Uniform Resource Identifier (URI) into the IP address, port, and transport protocol of the next hop to contact. It also uses DNS to allow a server to send a response to a backup client if the primary client has failed. This procedure uses the Fully-qualified domain name (FQDN).	Uncheck	Check/Uncheck
<b>Customized Tone Settings</b>			
Default Dial Tone	Defines the tone that will be heard during dialing. The string refers to tone, frequency, and cadence.	350@-19,440@-19;10(*0/1+2)	Set by the operator
Default Callwaiting Tone	Defines the tone that will be heard during call waiting. The string refers to tone, frequency, and cadence.	440@-22;31.2(.3/10.1/1)	
Default MWI Tone	Defines a message-waiting indicator tone. The string refers to tone, frequency, and cadence.	350@-13,440@-13;1.2(.1/.1/1+2);*(0/1+2)	
<b>Known SIP Provider</b>			
Enable WiMAX QoS For known SIP Provider	This check-box enables the CPE to select the quality of service level from a known SIP. This feature is used for MS initial service -flow.	Enabled	Enable/disable
List of SIP providers	Click <b>Insert</b> to add a known SIP provider to the list and specify the SIP Proxy address and Proxy port. To remove from the list, click <b>Del</b> .	N/A	



Table 9-2: VoIP Settings (Continued)

Parameter	Description	Default	Possible Values
<b>Line 1 Settings - Common Settings</b>			
Enable Line 1	To enable voice feature	Disabled	Enable/disable
DTMF Method	<p>Enable the sending of dual-tone multi-frequency (touch tone) phone signals over the VoIP connection:</p> <ul style="list-style-type: none"> <li>■ InBand - The DTMF signals are sent over the RTP voice stream.</li> <li>■ RFC2833 - Relay the DTMF signals over the RTP voice stream without any distortion</li> <li>■ RFC2833+InBand - Uses the best method depending on the called party.</li> <li>■ SIPInfo - Uses the data from SIP</li> </ul>	RFC2833+ InBand	InBand, RFC2833, RFC2833+InBand, SIPInfo
callForward Unconditional	Forwards an incoming call to another number for all calls.	Disabled	Enable/disable
callForward Unconditional Number	Enter the number to which to forward all incoming calls.	N/A	Up to 256 characters
callForward Busy	Forwards an incoming call to another number when the current line is busy.	Disabled	Enable/disable
callForward Busy Number	Enter the number to which to forward incoming calls when the current line is busy.	N/A	
callForward NoReply	Incoming calls are forwarded to another phone number only if there is no answer after a pre-configured timeout.	Disabled	Enable/disable
Call Forwarding No Reply Timeout	The time (in seconds) a call waits for an answer before being forwarded to the number specified in callForward NoReply	30 seconds	N/A
callForward NoReply Number	Enter the number to which to forward incoming calls when there is no reply from current line.	N/A	
Caller ID Block	Select this check-box to hide your name and number when calling another number.	Enable	Enable/disable
Anonymous Call Reject	Select this check-box to block calls from an unidentified number.	Disabled	Enable/disable

Table 9-2: VoIP Settings (Continued)

Parameter	Description	Default	Possible Values
E911	Emergency call: Enter a number that will be referred to as the emergency call. When dialing "911" this call will be routed to the emergency service.	N/A	
Automatic Recall	Return call: Enables calling back the number whose call you missed. Enter a special number (e.g. *42). Dialing this number will recall the number that was missed in last incoming call. Empty field means Automatic Return Call is disabled	N/A	
Redial	Enter a shortcut (e.g. *53) to define redialing to the last number	N/A	
Automatic Call Back	Repeat dial if busy: automatically redial the number time and again. Define a special number (e.g.*52). Dialing this number after the busy tone received, will automatically redial the number until the recipient's line is free. Then your phone will ring back when you are being connected. Empty field means Automatic Return Call is disabled.	N/A	
Inter-digit T/O	Delay in call establishment (timeout in seconds)	5 sec.	
Call Switching	Set a shortcut (e.g. *66) to enable switching from one phone to another without hanging up. Switching is done by pressing the flash button and dialing the shortcut number.	N/A	
DialPlan	Establish the expected number and pattern of digits for a telephone number	N/A	
Flash Timeout	When pressing Flash you have the time interval defined by this value to dial other numbers (e.g. for a conference call). If you do not dial a number within the specified time, you return to the initial call.	15 seconds	Any number
Date Mode	Use date information from the Date header in the SIP message/NTP server	Date Header	Date Header/NTP
Enable Hold Tone	Select whether to play hold tone when put in hold.	Check	Check/Uncheck

Table 9-2: VoIP Settings (Continued)

Parameter	Description	Default	Possible Values
CLIR per-call	Enter a dialing prefix for Calling Line Identification Restriction (CLIR) per call, for example: *45	N/A	Any number
CallHold	Enables holding the line while speaking with one participant in a conversation.	Disabled	Enable/disable
Do Not Disturb(DND)	Select this check-box to reject any incoming calls. The call will result in Busy tone.	Disabled	Enable/disable
<b>Codec Setting</b>			
g711u Codec Enable	The ITU-T G.711 with mu-law standard codec that uses Pulse Code Modulation (PCM) to produce a 64 Kbps high-quality voice data stream. This standard is used in North America and Japan.	Enable	Enable/disable
g711u Priority	The priority of codec by which the unit will attempt to use for best voice quality	Third priority	
g711u ptime	Set the time (in milliseconds) for the unit to attempt to use the codec highest priority in the list before trying the next lower one.	30 ms	
g711a Codec Enable	(G711.aLaw): The ITU-T G.711 with A-law standard codec that uses Pulse Code Modulation (PCM) to produce a 64 Kbps high-quality voice data stream. This standard is used in Europe and most other countries around the world.	Enabled	Enable/disable
g711a Priority	The priority of codec by which the unit will attempt to use for best voice quality	Second priority	
g711a ptime	Set the time (in milliseconds) for the unit to attempt to use the codec highest priority in the list before trying the next lower one.	30 ms	
g729 Codec Enable	The ITU-T G.729ab standard codec that uses Conjugate Structure Algebraic-Code Excited Linear Prediction (CS-ACELP) with silence suppression to produce a low-bandwidth data stream of 8 Kbps. Note that DTMF and fax tones do not transport reliably with this codec, it is better to use G.711 for these signals.	Enabled	Enable/disable

Table 9-2: VoIP Settings (Continued)

Parameter	Description	Default	Possible Values
g729 Priority	The priority of codec by which the unit will attempt to use for best voice quality	First priority	
g729 ptime	Set the time (in milliseconds) for the unit to attempt to use the codec highest priority in the list before trying the next lower one.	30 ms	
<b>DSP Setting (Digital Signal Processing)</b>			
Enable VAD	Voice Activity Detection - detects the periods of silence in the audio stream so that it is not transmitted over the network.	Enabled	Enable/Disable
Enable RTCP	Select this check-box to enable Real-time Transport Control Protocol	Enable	Enable/Disable
EC Length	Echo Cancellation - Sets the delay time (in milliseconds) for voice echo cancellation. A voice echo can be created on some two-wire phone loops, which becomes increasingly louder and annoying when there is a long delay. If voice echo is a problem during a call, you can adjust this parameter to try and reduce or remove it.	32	16, 32, 48
JB Delay Max	Jitter Buffer control: JB delays the arriving packets so that the end user experiences a clear connection with very little sound distortion.  Set the maximum jitter buffer delay time (in milliseconds)	100 ms	
JB DelayInit	The initial delay of the jitter buffer in milliseconds. The system holds the 1st received packet for the time defined in DelayInit before sending it out.	0 ms	
Tx Gain	Enter a value (in db) to control the voice transmission quality	0	-5 to +5
Rx Gain	Enter a value (in db) to control the voice receiving quality	0	-5 to +5



**Table 9-2: VoIP Settings (Continued)**

Parameter	Description	Default	Possible Values
T.38 Enable	Select one of the options to send fax messages over the VoIP network from a fax machine connected to one of the RJ-11 Phone ports on the unit.  T.38 is a standard for sending FAX across IP networks in a real-time mode.	Enable T.38	Enable T.38 Disable T.38 Enable T.38+WA (T.38 with Asterisk)



## 9.4 Service Line

In the Service Line page you set the rules for data traffic. If the Marking check-box is not activated (marking disabled), then you can configure a range of DSCPs (Differentiated Services Code Point) as a rule. For uplink traffic, if the packets have the DSCP in the specified interval of a rule and are coming from the configured port, then a match is found and traffic is forwarded towards WAN. For downlink traffic, if the packets have the DSCP in the specified interval of a rule and the destination is on the configured port then the packets are forwarded towards LAN.

A rule with Marking enabled must have the same value for the start and stop DSCP. For uplink traffic, when a rule with marking enabled is encountered then the traffic is marked with the corresponding DSCP value, regardless of the existing DSCP value. For downlink traffic, packets coming from WAN are forwarded to the configured LAN port only if they have the configured DSCP value. The value of the DSCP field of the first incoming packet from the specified LAN port will be used to mark all the reply packets towards LAN.

For example, if the first coming packet from Ethernet LAN has the DSCP value 3, the second 5 and so on, and the Service Line rule is configured to mark the Ethernet LAN packets with 10 - all the reply packets coming from WAN with the DSCP 10 will be forwarded to LAN with DSCP 3.

Any combination of VLAN ID, VLAN Priority and DSCP Value parameters must be unique over all the configured service lines. Otherwise the service line configuration is rejected. The set of rules are verified one by one until a match is found. If a match is found the other rules are not checked anymore. The default rule permits all the traffic (DSCP value between 0 and 63).

For IP-CS, Bridge-IPCS (IP Conversion Sublayer) and Bridge-ETHCS (Ethernet Conversion Sublayer) service line types are available depending on the function settings defined by the operator (see ["Function Settings"](#) on page 106).



WMX Config VoIP **Service Line** DEV Config DM Settings Function Settings UI Settings

Reserved DSCP

SIP DSCP : 26  
RTCP DSCP : 26  
RTP DSCP : 46  
MGMT DSCP : 6

Service Line Type : ETH-CS

Enable DSCP spoofing  
 Use Default Rule at end of rules

Sel.	No.	Port	VLAN ID		VLAN Priority		Outgoing VLAN ID	Outgoing VLAN Priority	Incoming Multicast Duplication Flag	DSCP	
			Start	Stop	Start	Stop				Marking	Start
<input type="checkbox"/>	1	all	0	4096	0	8	4096	8	<input checked="" type="checkbox"/>	<input type="checkbox"/>	64

Add Del Up Down Undo Apply

Config VoIP **Service Line** DEV Config DM Settings Function Settings UI Settings

Reserved DSCP

SIP DSCP : 26  
RTCP DSCP : 26  
RTP DSCP : 46  
MGMT DSCP : 6

Service Line Type : IP-CS

Enable DSCP spoofing  
 Use Default Rule at end of rules

Sel.	No.	Port	DSCP Value			Incoming Multicast Duplication Flag
			Marking	Start	Stop	
<input type="checkbox"/>	1	all	<input type="checkbox"/>	0	63	<input type="checkbox"/>

Add Del Up Down Undo Apply

Figure 9-4: Engineering - Service Line (ETHCS and IP-CS)

The following information is displayed:

**Reserved DSCP** - When DSCP spoofing is enabled, you cannot configure a rule with a range of DSCPs that contains one of the DSCPs reserved for SIP, RTP/RTCP, or MGMT. For example, if the values for SIP, RTP/RTCP, MGMT are 26/46/6, you cannot configure a rule that contains one of these values (DSCP start

4, DSCP stop 7 or DSCP start 20, DSCP stop 50). Also you cannot configure a rule to mark packets with one of these values. (See also "Function Settings" on page 106).

The following configuration parameters are available:

**Table 9-3: Service Line Parameters**

Parameter	Description
Use Default Rule at end of rules	The default rule permits all the traffic (DSCP value between 0 and 63). If the default rule is enabled and none of the configured rules can be applied to the traffic, the default rule is applied. If the default rule is disabled and none of the rules matches the packets, then the packets are discarded.
Enable DSCP spoofing	<p>When selected, packets containing Management or Voice DSCP value will be handled as follows:</p> <ul style="list-style-type: none"> <li>■ coming from the LAN side - dropped</li> <li>■ coming from the WAN side - routed to internal Management and Voice applications</li> </ul> <p>When not selected, packets containing Management or Voice DSCP value will be handled as follows:</p> <ul style="list-style-type: none"> <li>■ coming from the LAN side - passed through</li> <li>■ coming from the WAN side - routed to internal Management and Voice applications according to the destination IP address and Port range, or forwarded to LAN according to the destination IP.</li> </ul> <p>The default is not selected (DSCP spoofing disabled)</p>
Sel.	Select this check-box to delete this row
No.	Display the number of this rule
Port	Set the port for IP-CS/ETHCS: eth (Ethernet)
VLAN ID	VLAN Identification of the data flow in LAN. Range: 1-4096 (4096 = Untagged)
VLAN Priority	VLAN Priority of the data flow in LAN. Range: 1-8 (8=No priority)
DSCP Value	<ul style="list-style-type: none"> <li>■ Marking - Select this check-box to tag packets in this line for classification. If you select this option, the Start and Stop values should be the same (Start=Stop)</li> <li>■ Start /Stop - When Marking is disabled, enter a range of values, excluding the Internal Management, internal VoIP SIP and RTP DSCP reserved values. If the reserved values are in the range between start and stop, outgoing packets with these values will be dropped. Default: start=0, stop=63. Range: 0-63.</li> </ul>





**Table 9-3: Service Line Parameters (Continued)**

Parameter	Description
Incoming Multicast Duplication Flag	Select this check-box to enable duplication of multicast (VoIP, Data) packets.

- Use the **Add** or **Del** buttons to add a rule to the group or clear it from the group.
- Use the **Up** or **Down** buttons to change the rules priority.
- Click **Apply** to activate your changes.

## 9.5 Device Configuration

In the Dev Config page you save and export all the parameters currently set on the device, packed in a file, to your PC. This file will be used as a configuration template in order to apply the same settings to other CPEs. The format of the exported file is \*.tar, which will have to be converted into an \*.ipk file format using the Auto-configuration tool (see [“Configuring the Unit Using the WiMAX Modem Application CD”](#) on page 26).



Figure 9-5: Engineering - DEV Config.



### To save and export the current device settings:

- 1 Set the device parameters as required in each of the application pages. Be sure to click **Apply** to activate your changes.
- 2 In the Dev Config page click **Export** to save the current settings and export as a \*.tar file.
- 3 Save the file (\*.tar format) for mass CPE configuration (see [“Creating a Default Configuration File”](#) on page 31).



## 9.6 DM (Device Management) Settings

### 9.6.1 TR-069

In the DM Settings page you can set parameters for TR-069. TR-069 is a bidirectional SOAP/HTTP based protocol that provides the communication between CPE and Auto Configuration Servers (ACS). It includes both a safe auto configuration and the control of other CPE management functions within an integrated framework.




Figure 9-6: Engineering - DM Settings (TR-069)

The following table describes the configurable TR-069 parameters:

Table 9-4: DM Settings - TR-069

Parameter	Description	Default	Possible Values
WAN IP	Management IP of the device	N/A	N/A
Connection Status	Displays the CPE connection state	N/A	Connected/ disconnected
ACS URL	Enter the URL of the ACS server	N/A	N/A
ACS UserName	Enter the username for the ACS application	CPEmac@wimax.com	Up to 256 characters



**Table 9-4: DM Settings - TR-069**

Parameter	Description	Default	Possible Values
ACS UserPassword	Enter the password for the ACS application	quickynikyoky	Up to 256 characters
Enable Periodic Inform	Select this check-box to enable the CPE to send periodical information messages to the ACS	Enable	Enable/disable
Periodic Inform Interval	Set the interval (in seconds) for sending messages from CPE to ACS	3600 seconds	Less than defined in ACS
Connection Request User Name	Enter the CPE username for connecting with ACS.	CPEmac@wimax.com	Up to 256 characters
Connection Request Password	Enter the CPE password for connecting with ACS.	quickynikyoky	Up to 256 characters

## 9.6.2 OMA Device Management Parameters

OMA DM is a protocol specified by Open Mobile Alliance (OMA) for Device Management (DM) purposes, by the Device Management Working Group and the Data Synchronization (DS) Working Group.

The WiMax broadband modem can be remotely managed by a remote device management server using the OMA-DM protocol.

WMX Config VoIP Service Line DEV Config **DM Settings** Function Settings

DM switch- OMA

WAN IP

Connection Status dis-connected

Provisioned

Server IP

Server Port 443

Server ID MOTIVEDM-OMA-SERVE

Server Password

Client ID

Client Password

Model ID 4M-CPE4000-Si-2D-2V-W

Enable Client Poll

Enable Server Poll

Poll Interval 1

Poll Attempt 3600

WIB Try 10

WIB Interval 180

Client Initial Session

Boot Strapped

**Figure 9-7: Engineering - DM Settings (OMA)**

The following table describes the configurable OMA parameters:

**Table 9-5: DM Settings - OMA**

Parameter	Description	Default	Possible Values
WAN IP	Management IP of the device	N/A	N/A
Connection Status	Displays the CPE connection state	N/A	Connected/disconnected
Provisioned	Select this check-box to allow checking if the device is activated or not.	Disable	Enable/disable
Debug	Select this check-box to allow debugging of the device.	Disable	Enable/disable
Server IP	IP address of the OMA server		
Server Port	Port number of the OMA server		

Table 9-5: DM Settings - OMA

Parameter	Description	Default	Possible Values
Server ID	The OMA server authentication user name		
Server Password	Authentication password of the OMA server		Up to 128 characters
Client ID	OMA client authentication user name	WiMAXCPE	Up to 128 characters
Client Password	OMA client authentication password	admin	Up to 128 characters
Model ID	The device model ID. OMA DM client uses this ID in communication sessions. The server uses this ID to identify the client.	4M-CPE6000-PRO-1D_1V	
Enable Client Poll	Select this check-box to enable OMA DM client polling mechanism.	Enable	
Enable Server Poll	Select this check-box to enable an initial session between the server and client.	Enable	
Poll Interval	If the client polling mechanism is enabled, the client will follow this interval (in minutes) for polling.	1	
Poll Attempt	Enter the number of attempts for client polling	2	
WIB Try	The number of WIB (Wireless Initial Bootstrap) re-try that the client will try to do.	0	
WIB Interval	The interval (in seconds) between WIB actions.	180	
Network Entry Delay Time		0	



**Table 9-5: DM Settings - OMA**

Parameter	Description	Default	Possible Values
Server Nonce	A string used only once for the first session until the ID and password are set. The server nonce is used in an OMA DM session when a device authenticates the server. For the device to connect to the server, the nonce that is stored in the device must be the same as the nonce that the server has.	1234	
Client Nonce		1234	
Client Initial Session	Click <b>Initial Now</b> to start a contact and send a poll to the server.	N/A	
Boot Strapped	If client already has an OMA DM profile set with the parameters described above, this check-box is checked automatically.	Disable	Enable/Disable



# 9.7 Function Settings

In this page you reserve DSCP (Differentiated Services Code Point) markings for classification settings and set the ISP details.




Figure 9-8: Engineering - Function Settings

The following table describes the configurable Function Setting parameters:

Table 9-6: Function Settings

Parameter	Description	Default	Possible Values
<b>DSCP (Differentiated Services Code Point)</b>			
SIP DSCP	Session Initiation Protocol	26	0-63
RTCP DSCP	Real Time Voice Control Protocol	46	0-63
RTP DSCP	Real Time Voice	46	0-63
MGMT DSCP	Management	6	0-63
<b>ISP (Internet Service Provider)</b>			
ISP Name	Name of the internet service provider	N/A	
ISP URL	URL of the internet service provider	N/A	



## 9.8 UI Settings

This window enables controlling the User Interface of the subscriber. Selecting the features in this window disables the accessibility and availability of features for the end-user.



**Figure 9-9: Engineering - UI Settings**

The following table describes the configurable UI Setting parameters:

**Table 9-7: UI Settings Parameters**

Parameter	Description	Comments
Setup > Basic	<ul style="list-style-type: none"> <li>■ Operation Mode - select this check-box to disable the option to modify the operation mode by the user.</li> <li>■ Wan Mtu - select this check-box to disable the option to modify the WAN Mtu by the user.</li> </ul>	<p>Selecting both options makes the Setup &gt; Basic page unavailable to the subscriber.</p> <p>See also <a href="#">"Setting Basic Parameters" on page 37</a></p>
Setup > Restore To Factory	Restore To Factory - select this check-box to disable the option to restore parameters by the user.	Selecting this option makes the Setup > Restore To Factory page unavailable to the subscriber.

Table 9-7: UI Settings Parameters (Continued)

Parameter	Description	Comments
Advanced > Authentication	Authentication - select this check-box to disable the option to set Authentication parameters by the user.	See also <a href="#">"Setting Advanced Parameters"</a> on page 49
Advanced > Security	Security - select this check-box to disable the option to set Security parameters by the user.	
Advanced > Dynamic DNS	Dynamic DNS - select this check-box to disable the option to set DDNS parameters by the user.	Selecting this option makes the Advanced > Dynamic DNS page unavailable to the subscriber.
Advanced - Firewall	<ul style="list-style-type: none"> <li>■ Firewall - select this check-box to disable the option to set Firewall parameters by the user.</li> <li>■ VPN Passthrough - select this check-box to disable the option to set VPN Passthrough parameters by the user.</li> </ul>	See <a href="#">"Firewall"</a> on page 55
Status - Certificate	Certificate - select this check-box to disable the option to view and set the certificates by the user.	Selecting this option makes the Status > Certificate page unavailable to the subscriber  See <a href="#">"Certificate Status"</a> on page 74
Telephony	Telephony - select this check-box to disable the option to view the telephony parameters by the user.	Selecting this option makes the Telephony menu item unavailable to the subscriber  See <a href="#">"Configuring Telephony Parameters"</a> on page 77

# Glossary



<b>100BASE-TX</b>	IEEE 802.3u specification for 100 Mbps Fast Ethernet over two pairs of Category 5 or better UTP cable.
<b>10BASE-T</b>	IEEE 802.3 specification for 10 Mbps Ethernet over two pairs of Category 3 or better UTP cable
<b>Advanced Encryption Standard (AES)</b>	An strong encryption algorithm that implements symmetric key cryptography.
<b>Access List (ACL)</b>	A list of MAC addresses which are allowed to access the device
<b>Automatic Gain Control (AGC)</b>	Automatic electronic regulation by recording devices of video and audio signals at a predetermined rate (by electronic control).
<b>Authentication</b>	The process to verify the identity of a client requesting network access. IEEE 802.11 specifies two forms of authentication: open system and shared key.
<b>Auto-negotiation</b>	Signalling method allowing each node to select its optimum operational mode (speed and duplex mode) based on the capabilities of the node to which it is connected.
<b>Best Effort (BE)</b>	One of the five QoS service types defined in the IEEE 802.16 WiMAX.
<b>Base Station</b>	A WIMAX service provider's equipment that is installed at a fixed location to provide network connectivity for subscriber stations within a defined service area.
<b>Broadcast Key</b>	Broadcast keys are sent to stations using 802.1X dynamic keying. Dynamic broadcast key rotation is often used to allow the access point to generate a random group key and periodically update all key-management capable wireless clients.
<b>Channel Allocation Priority Level (CAPL)</b>	<p>CAPL scan list is defined by the customer provisioned list. There are some parameters with CAPL scan: NAPID, priority and RefID.</p> <p>NAPID is used to filter some BS if the NAPID is not matched.</p> <p>Priority is the customer defined priority scan order. Higher priority will be scanned first.</p> <p>RefID is a result of mapping from IDs into a scan list from the channel plan.</p>
<b>CINR</b>	Carrier to Interference-plus-Noise Ratio (CINR), expressed in decibels (dBs), is a measurement of signal effectiveness. The carrier is the desired signal, and the interference can either be noise or co-channel interference or both. In order for the signal receiver to be able to decode the signal, the signal must fall into an acceptable CINR range, which differs with the technology used (i.e., CDMA, GSM, etc.).
<b>Clear to Send (CTS)</b>	Signal that gives a modem permission to send data.



**Calling Line Identification Restriction (CLIR)**

Controls the presentation of caller identity (via CLIP-Calling Line Identification Presentation) in GSM networks. If CLIR is enabled, the caller's MSC (Mobile Switching Centre) indicates this restriction to the destination MSC. The identity is then not forwarded to the destination mobile station.

**Customer Premise Equipment (CPE)**

Customer Premise Equipment: Communications equipment that resides on the customer's premises.

**Dynamic Host Configuration Protocol (DHCP)**

A protocol used to assign IP addresses to computers on a Microsoft NT local area network

**Domain Name System (DNS)**

A mechanism used for translating host names for network nodes into IP addresses.

**Dynamic Domain Name System (DDNS)**

A method, protocol, or network service that provides the capability for a networked device to notify a domain name server to change the active DNS configuration of its configured hostnames, addresses or other information stored in DNS, in real-time.

**Dynamic Host Control Protocol (DHCP)**

Dynamic Host Configuration Protocol: Provides a framework for passing configuration information to hosts on a TCP/IP network. DHCP is based on the Bootstrap Protocol (BOOTP), adding the capability of automatic allocation of reusable network addresses and additional configuration options.

**("Demilitarized Zone") DMZ**

A server that acts as "neutral zone" and separates an internal network from a public one (in order to prevent outside access to a company's private data.

**Data/Digital Signal Processor (DSP)**

A system that controls voice quality

**Differentiated Services Code Point (DSCP)**

A field in the header of IP packets for packet classification purposes.

**Dual Tone Multi Frequency (DTMF)**

Allocation of a unique tone to each button on an appliance (made up of two frequencies - high and low) that allows a computer to recognize the tone.

**Extended Real-time POLLING SERVICE (ertPS)**

One of the five QoS service types defined in the IEEE 802.16 WiMAX.

**Ethernet**

A popular local area data communications network, which accepts transmission from computers and terminals.

**Ethernet Conversion Sublayer (ETH CS)**

A mode in which transmitted packets contain an 802.3 header

**Encryption**

Data passing between the SU-A-EZ and clients can use encryption to protect from interception and eavesdropping.

**Extended Service Set (ESS)**

Extended Service Set: More than one wireless cell can be configured with the same Service Set Identifier to allow mobile users can roam between different cells with the Extended Service Set.



**Extensible Authentication Protocol (EAP)**

An authentication protocol used to authenticate network clients. EAP is combined with IEEE 802.1X port authentication and a RADIUS authentication server to provide “mutual authentication” between a client, the access point, and the a RADIUS server

**EAP-Tunneled Transport Layer Security (EAP-TTLS)**

An EAP protocol that extends TLS. (see [“Transport Layer Security \(TLS\)” on page 115](#))

**File Transfer Protocol (FTP)**

File Transfer Protocol: A TCP/IP protocol used for file transfer.

**Fully-qualified Domain Name (FQDN)**

A fully-qualified domain name (FQDN), sometimes referred to as an absolute domain name, is a domain name that specifies its exact location in the tree hierarchy of the Domain Name System (DNS). It specifies all domain levels, including the top-level domain, relative to the root domain. A fully-qualified domain name is distinguished by this absoluteness in the name space.

**Hypertext Transfer Protocol (HTTP)**

Hypertext Transfer Protocol: HTTP is a standard used to transmit and receive all data over the World Wide Web.

**IDENT**

An Internet protocol that helps identify the user of a particular TCP connection.

**IEEE 802.16e**

A standard that provides mobile broadband wireless access using Scalable Orthogonal Frequency Division Multiple Access (SOFDMA).

**Internet Low Bitrate Codec (iLBC)**

A free speech codec suitable for robust voice communication over IP. The codec is designed for narrow band speech and results in a payload bit rate of 13.33 kbit/s with an encoding frame length of 30 ms and 15.20 kbps with an encoding length of 20 ms. The iLBC codec enables graceful speech quality degradation in the case of lost frames, which occurs in connection with lost or delayed IP packets.

**IP Conversion Sublayer (IP-CS)**

A mode in which transmitted packets contain an 802.3 header

**Itsy Package Management System (IPKG, ipkg)**

Itsy Package Management System - a lightweight package management system designed for embedded devices.

**Internet Protocol Security (IPsec)**

A protocol suite for securing Internet Protocol (IP) communications by authenticating and encrypting each IP packet of a data stream.

**Jitter Buffer (JB)**

A shared data area where voice packets can be collected, stored, and sent to the voice processor in evenly spaced intervals. Variations in packet arrival time, called jitter, can occur because of network congestion, timing drift, or route changes. The jitter buffer, which is located at the receiving end of the voice connection, intentionally delays the arriving packets so that the end user experiences a clear connection with very little sound distortion.

**Local Area Network (LAN)**

Local Area Network: A group of interconnected computer and support devices.

**Layer 2 Tunneling Protocol (L2TP)**

A tunneling protocol used to support virtual private networks (VPNs).



<b>Media Access Control (MAC)</b>	Media Access Control: The lower of the two sub-layers of the data link layer defined by the IEEE. The MAC sub-layer handles access to shared media, such as whether token passing or contention will be used.
<b>MAC Address</b>	Standardized data link layer address that is required for every port or device that connects to a LAN. Other devices in the network use these addresses to locate specific ports in the network and to create and update routing tables and data structures. MAC addresses are 6bytes long and are controlled by the IEEE.
<b>Maximum Transmission Unit (MTU)</b>	Largest size of a data packet or frame that can be sent in one complete unit over a packet-based computer network
<b>Multiple Input Multiple Output (MIMO)</b>	Using multiple antennas in a Wi-Fi device to improve performance and throughput.
<b>MSCHAPV2 (MS-CHAP. v2)</b>	Microsoft version of the Challenge-handshake authentication protocol, version 2. MS-CHAPv2 provides mutual authentication between peers by adding a peer challenge upon the Response packet and an authenticator response on the Success packet.
<b>Network Access Point (NAP)</b>	Network exchange point equipped with large-scale switching facilities and serving as a connection point between individual Internet Service Providers
<b>Network Address Translation (NAT)</b>	A system for reusing IP addresses - The process of modifying network address information in datagram packet headers, while in transit, across a router, in order to remap a given address space into another.
<b>Network Time Protocol (NTP)</b>	NTP is a protocol designed to synchronize the clocks of computers over a network. The time servers operate in a hierarchical-master-slave configuration in order to synchronize local clocks within the subnet and to national time standards via wire or radio.
<b>Open Mobile Alliance (OMA)</b>	OMA DM (device Management) is a protocol specified by Open Mobile Alliance (OMA) for Device Management purposes, by the Device Management Working Group and the Data Synchronization (DS) Working Group.
<b>Orthogonal Frequency Division Multiplexing (OFDM)</b>	Orthogonal Frequency Division Multiplexing: OFDM allows multiple users to transmit in an allocated band by dividing the bandwidth into many narrow bandwidth carriers.
<b>Physical Layer Device (PHY)</b>	The term used for a transceiver in Fast Ethernet and Gigabit Ethernet systems.



<b>Plain Old Telephone Service (POTS)</b>	Standard analog telephone service, regular telephone line without extra enhancements
<b>Power Over Ethernet (PoE)</b>	Power over Ethernet: A specification for providing both power and data to low-power network devices using a single Category 5 Ethernet cable. PoE provides greater flexibility in the locating of Wi2s and network devices, and significantly decreased installation costs.
<b>Point to Point Tunneling Protocol (PPTP)</b>	This protocol enables the transfer of data packets of TCP / IP through a foreign network that is not based on these protocols (by marking the packet with an address suited to the foreign network)
<b>Quadrature Phase Shift Keying (QPSK)</b>	A digital modulation scheme that conveys data by changing, or modulating, the phase of a reference signal (the carrier wave).
<b>Request for Comments (RFC)</b>	A memorandum published by the Internet Engineering Task Force (IETF) describing methods, behaviors, research, or innovations applicable to the working of the Internet and Internet-connected systems.
<b>Received signal strength indication (RSSI)</b>	<p>A measurement of the power present in a received radio signal.</p> <p>RSSI is generic radio receiver technology metric, which is usually invisible to the user of device containing the receiver, but is directly known to users of wireless networking of IEEE 802.11 protocol family.</p>
<b>Real-time Transport Protocol (RTP)</b>	The Real-time Transport Protocol (RTP) defines a standardized packet format for delivering audio and video over the Internet.
<b>Real-time Transport Control Protocol (RTCP)</b>	<p>Real-time Transport Control Protocol (RTCP) is a sister protocol of the Real-time Transport Protocol (RTP).</p> <p>RTCP provides out-of-band control information for an RTP flow. It partners RTP in the delivery and packaging of multimedia data, but does not transport any data itself. It is used periodically to transmit control packets to participants in a streaming multimedia session. The primary function of RTCP is to provide feedback on the quality of service being provided by RTP.</p>
<b>RTS Threshold</b>	Transmitters contending for the medium may not be aware of each other. RTS/CTS mechanism can solve this "Hidden Node Problem". If the packet size is smaller than the preset RTS Threshold size, the RTS/CTS mechanism will NOT be enabled.
<b>Service Set Identifier (SSID)</b>	An identifier that is attached to packets sent over the wireless LAN and functions as a password for joining a particular radio cell; i.e., Basic Service Set (BSS).
<b>Session Key</b>	Session keys are unique to each client, and are used to authenticate a client connection, and correlate traffic passing between a specific client and the AU-EZ.





<b>Shared Key</b>	A shared key can be used to authenticate each client attached to a wireless network. Shared Key authentication must be used along with the 802.11 Wireless Equivalent Privacy algorithm.
<b>Session Initiation Protocol (SIP)</b>	An application-layer control (signaling) protocol for creating, modifying, and terminating sessions with one or more participants. It can be used to create two-party, multiparty, or multicast sessions that include Internet telephone calls, multimedia distribution, and multimedia conferences.
<b>Simple Network Management Protocol (SNMP)</b>	Simple Network Management Protocol: The application protocol in the Internet suite of protocols which offers network management services.
<b>Simple Network Time Protocol (SNTP)</b>	SNTP allows a device to set its internal clock based on periodic updates from a Network Time Protocol (NTP) server. Updates can be requested from a specific NTP server, or can be received via broadcasts sent by NTP servers.
<b>Single Input Single Output (SISO)</b>	A form of antenna technology for wireless communications in which a single antenna at both the transmitter and at the destination (receiver) are used.
<b>Subscriber Station</b>	A general term for a customer's WIMAX terminal equipment that provides connectivity with a base station.
<b>Temporal Key Integrity Protocol (TKIP)</b>	Temporal Key Integrity Protocol - a security protocol used in Wi-Fi Protected Access (WPA). Unlike WEP, TKIP provides per-packet key mixing, a message integrity check and a rekeying mechanism. TKIP ensures that every data packet is sent with its own unique encryption key.
<b>TR-069 (Technical Report 069)</b>	A DSL Forum technical specification entitled CPE WAN Management Protocol (CWMP). It defines an application layer protocol for remote management of end-user devices.  It provides the communication between CPE and Auto Configuration Servers (ACS).
<b>Trivial File Transfer Protocol (TFTP)</b>	Trivial File Transfer Protocol: A TCP/IP protocol commonly used for software downloads.
<b>Transport Layer Security (TLS)</b>	A cryptographic protocol that provides security for communications over networks such as the Internet. TLS encrypts the segments of network connections at the Transport Layer end-to-end.
<b>Point to Point Tunneling Protocol (PPTP)</b>	protocol that enables the transfer of data packets of TCP / IP through a foreign network that is not based on these protocols (by marking the packet with an address suited to the foreign network)
<b>Unsolicited Grant Service (UGS)</b>	One of the five QoS service types defined in the IEEE 802.16 WiMAX. It is designed to support real-time service flows that generate fixed-size data packets on a periodic basis, such as T1/E1 and Voice over IP without silence suppression.



<b>User Datagram Protocol (UDP)</b>	Protocol with no connection required between sender and receiver that allows sending of data packets on the Internet (though unreliable because it cannot ensure the packets will arrive undamaged or in the correct order)
<b>Universal Plug and Play Internet Gateway Device (UPnP IGD)</b>	A set of networking protocols promulgated by the UPnP Forum. The goals of UPnP are to allow devices to connect seamlessly and to simplify the implementation of networks in the home and in corporate environments for simplified installation of computer components.
<b>UTP</b>	Unshielded twisted-pair cable.
<b>VoicE Activity Detection (VAD)</b>	Enables the detection of periods of silence in the audio stream so that it is not transmitted over the network.
<b>Wide Area Network (WAN)</b>	Communications network intended to connect between remote local area networks
<b>Wired Equivalent Privacy (WEP)</b>	Wired Equivalent Privacy: WEP is based on the use of security keys and the popular RC4 encryption algorithm. Wireless devices without a valid WEP key will be excluded from network traffic.
<b>Wireless Application Protocol (WAP)</b>	Wireless Application Protocol (WAP) is an open international standard for application-layer network communications in a wireless-communication environment. Most use of WAP involves accessing the mobile web from any mobile device or phone.
<b>Wi-Fi Protected Access (WPA)</b>	Wi-Fi Protected Access (WPA and WPA2) is a certification program developed to indicate compliance with the security protocol to secure wireless computer networks. The WPA protocol implements the majority of the IEEE 802.11i standard. WPA2 implements the mandatory elements of the 802.11i standard.
<b>WiFi Protected Access, Pre-Shared Key (WPA PSK)</b>	<p>WPA (see above) utilizes 128-bit encryption keys and dynamic session keys to ensure the wireless network's privacy and enterprise security.</p> <p>There are two basic forms of WPA:</p> <ul style="list-style-type: none"><li>• WPA Enterprise (requires a Radius server)</li><li>• WPA Personal (also known as WPA-PSK)</li></ul>
<b>Virtual Private Network (VPN)</b>	A private communications network that is based on the public network and uses information security and channeling protocol in order to maintain security of information transferred over the general network.