

SAGEM F@st™ 1704

Reference Manual



Edition of October 2009

253 272 861-A

Sagem Communications SAS (hereafter referred to as Sagem Communications) assiduously monitors technical developments and is constantly seeking to improve its products in order to let its clients take full advantage of them. It therefore reserves the right to modify its documentation accordingly without notice.

All brands mentioned in this guide are registered by their respective owners:

- **SAGEM F@st™** is a registered brand of **Sagem Communications SAS**.
- **Windows™** and **Internet Explorer™** are registered brands of Microsoft Corporation.

The purpose of this reference manual is to give users the functions for operating and managing the equipment. The only access level required (**Administrator**) is protected by a password and allows one to access these functions in read and write mode for all the user and network parameters (Login: admin; password: admin).



Note



Configuration of the router by HTTP is described in detail (cf. section 5).

To ease legibility of the reference manual, the term "router" will be used throughout the document to designate SAGEM F@st™ 1704 equipment.

Guide to symbols used in this manual

Symbols	Definition
 Note	Gives you important information which you must take into account
 Important	Warns you not to do an action, or commit a serious omission.

How should the document be used?

This reference manual is organised into sections and annexes. These sections and annexes cover the following subjects.

Section 1	Presentation of SAGEM F@st™ 1704 equipment
Section 2	Description of SAGEM F@st™ 1704 equipment
Section 3	Installation of SAGEM F@st™ 1704 equipment
Section 4	Configuration of network parameters
Section 5	Configuration of the router by HTTP
Section 6	Description of Internet access service
Section 7	Description of TV over ADSL service
Section 8	Updating the application
Annex A	Troubleshooting
Annex B	CE compliance declaration
Annex C	Environment
Annex D	Technical Characteristics
Annex E	Default configuration
Annex F	Glossary
Annex G	Connection technology

Contents

	Pages
Guide to symbols used in this manual	0-1
How should the document be used?	0-2
Contents	0-3 to 0-6
List of figures	0-7
1. Introduction	1-1
1.1 Presentation	1-2
1.2 Composition of router pack	1-4
1.3 (Minimum) prerequisites	1-5
2. Description and connection of router	2-1
2.1 Description	2-2
2.1.1 Connectors	2-3
2.1.2 LEDs	2-4
2.2 Connecting the ports of your router	2-5
2.3 Installing your SAGEM F@st™ 1704	2-6
2.3.1 Powering up	2-6
2.3.2 Connecting the ADSL cable	2-6
2.3.3 Connecting to your computer	2-8
2.3.3.1 Connecting the Ethernet interface of your router to your computer	2-8
2.3.3.2 Connecting the Wi-Fi interface of your router to your computer	2-9
2.3.4 Connecting the Ethernet interface of your router to your TV decoder	2-10
2.4 Installation safety instructions	2-11
3. Installing and configuring the SAGEM F@st™ 1704 router	3-1
4. Configuration of network parameters	4-1
4.1 Configuring as a DHCP client	4-3
4.2 Status of the DHCP server	4-4
4.3 Data of the DHCP client	4-5
5. Information / Configuration	5-1
5.1 Accessing the welcome screen	5-2

5.2	Recommendations	5-4
5.3	ADSL connection status	5-5
5.4	Display frame	5-5
5.5	Device Info	5-6
5.5.1	Summary	5-6
5.5.2	WAN	5-7
5.5.3	Statistics	5-8
5.5.3.1	LAN	5-8
5.5.3.2	WAN Service	5-9
5.5.3.3	xTM	5-10
5.5.3.4	xDSL	5-11
5.5.4	Route	5-13
5.5.5	ARP	5-14
5.5.6	DHCP	5-15
5.6	Internet Connection	5-16
5.7	Advanced Setup	5-17
5.7.1	Layer2 Interface	5-18
5.7.1.1	Add	5-19
5.7.2	WAN Service	5-21
5.7.2.1	Add	5-22
5.7.2.2	Ethernet over ATM – PPP over Ethernet (PPPoE)	5-23
5.7.2.3	Ethernet over ATM – IP over Ethernet (IPoE)	5-28
5.7.2.4	Ethernet over ATM – Bridging	5-33
5.7.2.5	PPP over ATM (PPPoA)	5-35
5.7.2.6	IP over ATM (IPoA)	5-40
5.7.3	LAN	5-44
5.7.4	IPv6 LAN Config	5-46
5.7.5	NAT	5-47
5.7.5.1	Virtual Servers	5-47
5.7.5.2	Port Triggering	5-50
5.7.5.3	DMZ Host	5-53
5.7.6	Security	5-54
5.7.6.1	IP Filtering	5-54
5.7.7	Parental Control	5-58
5.7.8	Quality of Service	5-60
5.7.8.1	Queue Config	5-62
5.7.8.2	QoS Classification	5-64
5.7.9	Routing	5-68
5.7.9.1	Default Gateway	5-68
5.7.9.2	Static Route	5-69
5.7.9.3	Policy Routing	5-71
5.7.9.4	RIP	5-73
5.7.9.5	IPv6 Static Route	5-74
5.7.10	DNS	5-76
5.7.10.1	DNS Server	5-76
5.7.10.2	Dynamic DNS	5-77
5.7.11	DSL	5-79
5.7.12	Upnp	5-82
5.7.13	DNS Proxy	5-83
5.7.14	Interface Grouping	5-84
5.7.15	LAN Ports	5-87
5.7.16	Certificate	5-88
5.7.16.1	Local	5-88
5.7.16.2	Trusted CA	5-91

5.8	Wireless	5-93
5.8.1	Basic	5-93
5.8.1.1	Wireless – Basic	5-94
5.8.2	Security	5-95
5.8.2.1	Network Authentication	5-97
5.8.3	MAC Filter	5-106
5.8.4	Advanced	5-108
5.8.5	Station Info	5-111
5.9	Diagnostics	5-112
5.10	Management	5-113
5.10.1	Settings	5-113
5.10.1.1	Backup	5-114
5.10.1.2	Update	5-115
5.10.1.3	Restore Default	5-116
5.10.2	System Log	5-117
5.10.2.1	View System Log	5-117
5.10.2.2	Configure System Log	5-118
5.10.3	TR-069 Client	5-120
5.10.4	Internet Time	5-121
5.10.5	Access Control	5-122
5.10.5.1	Passwords	5-122
5.10.6	Update Software	5-123
5.10.7	Reboot	5-124
6.	Internet access service	6-1
7.	TV over ADSL service	7-1
7.1	Introduction	7-2
7.2	Access to the optional TV over ADSL service	7-2
8.	Updating the firmware	8-1
A.	Annex A - Troubleshooting	A-1
A.1	Checking the assignment of an IP address	A-2
A.2	Front panel LEDs	A-3
A.3	Supervising your router	A-4
A.4	Diagnostics tool	A-5
A.5	Interpreting the LEDs	A-7
A.5.1	The "ADSL" LED blinks slowly	A-7
A.5.2	"Wi-Fi" LED off	A-7
A.5.3	All LEDs are off	A-7
A.6	Restarting your router	A-8
A.7	Resetting factory configuration	A-8
A.8	Offline mode	A-9

B. Annex B - Warnings for safety	B-1
B.1 Warnings for safety	B-2
B.1.1 Safety levels in relation to the case	B-2
B.2 EC compliance declaration	B-2
C. Annex C - Environment	C-1
C.1 Directive E 2002/96/CE	C-2
D. Annex D - Technical Characteristics	D-1
D.1 Mechanics; Display	D-2
D.2 Characteristics of the different interfaces	D-3
D.3 Environmental characteristics	D-5
D.4 Application and protocols	D-6
E. Annex E - Default configuration	E-1
E.1 Default username and password	E-2
E.2 Default configuration for the local network(LAN)	E-2
E.3 Default configuration for the local wireless network (WLAN)	E-3
F. Annex F - Glossary	F-1
G. Annex G - Connector Technology	G-1
G.1 Pinouts of the LINE connector	G-2
G.2 Pinouts of the PWR connector	G-2
G.3 Pinouts of the LAN1, LAN2, LAN3 and LAN4 connectors	G-3

List of figures

Figure 1.1 - Supervising your router	1-2
Figure 2.1 - Overview of case.....	2-2
Figure 2.2 - Interconnection of ports of SAGEM F@st™ 1704.....	2-5
Figure 2.3 - ADSL line / Power Supply Connection	2-7

1. Introduction

This section covers	➤ presentation of the SAGEM F@st™ 1704 router	§ 1.1
	➤ composition of the packaging	§ 1.2
	➤ required hardware and software	§ 1.3

1.1 Presentation

This reference manual is dedicated to the SAGEM F@st™ 1704 equipment. This equipment is a router which gives users, broadband Internet access from their computer or their games console by various Ethernet (10 or 100 BASE-T) or Wi-Fi (IEEE 802.11g) interfaces via an ADSL/ADSL2/ ADSL2+ network.

Using these interfaces, this router enables you both to surf the Internet and to watch television. It also lets you telephone over the Internet from an IP SIP telephone linked by Wi-Fi to your router.

Important



SAGEM F@st™ 1704 products adapt the ADSL function respectively for POTS (UIT G.992.1/3/5 - Annex A) and for ISDN (UIT G.992.1/3/5 - Annex B).





Figure 1.1 - Supervising your router

Its principal characteristics and functions are as follows:

- High-performance secure Bridge/Router with ADSL/ADSL2/ADSL2+ interface
- User access:
 - 4 x 10/100BT Ethernet ports,
 - 1 Wi-Fi port (802.11b/g) by mini-PCI,
- DHCP Client/Server/Relay,
- DNS Server/Relay,
- Access control (FTP/TELNET/HTTP/SSH Client),
- NAT/PAT router - FTP Compatibility, IRC, Net2Phone, Netbios, DNS, Netmeeting, VPN passthrough (IPSec, IKE, PPTP, L2TP), CUSeeMe, RealAudio, Microsoft IM and others,
- Security,
- Firewall,
- Spanning tree,
- Multi-VC ATM and ATM Quality of service (CBR, UBR, VBR),
- UpnP,
- TR069,
- QoS,
- Upgrade Firmware (Local and Remote),
- Backup/Restore and Upgrade configuration file (Local and Remote).

1.2 Composition of router pack

The router is supplied in a pack the composition of which changes according to the pack content requested:



Item	Description
1	SAGEM F@st™ 1704 router
2	Mains adapter
3	ADSL RJ11/11 FDT line cable (length = 3 m) used to connect your router to your telephone line
4	Ethernet RJ45/RJ45 cable (length = 1.75 m) used to connect your router to the Ethernet port of your computer
5	Quick Installation Guide
6	Installation CD-ROM
7	Filter/Splitter used to connect one phone set and your router to your telephone line*
8	Microfilter used to connect another phone set to your telephone line*
9	802.11g USB Wi-Fi key*
* Option depending on pack content requested	

The CD-ROM contains:

- the application for installing the USB interface.
- the Reference Manual (SAGEM F@st™ 1704) in PDF format file.
- the CE declaration of the router.

Note



Incomplete or damaged supply.

If on its receipt the equipment is damaged or incomplete, contact your supplier.

1.3 (Minimum) prerequisites

Using a router requires a minimum of:

- a computer equipped with:
 - a Wi-Fi 802.11b/g interface,or
 - an Ethernet interface (10BASE-T or 10/100BASE-T).
- a WEB browser (Internet Explorer version 5 or higher recommended).

The minimum configuration of your computer must be:

- for Windows: Pentium II, 400 MHz, RAM: 128 MB,
- for MacOS: Power PC G3, 233 MHz, RAM: 128 MB,
- a monitor of minimum resolution: 1024 x 768.

If you wish to use the Wi-Fi function (standard IEEE 802.11b/g), you must have the Wi-Fi Standard pack (see annex G for use of Wi-Fi).

Note



Before installing the router, we advise you to uninstall any modem or other router (for example, an ADSL router).

2. Description and connection of router

This section covers	➤ the description of your router	§ 2.1
	➤ connecting the ports of your router	§ 2.2
	➤ installing your router	§ 2.3
	➤ installation safety instructions	§ 2.4

2.1 Description

Figure 2.1 gives an overview of a router SAGEM F@st™ 1704.





Figure 2.1 - Overview of case


This case consists principally of a lid and a base. Inside is a printed circuit equipped with electronic components.

The front face of the lid has eight display LEDs (see § 2.1.2).
The base has the LED ideograms and the manufacturer logo.


Below the base is a label on which the product's identification code, series number and barcode are shown.

2.1.1 Connectors







Marking	Meaning
LINE	RJ11 connector - 6 pts. This connector is identified by the colour grey. It is used for the connection to an ADSL line (WAN interface).
LAN x (1 to 4)	RJ45 connectors - 8 pts (10/100BASE-T Ethernet Interface). These connectors are identified by the colour yellow. They are used to connect to a computer or a television set (via a TV/Video Decoder).
Power	Miniature jack fixed connector. This connector enables the router to be supplied with direct current from a mains adapter unit.
Reset	This button allows the router to be reset to the factory configuration (see § A.7). Note: To prevent an accidental loss of configuration, the router is reset relative to the other elements.
 WLAN/WPS	This button allows the router to switch to easy-pairing mode.

2.1.2 LEDs



The following table describes the meaning of the LEDs on the front panel of the router:

LED	Status	Meaning
 Power	Off	Power Off
	Green	Power On
	Red	Router in rescue mode
 ADSL	Off	ADSL Down
	Green steady	ADSL Up
	Green blinking	ADSL Synchronisation in progress
 Internet	Off	<ul style="list-style-type: none"> • Power Off or <ul style="list-style-type: none"> • The Internet account must be configured
	Green steady	<ul style="list-style-type: none"> • The Internet account is configured or <ul style="list-style-type: none"> • Bridge mode
	Green blinking	Tx/Rx traffic
	Red	Invalid or unauthorised Internet account
LAN x (1 to 4)	Off	No link detected on the Ethernet port
	Green steady	Ethernet port has detected a link with 100 Mbps device
	Green blinking	Tx/Rx traffic at 100 Mbps
 WLAN	Off	Wi-Fi deactivated
	Green steady	Wi-Fi activated
	Green blinking	Wi-Fi Tx/Rx

2.2 Connecting the ports of your router









Figure 2.2 - Interconnection of ports of SAGEM F@st™ 1704

2.3 Installing your SAGEM F@st™ 1704

2.3.1 Powering up

1. First connect the end of the mains adapter lead, supplied with the equipment, to the Power socket on your router.
2. Connect the other end of the mains adapter lead to a nearby power outlet.
3. The router switches on.
4. The  LED will light up first, followed by the four Ethernet LEDs (1 to 4), then these last four LEDs will be off. The  and Ethernet (which corresponds to the connected interface) LEDs should be steady and the  LED blinks during the establishment of the ADSL link, then steadies like the  LED. The  LED should be steady and turn from "Red" to "Green" when a PPP session has been created.

Note



The powering up process lasts around one minute.

2.3.2 Connecting the ADSL cable

1. Connect one end of the RJ11/RJ11 cable supplied with the equipment to the LINE socket of your router.
2. Connect the other end of the cable as shown in the Figure 2.3.

2 - Description and connection of your router




Figure 2.3 - ADSL line / Power Supply Connection


2.3.3 Connecting to your computer

Two connections may need to be made:

- Connection of the Ethernet interface of your router to your computer.
- Connection of the WLAN (Wi-Fi) interface to your computer.

2.3.3.1 Connecting the Ethernet interface of your router to your computer

1. Connect the end of the yellow Ethernet cable (RJ45/RJ45) supplied in the pack to the Ethernet fixed connector (marked **LAN1**, **LAN2**, **LAN3** or **LAN4**) of your router.
2. Connect the other end of the cable to your computer.



2.3.3.2 Connecting the Wi-Fi interface of your router to your computer

Wireless linking enables the router to be connected to your computer.

To make this connection you must have a Wi-Fi pack (option). This pack comprises the following elements:

- 1 Wi-Fi 188470912 key (Dongle) in an anti-static plastic bag,
- 1 CD-ROM.

Inserting a USB Wi-Fi key in your computer

This key should only be **connected** to your computer **during installation** of the Wi-Fi drivers (standard 802.11b/g)(see Quick Installation Guide).


Note



You can also use the Wi-Fi adapter incorporated in your computer.

2.3.4 Connecting the Ethernet interface of your router to your TV decoder

1. Connect the end of the yellow Ethernet cable (RJ45/RJ45) supplied in the pack to the Ethernet fixed connector (marked **LAN1**, **LAN2**, **LAN3** or **LAN4**) of your router.
2. Connect the other end of the cable to a TV decoder.



Note



For connection to the decoder, refer to the manufacturer's documentation.

2.4 Installation safety instructions

Power supply source

- Do not cover the router's mains adapter.
- The router comes with its own mains adapter. Do not use another adapter.
- This class II adapter does not need to be grounded (earthed). The connection to the electrical network should comply with the indications given on the label.
- Use a readily accessible mains outlet located near the router. The power supply cord is 2 m long.
- Arrange the power supply cord in such a way as to avoid any accidental power cut to the router.
- The router is designed to be connected to a GG- (ground-to-ground) or GN- (ground-to-neutral) type power supply network.
- The router is not designed to be connected to an electrical installation with IT type diagram (neutral connected to earth through an impedance).
- Protection against short-circuits and leaks between the phase, neutral and earth should be provided by the building's electrical installation. The power supply circuit for this equipment should be fitted with 16 A overcurrent protection and differential protection.
- Connect the router to the mains via a readily accessible wall socket ensuring the electric cutting.

Location conditions

By choosing an appropriate location, you will preserve the longevity of the device. Ensure that the selected location has the following characteristics:

- Install and use the router inside a building.
- The room temperature must not exceed 45°C.
- The router can be placed on a desktop or fixed vertically in its wall mounting.
- Do not expose the router to strong sunlight or place it near a substantial source of heat.
- Do not place the router in an environment where it could be subjected to considerable steam condensation.
- Do not expose the router to splashes of water.
- Do not cover the router's casing.
- Do not use the router or its peripherals for outdoor transmissions.

Maintenance

- Never open the casing. This must be done only by qualified personnel approved by your supplier.
- Do not use liquid or aerosol cleaning agents.

3. Installing and configuring the SAGEM F@st™ 1704 router

**For the installation of the SAGEM F@st™ 1704,
please refer to the Quick Installation Guide of this product.**

4. Configuration of network parameters


This section covers	➤ configuring as a DHCP client	Page 4-3
	➤ reading status of the DHCP server	Page 4-4
	➤ reading data of the DHCP client	Page 4-5

4 - Configuration of network parameters

The aim of this section is:

1. to configure your computer so that it is able to communicate with your router.
2. to display the "Networks" parameters of your router.

Your router implements the DHCP (**D**ynamic **H**ost **C**onfiguration **P**rotocol) server, relay and client functions in accordance with RFC 2131 and RFC 3132, whereas the computer connected directly to the router or via a local network by its LAN interface implements only the DHCP client function.

On receipt of a DHCP query from your computer (see ) , whether or not it is connected to your router, the latter responds by indicating:

- an address from the range defined in the configuration,
- the sub-network mask,
- the default gateway (address of your router),
- the address of the gateway as DNS server. The "DNS Relay" function is activated automatically.

Note



The configured range of IP addresses must be the same in the sub-network as in the LAN interface.

Important




It is imperative that your computer is configured as a DHCP client or that it has a fixed IP address in the configuration range defined by the DHCP server.

Configuration as a DHCP client is the more commonly used solution.

4.1 Configuring as a DHCP client

In Windows XP

1. Click on **Start > Control Panel > Network Connections**.
2. Right-click the appropriate network, and then select **Properties**.
The Local Area Connection Properties appears.
3. Select the protocol TCP/IP of the network card, and then click the **Properties** button.
The screen Internet Protocol (TCP/IP) Properties appears.
4. Select the **General** tab, then the case "**Obtain an IP address automatically**" and the case "**Obtain the addresses of the DNS servers automatically**".
5. Click the **OK** button to confirm your choice.



4.2 Status of the DHCP server

To obtain the status of the DHCP server:


1. Open your browser.
2. Enter the router's IP address (by default **http://192.168.1.1**) or enter the following URL <http://myrouter>
3. In the login screen that appears, enter "**admin**" in the "User Name" field and "**admin**" in the "Password" field (see note).

Note



The User name and Password values depend on the level of security. This information is provided by your Internet Service Provider (ISP).

4. Click on the **OK** button to validate.
5. Select **Advanced Setup** menu, then select the **LAN** menu. The following screen appears:



Field	Description	Display
IP Address	Displays the sub-network address	192.168.1.1
Subnet Mask	Displays the sub-network mask of the IP network.	255.255.255.0
Start IP Address	Displays the first address attributed by the DHCP server. Note : This IP address must belong to the same sub-network as that of the local network.	192.168.1.2
End IP Address	Displays the last address attributed by the DHCP server. Note : This IP address must belong to the same sub-network as that of the local network.	192.168.1.254
Leased Time (hour)	Displays the period (in hours) for obtaining an IP address for a terminal.	24

4.3 Data of the DHCP client

To obtain this data:

In Windows XP, 2000 and Me

1. Click on **Start > Run**, enter **cmd** and then click **OK**.
The command prompt screen appears.
2. Enter **ipconfig /all** (or **ipconfig/all**) then press **Enter**.

```

Microsoft Windows XP [Version 5.1.2600]
(C) Copyright 1985-2001 Microsoft Corp.

C:\Documents and Settings\Documentation>ipconfig /all

Windows IP Configuration

    Host Name . . . . . : UZY-P1198532
    Primary Dns Suffix . . . . . : sagem.ads.sagem
    Node Type . . . . . : Hybrid
    IP Routing Enabled. . . . . : No
    WINS Proxy Enabled. . . . . : No
    DNS Suffix Search List. . . . . : sagem.ads.sagem
                                        home
                                        ads.sagem

Ethernet adapter Local Area Connection 9:

    Connection-specific DNS Suffix . : home
    Description . . . . . : 3Com EtherLink XL 10/100 PCI TX NIC
    (3C905B-1X)
    Physical Address. . . . . : 00-50-DA-0C-C0-FA
    Dhcp Enabled. . . . . : Yes
    Autoconfiguration Enabled . . . . : Yes
    IP Address. . . . . : 192.168.1.2
    Subnet Mask . . . . . : 255.255.255.0
    Default Gateway . . . . . : 192.168.1.1
    DHCP Server . . . . . : 192.168.1.1
    DNS Servers . . . . . : 192.168.1.1
    Lease Obtained. . . . . : 17 March 2008 11:28:19
    Lease Expires . . . . . : 18 March 2008 11:28:19

C:\Documents and Settings\Documentation>

```


5. Information / Configuration

This section covers	➤ Accessing the welcome screen	§ 5.1
	➤ Recommendations for using the configuration screens	§ 5.2
	➤ The ADSL connection status	§ 5.3
	➤ Indications displayed on the display frame located in the HTTP configurer window	§ 5.4
	➤ The " Device Info " section	§ 5.5
	➤ The " Internet Connection " section	§ 5.6
	➤ The " Advanced Setup " section	§ 5.7
	➤ The " Wireless " section	§ 5.8
	➤ The " Diagnostics " section	§ 5.9
	➤ The " Management " section	§ 5.10

5.1 Accessing the welcome screen

Note



To access this screen, you must have configured one of your computer's interfaces using the installation CD-ROM provided with your router (see section 3).

If you are using your computer's Ethernet card to configure your router, connect it to an Ethernet port (**LAN1** to **LAN4**).


Your router is then configured using a simple Web browser (e.g. Internet Explorer).

Note



The router's DHCP server function is activated by default with an address range defined as indicated in subsection.5.7.3.

To access the configurator, proceed as follows:

1. Click on **Start > All Programs > SAGEM F@st 1704 >** 
2. In the login screen that appears, enter your identification information.
By default, the identification information is:

Username: admin

Password: admin



Note



The equipment's IP address (192.168.1.1) appears in the header bar.

3. Click on **OK** to validate.

4. Your computer's Web browser opens and displays the welcome screen of the router's HTTP configuration tool.
The configuration menus appear on the left panel.

The screenshot shows the SAGEM router's configuration interface. At the top right, there is a status box for ADSL and Internet connections. The ADSL status shows 'Down 19999 kbps' and 'Up 1052 kbps', with 'refresh' and 'reboot' buttons. The Internet status shows 'Connected'. On the left, a navigation menu lists options like 'Device Info', 'Summary', 'WAN', 'Statistics', 'Route', 'ARP', 'DHCP', 'Internet Connection', 'Advanced Setup', 'Wireless', 'Diagnostics', and 'Management'. The main area displays 'Device Info' with a table of hardware and software details, and a table for DSL connection statistics.

Board ID:	F@ST1704
HardWare Version:	253259678 PCBA FAST1704 V0.1
Serial Number:	002 0909011242
Mac Address:	00:25:69:ef:e3:be
Software Version:	4.08a4GL
Bootloader (CFE) Version:	1.0.37-102.6
Wireless Driver Version:	5.10.85.0.cpe4.402.8

This information reflects the current status of your DSL connection.

Line Rate - Upstream (Kbps):	
Line Rate - Downstream (Kbps):	
LAN IPv4 Address:	192.168.1.1
WAN IPv4 Address:	
Default Gateway:	
Primary DNS Server:	
Secondary DNS Server:	
LAN IPv6 Address:	
Default IPv6 Gateway:	
Date/Time:	Sat Jan 1 00:10:25 2000

The HTTP configuration tool opens by default on the **Device Info** menu:

- the centre panel shows router's information and the current ADSL connection status (see subsection 5.3).
- the router's activity and status is always available at the top right corner, as a box which lets you know the status of the ADSL line, lets you refresh the data displayed and restart your router at any time (see subsection 5.4).
- the left, panel gives you access to the router's configuration menus and submenus (see subsection 5.5 to 5.9).










Important



You can modify the password to access your router's configuration tool to optimise the safety of your network.

5.2 Recommendations

The meaning of the main buttons most commonly present in all the configuration windows is provided in the table below.

Button	Description
	Click on this button to add a new window to fill in the fields used to add an object.
	Click on this button to return to the previous screen.
	Click on this button to close the active window and return to the main screen.
	Click on this button to display a new window to modify the fields that can be accessed for a previously selected object.
	Click on this button to display the next screen.
	Click on this button to remove a selected object from a list. Note: You must check the "Remove" box to delete this object.
	Click on this button to save the entry in the router's non-volatile (flash) memory. Note: This value will only be taken into account when you restart your router.
	Click on this button to save the entry in the router's non-volatile (flash) memory. Note: This value will be taken into account immediately without you having to restart your router.
	Click on this button to save the entry in the router's non-volatile (flash) memory then restart your computer.

Basic principles

1. To make this guide easier to read and understand, it does not state that each time you enter information into a screen you must click on **Save** or **Save/Apply** or **Save/Reboot** (except, of course, if this is necessary).
2. When you select a section, the screen for the first menu in the section is displayed. In the same way, when you select a menu, the screen for the first sub-menu is displayed.
3. All the fields in the different screens are explained in a table.

5.3 ADSL connection status

Refer to subsection 5.5.1 – Device Info/Summary.

5.4 Display frame

The router's activity status is always visible at the top right corner of the HTTP configuration tool.



You can perform the following actions:

- click on **Refresh** to update the data displayed
- click on **Reboot** to restart your router

ADSL information

The following table presents the possible states of the **ADSL** field:

Status	Meaning
Green	ADSL line synchronised
Yellow	ADSL line synchronising
Red	ADSL line not connected

The **Down** field displays the nominal downlink bit rate.

The **Up** field displays the nominal uplink bit rate.

Internet information

The following table presents the possible states of the **Internet** field:

Status	Status	Meaning
Off	ADSL Down	ADSL line not connected or not activated
	Not configured	The Internet account must be configured
	Router rebooting	Router is rebooting
Green	Connected	The Internet account is configured
Yellow	Waiting for ISP	ADSL line synchronising
Red	Access denied	Incorrect Internet account

5.5 Device Info

Clicking on this heading displays the following menus:

- Summary (see subsection 5.5.1)
- WAN (see subsection 5.5.2)
- Statistics (see subsection 5.5.3)
- Route (see subsection 5.5.4)
- ARP (see subsection 5.5.5)
- DHCP (see subsection 5.5.6)

5.5.1 Summary

Object: This menu lets you display the current status of your Internet connection.

- In the **Device Info** menu, select **Summary**.
The following screen opens:

The screenshot shows the SAGEM F@st 1704 web interface. At the top right, there are status indicators for ADSL and Internet, both with green lights and labeled 'Connected'. The ADSL status shows 'Down 19999 kbps' and 'Up 1052 kbps', with 'refresh' and 'reboot' buttons. The main content area is titled 'Device Info' and contains a table with the following data:

Board ID:	F@st1704
HardWare Version:	253259678 PCBA FAST1704 V0.1
Serial Number:	002 0909011242
Mac Address:	00:25:69:efe3:be
Software Version:	4.08a4GL
Bootloader (CFE) Version:	1.0.37-102.6
Wireless Driver Version:	5.10.85.0.cpe4.402.8

Below this table, a note states: 'This information reflects the current status of your DSL connection.' Another table follows with network-related information:

Line Rate - Upstream (Kbps):	
Line Rate - Downstream (Kbps):	
LAN IPv4 Address:	192.168.1.1
WAN IPv4 Address:	
Default Gateway:	
Primary DNS Server:	
Secondary DNS Server:	
LAN IPv6 Address:	
Default IPv6 Gateway:	
Date/Time:	Sat Jan 1 00:10:25 2000

The interface includes a left-hand navigation menu with options like 'Device Info', 'Summary', 'WAN', 'Statistics', 'Route', 'ARP', 'DHCP', 'Internet Connection', 'Advanced Setup', 'Wireless', 'Diagnostics', and 'Management'. The SAGEM logo is visible in the top left and bottom left corners. A small image of the device is shown in the bottom right corner. A copyright notice at the bottom reads: '© 2005-2009 SAGEM Corporation. All rights reserved.'

Note



This screen also appears in the welcome screen (see subsection 5.1).

The following table provides the meaning of the different fields which are displayed.

Field	Meaning
Software Version	Software version currently installed.
Line Rate - Upstream (kbps)	Nominal up line rate
Line Rate - Downstream (kbps)	Nominal down line rate
LAN IPv4 Address	Local network IPv4 address (LAN)
WAN IPv4 Address	Remote network IPv4 address (WAN)
Default Gateway	Default gateway address
Primary DNS Server	Primary DNS server address
Secondary DNS Server	Secondary DNS server address
LAN IPv6 Address	Local network IPv6 address (LAN)
Default IPv6 Gateway	Default IPv6 gateway address
Date / Time	Date and Time (see Note)

Note



The **Date/Time** field only appears if the **"Automatically synchronize with Internet time servers"** box is checked in the **"Management / Internet Time"** menu (see subsection 5.10.4).

5.5.2 WAN

Object: This menu is used to display all the parameters which concern the remote network.

- In the **Device Info** menu, select **WAN**.
The following screen opens:

WAN Info

Interface	Description	Type	VlanMuxId	IPv6	Igmp	MLD	NAT	Firewall	Status	IPv4 Address
ppp0a0	ppp0a_0_8_35	PPPoA	Disabled	Disabled	Disabled	Disabled	Enabled	Enabled	Disconnected	

5.5.3 Statistics

Object: This menu is used to display all the router's statistics.

This menu contains the following four sub menus:

- LAN (see subsection 5.5.3.1),
- WAN Service (see subsection 5.5.3.2),
- xTM (see subsection 5.5.3.3),
- xDSL (see subsection 5.5.3.4).

5.5.3.1 LAN

Object: This menu is used to display all the parameters which concern the local network (LAN).

- In the **Device Info** menu, select **Statistics** then select **LAN**.
The following screen opens:

Statistics -- LAN

Interface	Received				Transmitted			
	Bytes	Pkts	Errs	Drops	Bytes	Pkts	Errs	Drops
eth0	537456	3487	0	0	1586832	3822	0	0
wl0	1748	20	0	0	8189	75	178	0

Reset Statistics

© 2005-2009 SAGEM Corporation. All rights reserved.

- Click on the **Reset Statistics** button to reset statistics.

5.5.3.2 WAN Service

Object: This menu is used to display all the parameters which concern the remote network (WAN).

- In the **Device Info** menu, select **Statistics** then select **WAN Service**. The following screen opens:

The screenshot shows the SAGEM web interface. At the top right, there is a status bar with indicators for ADSL and Internet, and network statistics: Down 19999 kbps, Up 1052 kbps, and a 'Connected.' status. A 'refresh' and 'reboot' button are also present. The main content area is titled 'Statistics -- WAN' and contains a table with the following data:

Interface	Description	Received				Transmitted			
		Bytes	Pkts	Errs	Drops	Bytes	Pkts	Errs	Drops
ppp0a0	ppp0a_0_8_35	0	0	0	0	0	0	0	0


Below the table is a 'Reset Statistics' button. The left navigation menu includes: Device Info, Summary, WAN, Statistics, LAN, WAN Service (highlighted), xTM, xDSL, Route, ARP, DHCP, Internet Connection, Advanced Setup, Wireless, Diagnostics, and Management. The SAGEM logo is visible in the bottom left corner, and a small image of a SAGEM device is in the bottom right corner. The footer contains the copyright notice: © 2005-2008 SAGEM Corporation. All rights reserved.

- Click on the **Reset Statistics** button to reset statistics.

5.5.3.3 xTM

Object: This menu is used to display all the xTM statistics of the line.

- In the **Device Info** menu, select **Statistics** then select **xTM**.
The following screen opens:



The screenshot shows the SAGEM web interface. At the top right, there are status indicators for ADSL (Down) and Internet (Connected). The ADSL status shows a speed of 19999 kbps down and 1052 kbps up, with 'refresh' and 'reboot' buttons. The Internet status shows 'Connected'. On the left, a navigation menu lists various options, with 'xTM' selected. The main content area is titled 'Interface Statistics' and contains a table with the following data:

Port Number	In Octets	Out Octets	In Packets	Out Packets	In OAM Cells	Out OAM Cells	In ASM Cells	Out ASM Cells	In Packet Errors	In Cell Errors
1	0	0	0	0	0	0	0	0	0	0

Below the table is a 'Reset' button. At the bottom right of the interface, there is a small image of a SAGEM device. The footer contains the SAGEM logo and the copyright notice: © 2005-2009 SAGEM Corporation. All rights reserved.

- Click on the **Reset** button to reset statistics.

5.5.3.4 xDSL

Object: This menu is used to display all the xDSL statistics of the line.

- In the **Device Info** menu, select **Statistics** then select **xDSL**.
The following screen opens:

The screenshot shows the SAGEM web interface for xDSL statistics. The status bar at the top right indicates 'ADSL' is 'Down' (19999 kbps) and 'Internet' is 'Up' (1052 kbps, Connected). The main content area displays the following statistics:

Statistics -- xDSL		
Mode:	ADSL_2plus	
Traffic Type:	ATM	
Status:	Up	
Link Power State:	LO	
	Downstream	Upstream
Line Coding(Trellis):	On	On
SNR Margin (0.1 dB):	122	170
Attenuation (0.1 dB):	80	22
Output Power (0.1 dBm):	0	126
Attainable Rate (Kbps):	24120	1228
	Path 0	
	Downstream	Upstream
Rate (Kbps):	18469	950
MSGC (# of bytes in overhead channel message):	58	12
B (# of bytes in Mux Data Frame):	44	58
M (# of Mux Data Frames in FEC Data Frame):	1	4
I (#Mux Data Frames over sync bytes):	13	2
R (# of check bytes in FEC Data Frame):	10	16
S (ratio of FEC over PMD Data Frame length):	0.778	7.8750
L (# of bits in PMD Data Frame):	5653	256
D (interleaver depth):	288	8
Delay (msec):	5.60	15.75
INP (DMT symbol):	2.3	2.0
Super Frames:	40393	36871
Super Frame Errors:	0	0
R5 Words:	33607092	331228
R5 Correctable Errors:	0	0
R5 Uncorrectable Errors:	0	0
HEC Errors:	4294967278	0
QCD Errors:	0	0
LCD Errors:	0	0
Total Cells:	29163855	1452562
Data Cells:	23	0
Bit Errors:	0	0
Total ES:	0	0
Total SES:	0	0
Total UAS:	15	4294967269

At the bottom of the statistics table, there are two buttons: 'xDSL BER Test' and 'Reset Statistics'.

- Click on the **Reset Statistics** button to reset statistics.

5 - Information / Configuration

- Click on the **xDSL BER Test** button to display the following screen:




- In the **Tested Time (sec)** field, select the test time from the scroll down list.
- Click on the **Start** button to run the test.
- Click on the **Close** button to close the window and return to the previous screen.

5.5.4 Route

Object: This menu is used to display all the information concerning your router's routing.

- In the **Device Info** menu, select **Route**.
The following screen opens:



The screenshot shows the SAGEM router's web interface. At the top right, there are status indicators for ADSL (Down 19999 kbps, Up 1052 kbps) and Internet (Connected). The main content area is titled "Device Info -- Route" and includes a legend for flags: U - up, I - reject, G - gateway, H - host, R - reinstate, D - dynamic (redirect), M - modified (redirect). Below the legend is a table with the following data:

Destination	Gateway	Subnet Mask	Flag	Metric	Service	Interface
192.168.1.0	0.0.0.0	255.255.255.0	U	0		br0

The left sidebar contains the following navigation options: Device Info, Summary, WAN, Statistics, Route (highlighted), ARP, DHCP, Internet Connection, Advanced Setup, Wireless, Diagnostics, and Management. The SAGEM logo is visible in the bottom left corner, and a small image of the router is in the bottom right corner. The footer contains the text: © 2005-2009 SAGEM Corporation. All rights reserved.

5.5.5 ARP

Object: This menu is used to display all the information concerning address resolution (ARP: **A**ddress **R**esolution **P**rotocol). This lets you find out the physical address of a computer's network card, corresponding to an IP address.

- In the **Device Info** menu, select **ARP**.
The following screen opens:

The screenshot shows the SAGEM web management interface. At the top right, there are status indicators for ADSL (Down 19999 kbps, Up 1052 kbps) and Internet (Connected). A navigation menu on the left includes options like Device Info, WAN, Statistics, Route, ARP (highlighted), DHCP, Internet Connection, Advanced Setup, Wireless, Diagnostics, and Management. The main content area is titled 'Device Info -- ARP' and contains a table with the following data:


IP address	Flags	HW Address	Device
192.168.1.2	Complete	00:24:7E:6A:25:95	br0
192.168.1.3	Complete	00:23:7A:D9:E1:4E	br0

At the bottom right of the interface, there is a small image of a white SAGEM router. The footer contains the SAGEM logo and the copyright notice: © 2005-2009 SAGEM Corporation. All rights reserved.

5.5.6 DHCP

Object: This menu is used to display all the computers which obtained an IP address from the router's DHCP server.

- In the **Device Info** menu, select **DHCP**.
The following screen opens:



The screenshot displays the SAGEM router's web interface. At the top right, there is a status bar showing ADSL and Internet connection status. The ADSL status is 'Down' with a speed of 19999 kbps, and the Internet status is 'Connected' with a speed of 1052 kbps. There are 'refresh' and 'reboot' buttons next to the status information. The main content area is titled 'Device Info -- DHCP Leases' and contains a table with the following data:


Hostname	MAC Address	IP Address	Expires In
RMM-P1267001	00:24:7e:6a:25:95	192.168.1.2	23 hours, 47 minutes, 28 seconds
BLACKBERRY-45A1	00:23:7a:d9:e1:4e	192.168.1.3	23 hours, 49 minutes, 5 seconds

The left sidebar contains a navigation menu with the following items: Device Info, Summary, WAN, Statistics, Route, ARP, DHCP (highlighted), Internet Connection, Advanced Setup, Wireless, Diagnostics, and Management. The SAGEM logo is visible in the bottom left corner, and a small image of the router is in the bottom right corner. The footer contains the copyright information: © 2005-2009 SAGEM Corporation. All rights reserved.

5.6 Internet Connection

Object: This menu lets you enter your connection ID and your connection password.

- Select the **Internet Connection** menu.
The following screen opens:



Field	Action	Default value
PPP Username	Enter your connection ID. This information is provided to you by your Internet Service Provider (ISP) .	-
PPP Password	Enter your connection password. This information is provided to you by your Internet Service Provider (ISP) .	-

Important



If the message "**There is no ppp connection**" appears, this means that the remote network (WAN) parameters have not been filled in (see subsection 5.7.2 - **Advanced Setup > WAN Service**).

Disconnect

When you click on the button **Disconnect**:

- **Internet access is no longer possible.**
- In the supervision box, the "**Internet**" indicator switches from green to **yellow** and the message "Connected" is replaced by "**Waiting for ISP**".
- On the front panel of the router, the indicator **@ goes out**.

5.7 Advanced Setup

Object: This menu is used to configure the specific parameters for your router.

Important



This menu must only be used by experienced users

This section contains the following nine menus:

- Layer2 Interface (see subsection 5.7.1)
- WAN Service (see subsection 5.7.2)
- LAN (see subsection 5.7.3)
- IPv6 LAN Config (see subsection 5.7.4)
- NAT (see subsection 5.7.5)
- Security (see subsection 5.7.6)
- Parental Control (see subsection 5.7.7)
- Quality of Service (see subsection 5.7.8)(see note)
- Routing (see subsection 5.7.9)
- DNS (see subsection 5.7.10)
- DSL (see subsection 5.7.11)
- Upnp (see subsection 5.7.12)
- DNS Proxy (see subsection 5.7.13)
- Interface Grouping (see subsection 5.7.14)
- LAN ports (see subsection 5.7.15)
- Certificate (see subsection 5.7.16)

Note




The menu **Quality of Service** only appears if you checked the "Enable Quality Of Service" box in the WAN interface configuration screen (see **Advanced Setup>WAN Service** – subsection 5.7.2>Add).

5.7.1 Layer2 Interface

Object: This menu is used to configure DSL ATM interfaces.


- In the **Advanced Setup** menu, select **Layer2 Interface**.
The following screen opens:



Field	Meaning
Interface	Name of the DSL ATM interface, allocated automatically.
VPI	Value of the VPI.
VCI	Value of the VCI.
DSL Latency	DSL Latency.
Category	Type of service adapter to the traffic.
Connection Mode	Connection mode (Default mode, VLAN MUX Mode or MSC Mode).
Qos	Status (Enabled or Disabled) of the Quality of Service function.

5.7.1.1 Add

- Click on the **Add** button to display the following screen:



ATM PVC Configuration

Field	Action	Default value
VPI	Enter a VPI value ¹ between 0 and 255.	0
VCI	Enter a VPI value ¹ between 32 and 65535.	35
Select DSL Link Type	Select the type of network protocol from the scroll down list: EoA : E thernet o ver A TM PPPoA : P PP o ver A TM IPoA : I P o ver A TM Note: EoA is for PPPoE, IPoE and Bridge.	EoA
Encapsulation mode	Select the encapsulation mode for the selected DSL link type. To provide more clarity, a summary table is presented below for each type of protocol.	LLC/SNAP - BRIDGING
Service Category	Select the type of service adapter to the traffic from the scroll down list: UBR without PCR : U nspecified B it R ate UBR with PCR : U nspecified B it R ate CBR : C onstant B it R ate Non Realtime VBR : V ariable B it R ate Realtime VBR : V ariable B it R ate	UBR without PCR

¹ This value is delivered to you by your Internet Service Provider (ISP).

5 - Information / Configuration

Field	Action	Default value
Peak Cell Rate²	Enter a maximum number of cells transmitted per second, between 1 and 2491.	-
Sustainable Cell Rate³	Enter an average number of cells transmitted per second. Note: This number must be lower than the Peak Cell Rate (PCR) .	-
Maximum Burst Size³	Enter the maximum number of cells emitted in burst (value between 1 and 1000 000).	-

Encapsulation modes

DSL Link type	Action	Default value
EoA (Ethernet over ATM)	Select the encapsulation of your choice from the scroll down list. <ul style="list-style-type: none"> • LLC/SNAP-BRIDGING, • VC/MUX. 	LLC/SNAP-BRIDGING
PPPoA (PPP over ATM)	Select the encapsulation of your choice from the scroll down list. <ul style="list-style-type: none"> • VC/MUX, • LLC/ENCAPSULATION. 	VC/MUX
IPoA (IP over ATM)	Select the encapsulation of your choice from the scroll down list. <ul style="list-style-type: none"> • LLC/SNAP-ROUTING, • VC/MUX. 	LLC/SNAP-ROUTING

Select Connection Mode

The Connection Mode selection only appears if you have selected the EoA DSL link type.

Field	Action	Default value
Default mode	Check this box to configure a single service over one connection.	Checked
VLAN MUX Mode	Check this box to configure Multiple Vlan service over one connection.	Not checked
MSC Mode	Check this box to configure Multiple Service over one connection.	Not checked

Enable Quality Of Service

Field	Action	Default value
Enable Quality Of Service	Check the box to activate the quality of service.	Not checked

² This field only appears when the "UBR with PCR", "CBR", "Non Realtime VBR" or "Realtime VBR" type of service is selected.

³ These fields only appear when the "Non Realtime VBR" or "Realtime VBR" type of service is selected.

5.7.2 WAN Service

Object: This menu is associated with the remote network. It is used to display the list of all the configured PVCs, and to add PVCs or remove them.

- In the **Advanced Setup** menu, select **WAN Service**.
The following screen opens:

The screenshot displays the 'Wide Area Network (WAN) Service Setup' page. At the top right, there are status indicators for ADSL (Down 19999 kbps, Up 1052 kbps) and Internet (Connected). The main content area contains a table with the following data:

Interface	Description	Type	Vlan8021p	VlanMuxId	ConnId	Igmp	NAT	Firewall	IPv6	MLD	Remove
ppp0a0	ppp0a_0_8_35	PPPoA	N/A	N/A	N/A	Disabled	Enabled	Enabled	Disabled	Disabled	<input type="checkbox"/>

Below the table are 'Add' and 'Remove' buttons. The left sidebar contains a navigation menu with options like 'Device Info', 'Internet Connection', 'Advanced Setup', 'Layer2 Interface', 'ATM Interface', 'WAN Service', 'LAN', 'IPv6 LAN Config', 'NAT', 'Security', 'Parental Control', 'Quality of Service', 'Routing', 'DNS', 'DSL', 'Uppnp', 'Dns Proxy', 'Interface Grouping', 'LAN Ports', 'Certificate', 'Wireless', 'Diagnostics', and 'Management'. The SAGEM logo is visible at the bottom left and right of the interface.

Field	Meaning
Interface	Name, allocated automatically, associated with the service name (for example, ATM interface "ppp_0_35_1" associated with the ATM service pppoe_0_35_1).
Description	Name of the ATM service. This name is made up as follows: Protocol_VPI_VCI_Index For example: pppoe_0_35_1.
Type	Data flow encapsulation mode.
Vlan8021p⁴	Value of the 802.1P Priority.
VlanMuxId⁴	Value of the 802.1Q VLAN ID.
ConnID	Connection Identification. This is used to identify the different PPP connections which belong to the same PVC. To do so, you need only increment the "VC number" in the "Service" field when adding a new "PVC".
IGMP	Status (Enabled or Disabled) of the IGMP function. (see Note).
NAT	Status (Enabled or Disabled) of the NAT.
Firewall	Status (Enabled or Disabled) of the Firewall.
IPv6	Status (Enabled or Disabled) of the IPv6.
MLD	Status (Enabled or Disabled) of the MLD.

Note



This function enables the distribution of Multicast datagrams over the local network (LAN) and interaction between the router and the local network hosts.

⁴ These values only appear if the WAN service is configured over a DSL ATM interface using VLAN MUX Mode.

5.7.2.1 Add

Note



You must have configured a DSL ATM interface (see section 5.7.1) to add a WAN service.

- Click on the **Add** button.

Interface	Description	Type	Vlan8021p	VlanMuxId	ConnId	Igmp	NAT	Firewall	IPv6	MLD	Remove
ppp0a0	ppp0a_0_8_35	PPPoA	N/A	N/A	N/A	Disabled	Enabled	Enabled	Disabled	Disabled	<input type="checkbox"/>

- Select the DSL ATM interface for the WAN service.

- Click on the **Next** button to continue configuring the WAN service.

Note



Depending on the type of network protocol configured for the selected DSL ATM interface (EoA, PPPoA or IPoA), the content of the following WAN interface configuration screens differs.

Therefore, and for more clarity, each type of protocol will be dealt with separately (screens + associated summary tables) below.


5.7.2.2 Ethernet over ATM – PPP over Ethernet (PPPoE)

- Select the WAN service type **PPP over Ethernet (PPPoE)**.

Field	Action	Default value
Enter Service description	Displays the name of the service being configured. This name, which is allocated automatically, is made up as follows: Protocol_VPI_Index_VCI For example: pppoe_0_0_35. Note: You may enter another service name.	pppoe_0_0_35
Enter 802.1P Priority⁵	Enter a value for the 802.1P Priority. This value is between 0 and 7.	-1
Enter 802.1Q VLAN ID⁵	Enter a value for the 802.1QVLAN ID. This value is between 0 and 4094.	-1
Enable IPv6 for this service	Check this box to enable IPv6 for this service.	Not checked

- Click on the **Next** button to continue configuring the WAN service.

⁵ These values only appear if the WAN service is configured over a DSL ATM interface using VLAN MUX Mode.




Field	Action	Default value
PPP Username	Enter your connection ID. This information is provided to you by your Internet Service Provider (ISP).	-
PPP Password	Enter your connection password. This information is provided to you by your Internet Service Provider (ISP).	-
PPPoE Service Name	Enter the name of the PPPoE service. This information is provided to you by your Internet Service Provider (ISP).	-
Authentication Method	Select the authentication method of your choice from the scroll down list: <ul style="list-style-type: none"> • AUTO, • PAP, • CHAP, • MSCHAP. 	AUTO
Dial on demand (with idle timeout timer)	Check the box to only connect to the Internet on "Traffic".	Not checked
Inactivity Timeout (minutes) [1-4320]:⁶	Enter the inactivity time. This value (in minutes) is between 1 and 4320 (i.e. 72 hours). If there is no traffic for a certain period of time, the PPPoE session is interrupted.	0

⁶ This field only appears when the "Dial on demand (with idle timeout timer)" field is activated (box checked).

Field	Action	Default value
PPP retry on authentication error	Check the box, PPP can be retried again and again while authentication fails	Checked
PPP retry period (seconds)	Enter if required a retry period. This value (in seconds) is by default set to 15 seconds. You can set another value from 3 to 65535.	15
PPP MTU (Bytes)	Enter an MTU (Maximum Transfer Unit) value. This value (in bytes) is between 38 and 1492. Note: The MTU specifies the maximum size of the data used (IP packets) expressed as a number of bytes.	1492
Use Static IPv4 Address	Check the box to use the static IPv4 address.	Not checked
IPv4 Address:⁷	Enter the static IPv4 address.	0.0.0.0
Use Static IPv6 Address⁸	Check the box to use the static IPv6 address.	Not checked
IPv6 Address⁹	Enter the static IPv6 address.	-
IPv6 Address Prefix Length⁹	Enter the prefix length for the IPv6 address.	64
Enable PPP Debug mode	Check the box to use the PPP Debug mode. In the event of connection failure, this option will enable you to trace a possible problem in the SYSLOG file.	Not checked
Bridge PPPoE frames between WAN and Local Ports	Check the box to enable the router when bridging the frames between WAN and local Ethernet ports	Not checked
Enable IGMP Multicast Proxy	Check the box to activate the IGMP function.	Not checked

- Click on the **Next** button to continue configuring the remote network (WAN) in PPPoE mode.
- Select a preferred wan interface as the system default gateway.



⁷ This field only appears when the "Use Static IPv4 Address" field is activated (box checked).

⁸ This field only appears when the "Enable IPv6 for this service" feature is activated (box checked).

⁹ These fields only appear when the "Use Static IPv6 Address" field is activated (box checked).

5 - Information / Configuration

- Click on the **Next** button to continue configuring the remote network (WAN) in PPPoE mode.

Field	Action	Default value
Obtain DNS info from a WAN interface	Check the box to obtain DNS server addresses automatically, and select the desired interface in the list WAN Interface selected .	Checked
Use the following Static DNS IP address	If you check this box, you must enter DNS server addresses.	Not checked
Primary DNS server	Enter a primary DNS server address.	-
Secondary DNS server	Enter a secondary DNS server address.	-

- Click on the **Next** button to continue configuring the remote network (WAN) in PPPoE mode.

SAGEM

ADSL Down 19999 kbps Up 1052 kbps refresh reboot
Internet Connected.

Device Info
Internet Connection
Advanced Setup
Layer2 Interface
ATM Interface
WAN Service
LAN
IPv6 LAN Config
NAT
Security
Parental Control
Quality of Service
Routing
DNS
DSL
Upnp
Dns Proxy
Interface Grouping
LAN Ports
Certificate
Wireless
Diagnostics
Management

WAN Setup - Summary
Make sure that the settings below match the settings provided by your ISP.

PORT / VPI / VCI:	0 / 0 / 35
Connection Type:	PPPoE
Service Name:	pppoe_0_0_35
Service Category:	UBR
IP Address:	Automatically Assigned
Service State:	Enabled
NAT:	Enabled
Firewall:	Enabled
IGMP Multicast:	Disabled
Quality Of Service:	Enabled

Click "Apply/Save" to have this interface to be effective. Click "Back" to make any modifications.


SAGEM
© 2005-2009 SAGEM Corporation. All rights reserved.

Field	Action
PORT / VPI / VCI	Displays the Port/VPI/VCI specific to the "PPPoE" connection
Connection Type	Displays the "PPPoE" protocol
Service Name	Displays the name of the service: pppoe_0_0_35.
Service Category	Displays the type of service adapted to the traffic required.
IP Address	Indicates that the IP address is allocated automatically: Automatically assigned
Service State	Displays the status of the service: Enabled
NAT	Displays the status of the NAT: Enabled
Firewall	Displays the status of the firewall: Enabled
IGMP Multicast	Displays the status of the IGMP function: Disabled
Quality of Service	Displays the status of the Quality of Service function: Enabled

- Click on the **Apply/Save** button to confirm the new WAN service.

5.7.2.3 Ethernet over ATM – IP over Ethernet (IPoE)

- Select the WAN service type **IP over Ethernet (IPoE)**.



Field	Action	Default value
Enter Service description	Displays the name of the service being configured. This name, which is allocated automatically, is made up as follows: Protocol_VPI_Index_VCI For example: ipoe_0_0_35. Note: You may enter another service name.	ipoe_0_0_35
Enter 802.1P Priority¹⁰	Enter a value for the 802.1P Priority. This value is between 0 and 7.	-1
Enter 802.1Q VLAN ID¹⁰	Enter a value for the 802.1QVLAN ID. This value is between 0 and 4094.	-1
Enable IPv6 for this service	Check this box to enable IPv6 for this service.	Not checked

- Click on the **Next** button to continue configuring the WAN service.

¹⁰ These values only appear if the WAN service is configured over a DSL ATM interface using VLAN MUX Mode.

SAGEM

ADSL ● Down 19999 kbps Up 1052 kbps refresh reboot
Internet ● Connected.

Device Info
Internet Connection
Advanced Setup
Layer2 Interface
ATM Interface
WAN Service
LAN
IPv6 LAN Config
NAT
Security
Parental Control
Quality of Service
Routing
DNS
DSL
Upnp
Dns Proxy
Interface Grouping
LAN Ports
Certificate
Wireless
Diagnostics
Management

WAN IP Settings

Enter information provided to you by your ISP to configure the WAN IP settings.
Notice: If "Obtain an IP address automatically" is chosen, DHCP will be enabled for PVC in MER mode.
If "Use the following Static IP address" is chosen, enter the WAN IP address, subnet mask and interface gateway.

Obtain an IP address automatically

Option 60 Vendor ID: (8 hexadecimal digits)

Option 61 IAID: (8 hexadecimal digits)

Option 61 DUID: (hexadecimal digit)

Option 125: Disable Enable

Use the following Static IP address:

WAN IP Address:

WAN Subnet Mask:

WAN gateway IP Address:

Back Next

SAGEM

© 2005-2009 SAGEM Corporation. All rights reserved.

Field	Action	Default value
Obtain an IP address automatically	Check the box to obtain an IP address automatically from your router's DHCP server.	Checked
Use the following Static IP address:	If you check this box, you must enter a static WAN IP address and the dedicated WAN subnet mask and WAN gateway IP address.	Not checked
WAN IP Address	Enter the static IP address.	-
WAN Subnet Mask	Enter the subnet mask.	-
WAN gateway IP address	Enter the gateway IP address.	-


5 - Information / Configuration

- Click on the **Next** button to continue configuring the remote network (WAN) in IPoE mode.

Field	Action	Default value
Enable IGMP Multicast	Check the box to activate the IGMP function.	Not checked

- Select a preferred wan interface as the system default gateway.

- Click on the **Next** button to continue configuring the remote network (WAN) in IPoE mode.



Field	Action	Default value
Obtain DNS info from a WAN interface	Check the box to obtain DNS server addresses automatically, and select the desired interface in the list WAN Interface selected .	Checked
Use the following Static DNS IP address:	If you check this box, you must enter DNS server addresses.	Not checked
Primary DNS server	Enter a primary DNS server address.	-
Secondary DNS server	Enter a secondary DNS server address.	-

- Click on the **Next** button to continue configuring the remote network (WAN) in IPoE mode.

SAGEM

ADSL Down 19999 kbps Up 1052 kbps refresh reboot
Internet Connected.

WAN Setup - Summary

Make sure that the settings below match the settings provided by your ISP.

PORT / VPI / VCI:	0 / 0 / 35
Connection Type:	IPoE
Service Name:	ipoe_0_0_35
Service Category:	UBR
IP Address:	Automatically Assigned
Service State:	Enabled
NAT:	Enabled
Firewall:	Enabled
IGMP Multicast:	Disabled
Quality Of Service:	Enabled

Click "Apply/Save" to have this interface to be effective. Click "Back" to make any modifications.

[Back](#) [Apply/Save](#)

SAGEM

© 2005-2009 SAGEM Corporation. All rights reserved.

Field	Action
PORT / VPI / VCI	Displays the Port/VPI/VCI specific to the "IPoE" connection.
Connection Type	Displays the "IPoE" protocol
Service Name	Displays the name of the service: ipoe_0_0_35.
Service Category	Displays the type of service adapted to the traffic required.
IP Address	Indicates that the IP address is allocated automatically: Automatically Assigned
Service State	Displays the status of the service: Enabled
NAT	Displays the status of the NAT: Enabled
Firewall	Displays the status of the firewall: Enabled
IGMP Multicast	Displays the status of the IGMP function: Disabled
Quality Of Service	Displays the status of the Quality Of Service function: Enabled

- Click on the **Apply/Save** button to confirm the new WAN service.

5.7.2.4 Ethernet over ATM – Bridging

- Select the WAN service type **Bridging**.

Field	Action	Default value
Enter Service description	Displays the name of the service being configured. This name, which is allocated automatically, is made up as follows: Protocol_VPI_Index_VCI For example: br_0_0_35. Note: You may enter another service name.	br_0_0_35
Enter 802.1P Priority¹¹	Enter a value for the 802.1P Priority. This value is between 0 and 7.	-1
Enter 802.1Q VLAN ID¹¹	Enter a value for the 802.1QVLAN ID. This value is between 0 and 4094.	-1
Enable IPv6 for this service	Check this box to enable IPv6 for this service.	Not checked

- Click on the **Next** button to continue configuring the remote network (WAN) in Bridge mode.

¹¹ These values only appear if the WAN service is configured over a DSL ATM interface using VLAN MUX Mode.

SAGEM

ADSL ● Down 19999 kbps Up 1052 kbps refresh reboot
Internet ● Connected.

WAN Setup - Summary

Make sure that the settings below match the settings provided by your ISP.

PORT / VPI / VCI:	0 / 0 / 35
Connection Type:	Bridge
Service Name:	br_0_0_35
Service Category:	UBR
IP Address:	Not Applicable
Service State:	Enabled
NAT:	Disabled
Firewall:	Disabled
IGMP Multicast:	Not Applicable
Quality Of Service:	Enabled

Click "Apply/Save" to have this interface to be effective. Click "Back" to make any modifications.

SAGEM

© 2005-2009 SAGEM Corporation. All rights reserved.

Field	Action
PORT / VPI / VCI	Displays the Port/VPI/VCI specific to the "Bridge" connection.
Connection Type	Displays the "Bridge" protocol
Service Name	Displays the name of the service: br_0_0_35.
Service Category	Displays the type of service adapted to the traffic required.
IP Address	In the "Bridge" connection, this field is: Not Applicable
Service State	Displays the status of the service: Enabled
NAT	Displays the status of the NAT: Disabled
Firewall	Displays the status of the firewall: Disabled
IGMP Multicast	In the "Bridge" connection, this field is: Not Applicable
Quality Of Service	Displays the status of the Quality Of Service function: Enabled

- Click on the **Apply/Save** button to confirm the new WAN service.

5.7.2.5 PPP over ATM (PPPoA)

WAN Service Configuration


Enter Service Description:

Back Next

© 2005-2009 SAGEM Corporation. All rights reserved.

Field	Action	Default value
Enter Service description	Displays the name of the service being configured. This name, which is allocated automatically, is made up as follows: Protocol_VPI_Index_VCI For example: pppoa_0_0_35. Note: You may enter another service name.	pppoa_0_0_35

- Click on the **Next** button to continue configuring the WAN service.




Field	Action	Default value
PPP Username	Enter your connection ID. This information is provided to you by your Internet Service Provider (ISP).	-
PPP Password	Enter your connection password. This information is provided to you by your Internet Service Provider (ISP).	-
Authentication Method	Select the authentication method of your choice from the scroll down list: <ul style="list-style-type: none"> • AUTO, • PAP, • CHAP, • MSCHAP. 	AUTO
Dial on demand (with idle timeout timer)	Check the box to only connect to the Internet on "Traffic".	Not checked
Inactivity Timeout (minutes) [1-4320]:¹²	Enter the inactivity time. This value (in minutes) is between 1 and 4320 (i.e. 72 hours).	0

¹² This field only appears when the "Dial on demand (with idle timeout timer)" field is activated (box checked).


Field	Action	Default value
PPP retry on authentication error	Check the box, PPP can be retried again and again while authentication fails	Checked
PPP retry period (seconds)	Enter if required a retry period. This value (in seconds) is by default set to 15 seconds. You can set another value from 3 to 65535.	15
PPP MTU (Bytes)	Enter an MTU (Maximum Transfer Unit) value. This value (in bytes) is between 46 and 1500. Note: The MTU specifies the maximum size of the data used (IP packets) expressed as a number of bytes.	1500
Use Static IPv4 Address	Check the box to use the static IPv4 address.	Not checked
IPv4 Address:¹³	Enter the static IPv4 address.	0.0.0.0
Enable PPP Debug mode	Check the box to use the PPP Debug mode. In the event of connection failure, this option will enable you to trace a possible problem in the SYSLOG file.	Not checked
Enable IGMP Multicast Proxy	Check the box to activate the IGMP function.	Not checked

- Click on the **Next** button to continue configuring the remote network (WAN) in PPPoA mode.
- Select a preferred wan interface as the system default gateway.



- Click on the **Next** button to continue configuring the remote network (WAN) in PPPoA mode.

¹³ This field only appears when the "Use Static IPv4 Address" field is activated (box checked).



Field	Action	Default value
Obtain DNS info from a WAN interface	Check the box to obtain DNS server addresses automatically, and select the desired interface in the list WAN Interface selected .	Checked
Use the following Static DNS IP address	If you check this box, you must enter DNS server addresses.	Not checked
Primary DNS server	Enter a primary DNS server address.	-
Secondary DNS server	Enter a secondary DNS server address.	-

- Click on the **Next** button to continue configuring the remote network (WAN) in PPPoA mode.

SAGEM

ADSL Down 19999 kbps Up 1052 kbps refresh reboot
Internet Connected.

WAN Setup - Summary

Make sure that the settings below match the settings provided by your ISP.

PORT / VPI / VCI:	0 / 0 / 35
Connection Type:	PPPoA
Service Name:	pppoa_0_0_35
Service Category:	UBR
IP Address:	Automatically Assigned
Service State:	Enabled
NAT:	Enabled
Firewall:	Enabled
IGMP Multicast:	Disabled
Quality Of Service:	Disabled

Click "Apply/Save" to have this interface to be effective. Click "Back" to make any modifications.

Back Apply/Save


SAGEM

© 2005-2009 SAGEM Corporation. All rights reserved.

Field	Action
PORT / VPI / VCI	Displays the Port/VPI/VCI specific to the "PPPoA" connection.
Connection Type	Displays the "PPPoA" protocol.
Service Name	Displays the name of the service: pppoa_0_0_35.
Service Category	Displays the type of service adapted to the traffic required.
IP Address	Indicates that the IP address is allocated automatically: Automatically Assigned.
Service State	Displays the status of the service: Enabled.
NAT	Displays the status of the NAT: Enabled.
Firewall	Displays the status of the firewall: Enabled.
IGMP Multicast	Displays the status of the IGMP function: Disabled.
Quality of Service	Displays the status of the Quality of Service function: Disabled.

- Click on the **Apply/Save** button to confirm the new WAN service.

5.7.2.6 IP over ATM (IPoA)



Field	Action	Default value
Enter Service description	Displays the name of the service being configured. This name, which is allocated automatically, is made up as follows: Protocol_VPI_Index_VCI For example: ipoa_0_0_35. Note: You may enter another service name.	ipoa_0_0_35

- Click on the **Next** button to continue configuring the WAN service.

The screenshot shows the SAGEM router's configuration interface. At the top right, there are status indicators for ADSL (green) and Internet (green), along with speed information: Down 19999 kbps, Up 1052 kbps, and a 'Connected.' status. A 'refresh' and 'reboot' button is also present. On the left, a navigation menu lists various settings like Device Info, Internet Connection, Layer2 Interface, etc. The main content area is titled 'WAN IP Settings' and contains the instruction: 'Enter information provided to you by your ISP to configure the WAN IP settings.' Below this, there are two input fields: 'WAN IP Address:' with the value '0.0.0.0' and 'WAN Subnet Mask:' with the value '0.0.0.0'. 'Back' and 'Next' buttons are located below the input fields. A small image of the router is visible in the bottom right corner of the configuration area.

Field	Action	Default value
WAN IP Address	Enter the static IP address.	0.0.0.0
WAN Subnet Mask	Enter a subnet mask.	0.0.0.0

- Click on the **Next** button to continue configuring the remote network (WAN) in IPoA mode.

The screenshot shows the SAGEM router's configuration interface for IGMP Multicast. The top status bar is identical to the previous screenshot. The left navigation menu is also the same. The main content area is titled 'IGMP Multicast' and contains a single checkbox labeled 'Enable IGMP Multicast', which is currently unchecked. Below the checkbox, there are 'Back' and 'Next' buttons. A small image of the router is visible in the bottom right corner of the configuration area.

5 - Information / Configuration

Field	Action	Default value
Enable IGMP Multicast	Check the box to activate the IGMP function.	Not checked

- Click on the **Next** button to continue configuring the remote network (WAN) in IPoA mode.
- Select a preferred wan interface as the system default gateway.


The screenshot shows the SAGEM router's web interface. At the top right, there are status indicators for ADSL and Internet, both showing 'Connected'. The main content area is titled 'Routing -- Default Gateway' and contains the instruction: 'Select a preferred wan interface as the system default gateway..'. Below this, there is a dropdown menu labeled 'Selected WAN Interface' with the value 'pppoe_0_8_35/pppoe0' selected. At the bottom of the main area, there are 'Back' and 'Next' buttons. A sidebar on the left lists various configuration options, and a small image of the router is in the bottom right corner.

- Click on the **Next** button to continue configuring the remote network (WAN) in IPoA mode.

The screenshot shows the SAGEM router's web interface for 'DNS Server Configuration'. At the top right, the status indicators for ADSL and Internet remain 'Connected'. The main content area is titled 'DNS Server Configuration' and includes the instruction: 'Get DNS server information from the selected WAN interface OR enter static DNS server IP addresses. If only a single PVC with IPoA or static MER protocol is configured, you must enter static DNS server IP addresses.'. There are two radio button options: 'Obtain DNS info from a WAN interface:' (which is selected) and 'Use the following Static DNS IP address:'. The selected option has a dropdown menu for 'WAN Interface selected:' with 'pppoe_0_8_35/pppoe0' chosen. Below the static option, there are input fields for 'Primary DNS server:' and 'Secondary DNS server:'. 'Back' and 'Next' buttons are at the bottom. The sidebar and router image are also present.

Field	Action	Default value
Obtain DNS info from a WAN interface	Check the box to obtain DNS server addresses automatically, and select the desired interface in the list WAN Interface selected .	Checked
Use the following Static DNS IP address	If you check this box, you must enter DNS server addresses.	Not checked
Primary DNS server	Enter a primary DNS server address.	-
Secondary DNS server	Enter a secondary DNS server address.	-

- Click on the **Next** button to continue configuring the remote network (WAN) in IPoA mode.




Field	Action
PORT / VPI / VCI	Displays the Port/VPI/VCI specific to the "IPoA" connection.
Connection Type	Displays the "IPoA" protocol.
Service Name	Displays the name of the service: ipoa_0_0_35.
Service Category	Displays the type of service adapted to the traffic required.
IP Address	Indicates the IP address entered.
Service State	Displays the status of the service: Enabled .
NAT	Displays the status of the NAT: Enabled .
Firewall	Displays the status of the firewall: Enabled .
IGMP Multicast	Displays the status of the IGMP function: Disabled .
Quality of Service	Displays the status of the Quality of Service function: Disabled .

- Click on the **Apply/Save** button to confirm the new WAN service.

5.7.3 LAN

Object: This is used to configure the IP parameters for the local network (LAN).

- In the **Advanced Setup** menu, select **LAN**.
The following screen opens:



Field	Action	Default value
Groupname	Select the required group.	Default
IP Address	Enter the address of your local network.	192.168.1.1
Subnet Mask	Enter your network's subnet mask.	255.255.255.0
Enable IGMP Snooping	Check this box to activate the IGMP (Internet Group Management Protocol) protocol. This lets you manage the declarations of belonging to one or more groups with Multicast routers.	Not checked
Standard Mode¹⁴	Check the box if you wish the IGMP snooping runs in normal mode (transparency with IGMP frames).	Checked
Blocking Mode¹⁴	Check the box if you wish the IGMP snooping runs in blocking mode (interception and removal of IGMP frames).	Not checked
Enable LAN side firewall	Check the box to activate the LAN side firewall.	Not checked

¹⁴ These fields only appear when the "Enable IGMP Snooping" field is activated (box checked).


Field	Action	Default value
Disable DHCP Server	Check this box to deactivate your router's DHCP server. Note: You must configure your computer with the parameters appropriate to your local network (IP address, subnet mask and default gateway) as well as enter the primary and secondary DNS server addresses.	Not checked
Enable DHCP	Check this box to activate your router's DHCP server. Note: You must configure your computer as DHCP client and DNS client (or enter the primary and secondary DNS server addresses).	Checked
Start IP Address	Enter the first address attributed by your router's DHCP server.	192.168.1.2
End IP Address	Enter the last address attributed by your router's DHCP server.	192.168.1.254
Leased Time (hour)	Enter an unavailability time (in hours) for each attributed address.	24
Static IP Lease List	Enter if required the list of static IP Lease.	–
Configure the second IP Address and Subnet Mask for LAN interface	Check the box to configure the IP parameters (IP address, subnet mask) of a second address for the local network (LAN).	Not checked
IP Address¹⁵	Enter a second address for your local network (LAN).	–
Subnet Mask¹⁵	Enter a subnet mask for the second address for your local network (LAN).	–

¹⁵ These fields only appear when the "Configure the second IP Address and Subnet Mask for LAN interface" field is activated (box checked).

5.7.4 IPv6 LAN Config

Object: This menu lets you set IPv6 LAN Host configuration.

- In the **Advanced Setup** menu, select **IPv6 LAN Config**.
The following screen appears:



Field	Action	Default value
Enable DHCPv6 Server	Check the box to activate the DHCPv6 Server.	Not checked
Enable RADVD	Uncheck the box to deactivate RADVD (R outer A dvertisement D aemon) function.	Checked
Delegated from WAN	Check the box if you want the IPv6 Site Prefix Configuration type to be delegated from WAN, and select the required WAN interface in the WAN Interface selected list.	Checked
Static	Check the box if you want to set manually the IPv6 Site Prefix Configuration type.	Not Checked
Site Prefix	Enter the IPv6 site prefix.	-
Site Prefix Length	Enter the IPv6 site prefix length.	-
Enable MLD Snooping	Check this box to activate the MLD (M ulticast L istener D iscovery) protocol. This lets you manage the declarations of belonging to one or more groups with Multicast routers.	Not checked
Standard Mode¹⁶	Check the box if you wish the MLD snooping runs in normal mode.	Checked
Blocking Mode¹⁶	Check the box if you wish the MLD snooping runs in blocking mode.	Not checked

¹⁶ These fields only appear when the “Enable MLD Snooping” field is activated (box checked).

5.7.5 NAT

Object: NAT is a configurable IP address translation function which will be applied to the interfaces of your router which you will have activated for this function. Several translation function configurations, the NAT actions, can be configured and may be activated as indicated in section 5.7.5.1 > **Add**.

This section contains the following four menus:

- Virtual Servers (see subsection 5.7.5.1)
- Port Triggering (see subsection 5.7.5.2)
- DMZ Host (see subsection 5.7.5.3)

5.7.5.1 Virtual Servers

Object: This menu is used to route directly to the External Ports the incoming data from a Service server (such as, for example, FTP Server, SNMP, TFTP etc.) of the remote network (WAN) to computers on the local network (LAN) via the Internal Ports.

- In the **Advanced Setup** menu, select **NAT** then select **Virtual Servers**. The following screen opens:

NAT -- Virtual Servers Setup

Virtual Server allows you to direct incoming traffic from WAN side (identified by Protocol and External port) to the Internal server, with private IP address on the LAN side. The Internal port is required only if the external port needs to be converted to a different port number used by the server on the LAN side. A maximum 32 entries can be configured.

Buttons: Add Remove


Server Name	External Port Start	External Port End	Protocol	Internal Port Start	Internal Port End	Server IP Address	WAN Interface	Remove

© 2005-2009 SAGEM Corporation. All rights reserved.

Field	Meaning
Server Name	<ul style="list-style-type: none"> • Select a Service: Service available over Internet (such as, for example FTP Server, SNMP, TFTP etc.). • Custom Service: Name you want to allocate to a local server.
External Port Start	Internal start port (WAN side).
External Port End	Internal end port (WAN side).
Protocol	Transport protocol (TCP, UDP or TCP/UDP).
Internal Port Start	Internal start port (LAN side).
Internal Port End	This internal end port (LAN side) is associated with the external end port (WAN) side. Note: This cannot be modified.
Server IP Address	Computer address delivered by your router's DHCP server.
WAN Interface	WAN interface used.

Add

- Click on the **Add** button; the following screen appears:



Proceed as follows:

- Select the required WAN interface in the **Use Interface** list.

- Check the **Select a Service** box, then select the service of your choice from the scroll down list, for example "SNMP".

The **External Port Start**, **External Port End**, **Internal Port Start**, **Internal Port End** and **Protocol** fields (transport protocol associated with this service) are automatically filled in the table.

Note



You may complete the table by adding other ports associated with a protocol.


or

- Check the **Custom Service** box, enter the name of the server you want to connect to, then:
 - Complete the ID Host of your computer's IP address (this is attributed by your router's DHCP server).
 - Fill in the **External Port Start**, **External Port End**, **Internal Port Start**, **Internal Port End** and **Protocol** fields.

A few rules for entering values:

- When you want to select a single port, the start port (**External Port Start** or **Internal Port Start**) and the end port (**External Port End** or **Internal Port End**) must be identical.
- When you want to select a range of ports, the start port number must be lower than the end port number.
- You must always start entering with the **External Port Start** and **External Port End** ports.
- When you allocate a number to an **External Port Start**, the same number is automatically allocated to the **Internal Port Start** and identically for **External Port End**.

The following diagram contains an example:




The "Delta Force 2" service is available on your computer via the external ports 3568 and 3569 (WAN side) and via the internal ports 3568 and 3569 (LAN side).

5.7.5.2 Port Triggering

Object: The purpose of this menu is to open dynamically the firewall ports (open ports) via "Trigger Ports" when an application (such as games or video) opens a connection via the transport layer (TCP or UDP).

- In the **Advanced Setup** menu, select **NAT** then select **Port Triggering**. The following screen opens:



Field	Meaning
Application Name	Application name.
Trigger	<ul style="list-style-type: none"> • Protocol: Transport protocol (TCP, UDP or TCP/UDP). • Port Range: A port range contains a Start port and an End port. Note: A single port is characterised by an identical start port and end port.
Open	<ul style="list-style-type: none"> • Protocol: Transport protocol (TCP, UDP or TCP/UDP). • Port Range: A port range contains a Start port and an End port. Note: A single port is characterised by an identical start port and end port.
WAN Interface	WAN Interface used.

Add

- Click on the **Add** button; the following screen appears:

To configure **Trigger Port** and **Open Port**, proceed as follows:

- Select the required WAN interface in the **Use Interface** list.
- Check the **Select an application** box, then select the service of your choice from the scroll down list, for example "Aim Talk".

The **Trigger Port Start**, **Trigger Port End**, **Open Port Start**, **Open Port End** and **Protocol** fields (transport protocol associated with this service) are automatically filled in the table.

Note



You may complete the table by adding other ports associated with a protocol.


or

- Check the **Custom application** box to specify your own application, then.
 - Enter the name of your own application.
 - Fill in the **Trigger Port Start**, **Trigger Port End**, **Open Port Start**, **Open Port End** and **Protocol** fields.

A few rules for entering values:

- When you want to select a single port, the start port (**Trigger Port Start** or **Open Port Start**) and the end port (**Trigger Port End** or **Open Port End**) must be identical.
- When you want to select a range of ports, the start port number must be lower than the end port number.

The following diagram contains an example:



Using the "Trigger" 3568 port (WAN side), the "Delta Force" service server triggers the opening of port range 3100 to 3999 for your computer to access this service.

5.7.5.3 DMZ Host

Object: This "DMZ" (**De**Militarized **Z**one) lets you access the server you selected directly via the Internet without going through the "Firewall".

Important



Caution, this process presents an intrusion risk. It is therefore vital that you take precautions so that no connections may be initiated to the private network.

- In the **Advanced Setup** menu, select **NAT** then select **DMZ Host**. The following screen opens:

The screenshot displays the SAGEM router's web interface for configuring the DMZ Host. The main content area is titled 'NAT - DMZ Host' and contains the following text: 'The DSL router will forward IP packets from the WAN that do not belong to any of the applications configured in the Virtual Servers table to the DMZ host computer. Enter the computer's IP address and click "Apply" to activate the DMZ host. Clear the IP address field and click "Apply" to deactivate the DMZ host.' Below this text is a text input field labeled 'DMZ Host IP Address:' and a 'Save/Apply' button. The left sidebar lists various configuration options, with 'DMZ Host' highlighted. The top right corner shows network status: 'ADSL Down 19999 kbps Up 1052 kbps' and 'Internet Connected.' with 'refresh' and 'reboot' buttons.

Field	Action	Default value
DMZ Host IP Address	Enter the IP address of a server to activate the "DMZ" and therefore access it directly from the Internet. To deactivate the "DMZ" zone, erase the address entered in the field. Note: Click on the Save/Apply button to take account of the address or its erasure.	-

Note



The **DMZ** zone is deactivated by default.

5.7.6 Security


5.7.6.1 IP Filtering

Outgoing

Object: This menu is used to create outgoing IP filters to refuse data from the LAN to the WAN and list the existing outgoing IP filters.

By default, all the outgoing data is accepted.

- In the **Advanced Setup** menu, select **Security > IP Filtering > Outgoing**. The following screen opens:



Field	Meaning
Filter Name	Name of the filter.
Protocol	Transport protocol.
Source Address / Mask	Source IP address / Subnet mask.
Source Port	Source port
Dest. Address / Mask	Destination IP address / Subnet mask.
Dest. Port	Destination port.

Add

- Click on the **Add** button to display the following screen:

The screenshot displays the SAGEM web interface for configuring an outgoing IP filter. The top right corner shows network status: ADSL (Down 19999 kbps, Up 1052 kbps) and Internet (Connected). The left sidebar lists various configuration options, with 'IP Filtering' and 'Outgoing' selected. The main area is titled 'Add IP Filter -- Outgoing' and contains the following fields:

- Filter Name:
- Protocol:
- Source IP address:
- Source Subnet Mask:
- Source Port (port or port:port):
- Destination IP address:
- Destination Subnet Mask:
- Destination Port (port or port:port):

An 'Apply/Save' button is positioned below the fields. A small image of a SAGEM router is visible in the bottom right corner of the interface.

Field	Action
Filter Name	Enter a representative name for the filter.
Protocol	Select the dedicated protocol from the scroll down list (TCP/UDP, TCP, UDP, ICMP).
Source IP address	Enter the Source IP address (LAN).
Source Subnet Mask	Subnet Mask.
Source Port (port or port:port)	Enter a "Source" port (LAN) or range of ports. Note: For one port, for example, enter 80. For a range of ports, enter 80:90.
Destination IP address	Enter the Destination IP address (WAN).
Destination Subnet Mask	Subnet Mask.
Destination Port (port or port:port)	Enter a "Destination" port (WAN) or range of ports. Note: For one port, for example, enter 80. For a range of ports, enter 80:90.

Incoming

Object: This menu is used to create incoming IP filters to refuse data from the WAN to the LAN and list the existing incoming IP filters.

By default, all the incoming data is refused when the Firewall is activated.

- In the **Advanced Setup** menu, select **Security > IP Filtering > Incoming**.
The following screen opens:

The screenshot displays the SAGEM F@st 1704 web interface. At the top right, there is a status bar showing 'ADSL' with a green light, 'Down 19999 kbps', 'Up 1052 kbps', and buttons for 'refresh' and 'reboot'. Below this, it indicates 'Internet Connected.' with another green light.

The main content area is titled 'Incoming IP Filtering Setup'. It contains the following text: 'When the firewall is enabled on a WAN or LAN interface, all incoming IP traffic is BLOCKED. However, some IP traffic can be **ACCEPTED** by setting up filters. Choose Add or Remove to configure incoming IP filters.'


Below the text is a table with the following columns: Filter Name, Interfaces, Protocol, Source Address / Mask, Source Port, Dest. Address / Mask, Dest. Port, and Remove. The table is currently empty. Below the table are two buttons: 'Add' and 'Remove'.

On the left side, there is a navigation menu with the following items: Device Info, Internet Connection, Advanced Setup, Layer2 Interface, WAN Service, LAN, IPv6 LAN Config, NAT, Security, IP Filtering, Outgoing, Incoming (highlighted), Parental Control, Quality of Service, Routing, DNS, DSL, Upnp, Dns Proxy, Interface Grouping, LAN Ports, Certificate, Wireless, Diagnostics, and Management.

The SAGEM logo is visible in the bottom left corner, and a small image of the router is in the bottom right corner. The footer contains the text: '© 2005-2009 SAGEM Corporation. All rights reserved.'

Add

- Click on the **Add** button to display the following screen:



Field	Action
Filter Name	Enter a representative name for the filter.
Protocol	Select the dedicated protocol from the scroll down list (TCP/UDP, TCP, UDP, ICMP).
Source IP address	Enter the Source IP address (WAN).
Source Subnet Mask	Subnet mask.
Source Port (port or port:port)	Enter a "Source" port (WAN) or range of ports. Note: For one port, for example, enter 80. For a range of ports, enter 80:90.
Destination IP address	Enter the destination IP address (LAN).
Destination Subnet Mask	Subnet mask.
Destination Port (port or port:port)	Enter a "destination" port (LAN) or range of ports. Note: For one port, for example, enter 80. For a range of ports, enter 80:90.

WAN interfaces

Field	Action	Default value
Select All	Check the box to select all WAN interfaces. Note: By unchecking the box, no interface is selected and the other WLAN/LAN interfaces displayed boxes become unchecked.	Checked
pppoa_0_8_35/pppoa0	Check the box to select the displayed interface.	Checked
br0/br0	Check the box to select the displayed interface.	Checked

5.7.7 Parental Control

Object: This menu is used to create and manage access time restriction for LAN devices which are connected to the router.

- In the **Advanced Setup** menu, select **Parental Control**.
The following screen opens:



Add

- Click on the **Add** button to display the following screen:

The screenshot shows the SAGEM router's web interface. At the top right, there are status indicators for ADSL (Down 19999 kbps, Up 1052 kbps) and Internet (Connected). The main content area is titled 'Access Time Restriction' and contains the following fields and options:

- User Name:** A text input field.
- MAC Address:** A radio button selected, followed by a text input field with a placeholder '(xxxxxxxxxxxx)'. A note below explains that this is for a Windows-based PC and provides the command 'ipconfig /all'.
- Days of the week:** A row of checkboxes for Mon, Tue, Wed, Thu, Fri, Sat, and Sun. The 'Mon' checkbox is checked.
- Start Blocking Time (hh:mm):** A text input field.
- End Blocking Time (hh:mm):** A text input field.
- Apply/Save:** A button to save the configuration.

A sidebar on the left lists various configuration categories, and a small image of the router is shown in the bottom right corner of the page.

Field	Action
User Name	Enter a representative name for the LAN device.
MAC Address	Enter the MAC address of the required LAN device. Note: To find out the MAC address of a Windows based PC, open a command window and type "ipconfig /all".
Days of the week	Select the days of the week on which the restriction is effective by checking the corresponding box.
Start Blocking Time	Enter the required blocking start hour (for example 08:00).
End Blocking Time	Enter the required blocking end hour (for example 20:00).

5.7.8 Quality of Service

This menu contains 2 sub-menus:

- Queue Config (see subsection 5.7.8.1),
- QoS Classification (see subsection 5.7.8.2).

Object: This menu is used to allocate different types of traffic queues with different priorities in order to improve the traffic flow. To do this, the quality of service (QoS) provides the following three services: Classification (set-1, set-2), Marking (TOS, DSCP) and queues (Queuing).

The quality of service is only significant if all the traffic (data, video) is greater than the up rate of the ADSL line.

- In the **Advanced Setup** menu, select **Quality of Service**.
The following screen opens:


The screenshot displays the SAGEM web interface for QoS configuration. At the top right, there are status indicators for ADSL and Internet connections, showing speeds of 19999 kbps down and 1052 kbps up, with 'refresh' and 'reboot' buttons. The main content area is titled 'QoS -- Queue Management Configuration' and includes instructions on enabling QoS and selecting a default DSCP mark. A checkbox for 'Enable QoS' is checked, and a dropdown menu for 'Select Default DSCP Mark' is set to 'No Change(-1)'. An 'Apply/Save' button is visible. A sidebar on the left lists various configuration options, with 'Quality of Service' expanded to show 'Queue Config' and 'QoS Classification'. A small image of a SAGEM router is shown in the bottom right corner of the interface.

Field	Action
Enable QoS	Check the Enable QoS box to authorize QoS actions to be performed at the ingress and egress interfaces.
Select Default DSCP Mark	<p>The IP datagram DSCP (Differentiated Services Code Point, priority value from 0 to 63) identifies which output queue a packet is to be assigned to.</p> <p>Default DSCP Mark is used to mark the priority of the packets when they are not tagged in the computer. In this case the router will do it with the values indicated.</p> <p>Select from the scroll down list:</p> <p>No Change (-1): Value of –1 indicates no change from the incoming packet,</p> <p>Auto Marking (-2)</p> <p>Default (000000) : Marks everything else to DSCP 0,</p> <p>AF13 (001110)</p> <p>AF12 (001100) : Recommended markings for Bulk-Data,</p> <p>AF11 (001010) : Recommended markings for Bulk-Data,</p> <p>CS1 (001000) : Recommended markings for Scavenger traffic,</p> <p>AF23 (010110)</p> <p>AF22 (010100) : Recommended markings for Transactional-Data,</p> <p>AF21 (010010) : Recommended markings for Transactional-Data,</p> <p>CS2 (010000) : Recommended markings for Network Management,</p> <p>AF33 (011110)</p> <p>AF32 (011100) : Recommended markings for Mission-Critical Data,</p> <p>AF31 (011010) : Recommended markings for Mission-Critical Data,</p> <p>CS3 (011000) : Call-Signalling markings,</p> <p>AF43 (100110)</p> <p>AF42 (100100) : Recommended markings for IP/VC,</p> <p>AF41 (100010) : Recommended markings for IP/VC,</p> <p>CS4 (100000) : Recommended markings for Streaming-Video,</p> <p>EF (101110) : IP Phones mark Voice to EF,</p> <p>CS5 (101000)</p> <p>CS6 (110000) : Routers mark Routing traffic to CS6,</p> <p>CS7 (111000)</p> <p>Note: This drop-down list is present only if the box Enable Qos is checked.</p>

5.7.8.1 Queue Config

Object: This menu is used to enable or disable QoS on an interface, and to configure QoS to use policy maps attached to an interface.

- In the **Advanced Setup** menu, select **Quality of Service** then select **Queue Config**. The following screen opens:



Field	State
Name	Queue entry name
Key	Sequence number allocated by the system, incremented of a unit to each addition of a QoS Queue.
Interface	Name of the network interface configured (8/35 for example).
Precedence	Priority allocated to "Queue Precedence" from 1 to 3.
DSL Latency	DSL Latency
PTM Priority	PTM priority
Enable	QoS enabled or disabled for this interface. Note: This status can be amended starting from this window.

Add

- Click on the **Add** button to display the following screen:

SAGEM ADSL Down 19999 kbps Up 1052 kbps refresh reboot
Internet Connected.

QoS Queue Configuration

The screen allows you to configure a QoS queue entry and assign it to a specific network interface. Each of the queues can be configured for a specific precedence. The queue entry configured here will be used by the classifier to place ingress packets appropriately. **Note: Lower integer values for precedence imply higher priority for this queue relative to others.** Click 'Apply/Save' to save and activate the queue.

Name:

Enable:

Interface:

Precedence:

SAGEM
© 2005-2009 SAGEM Corporation. All rights reserved.

Field	Action
Name	Enter a representative name.
Enable	Select from the scroll down list: <ul style="list-style-type: none"> Disable: To disable the QoS queue entry Enable: To enable the QoS queue entry
Interface	Select from the scroll down list: <ul style="list-style-type: none"> Blank 8/35: Interface name.
Queue Precedence	Select from the scroll down list: <ul style="list-style-type: none"> Blank 1: High priority for this queue, 2: Medium priority for this queue, 3: Low priority for this queue. <p>Note: A high priority leads to low packet loss.</p>

5.7.8.2 QoS Classification

Object: This menu is used for the classification of packets into traffic classes, and for the enforcement of policies using queuing.

- In the **Advanced Setup** menu, select **Quality of Service** then select **QoS Classification**. The following screen opens:

QoS Classification Setup – A maximum 32 entries can be configured.

Choose Add or Remove to configure network traffic classes.
If you disable WMM function in Wireless Page, classification related to wireless will not take effects

CLASSIFICATION CRITERIA														CLASSIFICATION RESULTS				
Class Name	Order	Class	Ether Intf	SrcMAC/Mask	DstMAC/Mask	SrcIP/Mask	DstIP/Mask	Proto	Src Port	Dst Port	DSCP Check	802.1P Check	Queue Key	DSCP Mark	802.1P Mark	VlanID Tag	Enable	Remove
<input type="button" value="Add"/> <input type="button" value="Enable"/> <input type="button" value="Remove"/>																		

Field	State
Class Name	Traffic Class Name.
Order	Sequence number.
Classification Criteria	
Class Intf	
Ether Type	Nature of the LAN port.
SrcMAC/Mask	"Source" MAC address (your computer, for example) and associated subnet mask.
DstMAC/Mask	"Destination" MAC address (a machine on the Internet, for example) and associated subnet mask.
SrcIP/Mask	"Source" address (your computer, for example) and associated subnet mask.
DstIP/Mask	"Destination" address (a machine on the Internet, for example) and associated subnet mask.
Proto	Protocol used.
Src Port	"Source" port.
Dst Port	"Destination" port.
DSCP Check	Differentiated Services Code Point, priority value from Default to CS7.
802.1P Check	Priority field 802.1P (value between 0 and 7).
Classification Results	
Queue Key	Queue number, allocated by the system according to the selected precedence.
DSCP Mark	DSCP priority (from Default to CS7).
802.1P Mark	Priority field 802.1P (value between 0 and 7).
VlanID Tag	
Enable	QoS enabled or disabled for this traffic class. Note: This status can be amended starting from this window.

Add

- Click on the **Add** button to display the following screen:

The screenshot displays the SAGEM web management interface. At the top right, there are status indicators for ADSL (Down 19999 kbps, Up 1052 kbps) and Internet (Connected), along with 'refresh' and 'reboot' buttons. The left sidebar contains a navigation menu with categories like Device Info, Internet Connection, Advanced Setup, Layer2 Interface, WAN Service, LAN, IPv6 LAN Config, NAT, Security, Parental Control, Quality of Service, Queue Config, QoS Classification, Routing, DNS, DSL, Upnp, Dns Proxy, Interface Grouping, LAN Ports, Certificate, Wireless, Diagnostics, and Management. The main content area is titled 'Add Network Traffic Class Rule' and includes a descriptive paragraph: 'The screen creates a traffic class rule to classify the upstream traffic, assign queue which defines the precedence and the interface and optionally overwrite the IP header DSCP byte. A rule consists of a class name and at least one condition below. All of the specified conditions in this classification rule must be satisfied for the rule to take effect. Click 'Save/Apply' to save and activate the rule.'

The configuration fields are as follows:

- Traffic Class Name:
- Rule Order: (dropdown)
- Rule Status: (dropdown)
- Specify Classification Criteria**
A blank criterion indicates it is not used for classification.
 - Class Interface: (dropdown)
 - Ether Type: (dropdown)
 - Source MAC Address:
 - Source MAC Mask:
 - Destination MAC Address:
 - Destination MAC Mask:
- Specify Classification Results**
Must select a classification queue. A blank mark or tag value means no change.
 - Assign Classification Queue: (dropdown)
 - Mark Differentiated Service Code Point (DSCP): (dropdown)
 - Mark 802.1p priority: (dropdown)
 - Tag VLAN ID [0-4094]:

An 'Apply/Save' button is located at the bottom of the form. A small image of a SAGEM router is visible in the bottom right corner of the main content area. The footer of the page contains the copyright notice: '© 2005-2009 SAGEM Corporation. All rights reserved.'

Field	Action
Traffic Class Name	Enter a name for the traffic class you want to create.
Rule Order	Select from the scroll down list: <ul style="list-style-type: none"> • Blank • Last • Number: Number allotted by the system to the existing rules
Rule Status	Select from the scroll down list: <ul style="list-style-type: none"> • Disable: QoS disabled for this static class rule • Enable: QoS enabled for this static class rule
Class Interface	Select from the scroll down list: <ul style="list-style-type: none"> • Local • eth0 • wl0
Ether Type	Select from the scroll down list: <ul style="list-style-type: none"> • IP • ARP • IPv6 • PPPoE_DISC • PPPoE_SES • 8865 • 8866 • 8021Q
Source MAC Address	Enter a "Source" MAC address.
Source MAC Mask	Enter a "Source" MAC mask.
Destination MAC Address	Enter a "Destination" MAC address.
Destination MAC Mask	Enter a "Destination" MAC mask.
Assign Classification Queue	Select from the scroll down list: <ul style="list-style-type: none"> • Blank • Number: Priority number and associated queue number, defined by the system starting from the "Queue Precedence" (see subsection 5.7.8.1).
Mark Differentiated Service Code Point (DSCP)	Select the type of Differentiated Services Code Point (DSCP) mark to be allocated (6-bit coding) from the scroll down list. Default to CS7: 000000 to 111000
Mark 802.1p priority	Select Blank or a priority value between 0 and 7 from the scroll down list.
Tag VLAN ID	Enter a value from 0 to 4094.

5.7.9 Routing

This menu contains 3 sub-menus:

- Default Gateway (see subsection 5.7.9.1)
- Static Route (see subsection 5.7.9.2)
- Policy Routing (see subsection 5.7.9.3)
- RIP (see subsection 5.7.9.4)
- IPv6 Static Route (see subsection 5.7.9.5)

5.7.9.1 Default Gateway

Object: This menu is used either to allocate dynamically a default gateway address to the router from a PVC or to enter an address or choose an interface.

- In the **Advanced Setup** menu, select **Routing** then select **Default Gateway**. The following screen opens:




Field	Action
Select a preferred wan interface as the system default gateway	Select the interface you want to use from the scroll down list (pppoa_0_8_35 for example).
Select a preferred wan interface as the system default IPv6 gateway	Select the interface you want to use from the scroll down.

5.7.9.2 Static Route

Object: This menu is used to add a static route.


- In the **Advanced Setup** menu, select **Routing** then select **Static Route**. The following screen opens:



Field	Meaning
Destination	Remote network IP address
Subnet Mask	Remote subnet mask
Gateway	Default gateway of the remote network
Interface	Remote network interface

Add

- Click on the **Add** button to display the following screen:




Field	Action
Destination Network Address	Enter the IP address of the remote network.
Subnet Mask	Enter the remote subnet mask.
Use Interface	Select the interface you want to use from the scroll down list (pppoe_0_8_35 for example).

5.7.9.3 Policy Routing

Object: This menu is used to add policy routings.


- In the **Advanced Setup** menu, select **Routing** then select **Policy Routing**. The following screen opens:



Field	Meaning
Policy Name	Policy name
Source IP	Source IP address
LAN Port	Nature of the LAN port
WAN	Interface used
Default GW	Default gateway

Add

- Click on the **Add** button to display the following screen:




Field	Action
Policy Name	Enter the policy name.
Physical LAN Port	Select Blank or the interface of your choice (ENET(1-4) or wlan0) from the scroll down list.
Source IP	Enter a "Source" IP address
Use Interface	Select the interface you want to use from the scroll down list (pppoe_0_8_35 for example).
Default Gateway	Enter the default gateway IP address.

5.7.9.4 RIP

Object: The "RIP" protocol (**R**outing **I**nformation **P**rotocol) lets you tell routers the distance (number of hops) which separates them.

This protocol only takes account of the distance between two machines in terms of hops.

- In the **Advanced Setup** menu, select **Routing** then select **RIP**.
The following screen opens:




Field	Action/Meaning	Default value
Interface	Created or native interface.	
Version	Select the RIP version of your choice from the scroll down list. <ul style="list-style-type: none"> • 1: for RIP1 • 2: for RIP2 • Both 	2
Operation	Select the operation in the scroll down list: <ul style="list-style-type: none"> • Active: to transmit the routing information to the other routers and receive it from them • Passive: to listen to the RIP broadcasts and update its routing table, but not indicate its own routes (silent mode) 	Passive
Enabled	Check the box to activate the "RIP" function on the corresponding interface.	Not checked

5.7.9.5 IPv6 Static Route

Object: This menu is used to add a static route.


- In the **Advanced Setup** menu, select **Routing** then select **IPv6 Static Route**. The following screen opens:



Field	Meaning
Destination	Remote network IPv6 address
Prefix Length	Prefix length
Gateway	IPv6 gateway of the remote network
Interface	Remote network interface

Add

- Click on the **Add** button to display the following screen:



Field	Action
Destination IPv6 Address	Enter the destination IPv6 address.
Subnet Prefix Length	Enter the subnet prefix length.
Gateway IPv6 Address	Enter the IPv6 address of the gateway.
Interface	Select the interface you want to use from the scroll down.

5.7.10 DNS

5.7.10.1 DNS Server

Object: This menu enables the automatic resolution of domain names by polling remote servers.

- In the **Advanced Setup** menu, select **DNS** then select **DNS Server**. The following screen opens:

Field	Action	Default value
Obtain DNS info from a WAN interface	Check the box to obtain DNS server addresses automatically, and select the desired interface in the list WAN Interface selected .	Checked
Use the following Static DNS IP address	If you check this box, you must enter DNS server addresses.	Not checked
Primary DNS server	Enter a primary DNS server address.	-
Secondary DNS server	Enter a secondary DNS server address.	-

5.7.10.2 Dynamic DNS

Object: Enables a web surfer to access your router (having no fixed IP address but only a DNS entry) through a dynamic DNS provider such as, for example, **dyndns.org**.

- In the **Advanced Setup** menu, select **DNS** then select **Dynamic DNS**. The following screen opens:

The screenshot displays the SAGEM router's web interface for Dynamic DNS configuration. The main content area includes the following text:

Dynamic DNS

The Dynamic DNS service allows you to alias a dynamic IP address to a static hostname in any of the many domains, allowing your DSL router to be more easily accessed from various locations on the Internet.

Choose Add or Remove to configure Dynamic DNS:

Hostname	Username	Service	Interface	Remove

Below the table are two buttons: **Add** and **Remove**.

The left sidebar menu includes: Device Info, Internet Connection, Advanced Setup, Layer2 Interface, WAN Service, LAN, IPv6 LAN Config, NAT, Security, Parental Control, Quality of Service, Routing, DNS, DNS Server, **Dynamic DNS**, DSL, Upnp, Dns Proxy, Interface Grouping, LAN Ports, Certificate, Wireless, Diagnostics, and Management.

The top right status bar shows: ADSL Down 19999 kbps, Internet Up 1048 kbps, Connected. There are also 'refresh' and 'reboot' buttons.

At the bottom right, there is a small image of the SAGEM router.


Refer to the next subsection (Add) for detailed information on the fields of the table.

Note



The "Service" field is automatically filled by the system in "dyndns".

Add



Add dynamic DDNS

Field	Action
D-DNS provider	Select from the relevant drop-down list : <ul style="list-style-type: none"> • DynDNS.org • TZO
Hostname	Enter the symbolic name (for example butterfly) that you want to assign to your Residential Gateway. This is the name provided to you by your dynamic DNS provider (see Note).
Interface	Select from the relevant drop-down list the WAN interface which you want to use (pppoa_0_8_35/pppoa0 for example).

Note



If you enter the name "butterfly", the dynamic DNS provider (dyndns.org for example) incorporates this name in the domain name (butterfly.dyndns.org). The web surfer who wants to access your Residential Gateway receives from the dynamic DNS provider the dynamic IP address (transcription of the domain name) of your Residential Gateway supplied by your Internet service provider.


DynDNS Settings

Field	Action
Username	Enter the account name supplied to you by the dynamic DNS provider.
Password	Enter the account password provided to you by the dynamic DNS provider.

5.7.11 DSL

Object: The purpose of this menu is to parameter your ADSL line.

- In the **Advanced Setup** menu, select **DSL**.
The following screen opens:



Modulation

- Check the boxes according to the characteristics of your line.

Field	Default value
G.Dmt Enabled	Checked
G.lite Enabled	Checked
T1.413 Enabled	Checked
ADSL2 Enabled	Checked
AnnexL Enabled	Checked
ADSL2+ Enabled	Checked
AnnexM Enabled	Not checked

Phone line pair


- Check the boxes according to the characteristics of your line.

Field	Default value
Inner pair	Checked
Outer pair	Not checked

Capability


Field	Default value
Bitswap Enable	Checked
SRA Enable	Not checked

- Click on the **Advanced Settings** button to display the following screen:



Field	Default value
Normal	Checked
Reverb	Not checked
Medley	Not checked
No retrain	Not checked
L3	Not checked

- Click on the **Tone Selection** button to display the following screen:



Note



There are 32 ascending tones and 224 descending tones.

- Click on the **Check All** button to select all the tones or the **Clear All** button to select none of them.

Note




All the tones are selected by default.
To select a tone, simply check the associated box.
To unselect a tone, simply leave its associated box empty.

5.7.12 Upnp

Object: This menu is used to enable or disable the Upnp protocol. The Upnp function lets you automatically join a network dynamically and obtain an IP address.

- In the **Advanced Setup** menu, select **Upnp**. The following screen opens:



- To enable Upnp protocol, check the box. To disable it, uncheck the box.

5.7.13 DNS Proxy

Object: This menu is used to enable or disable DNS proxy.

- In the **Advanced Setup** menu, select **Dns Proxy**.
The following screen opens:


The screenshot displays the SAGEM web interface for DNS Proxy Configuration. The top right corner shows network status: ADSL (Down 19999 kbps, Up 1048 kbps) and Internet (Connected). The main content area is titled 'Dns Proxy Configuration' and contains a checked checkbox for 'Enable or disable Dns proxy.' Below this are two input fields: 'Host name of the modem:' with the value 'MyRouter' and 'Domain name of the LAN network:' with the value 'Home'. An 'Apply/Save' button is located to the right of the input fields. The sidebar on the left lists various configuration options, with 'Dns Proxy' highlighted. The SAGEM logo is visible in the top left and bottom left corners.

Field	Action	Default value
Enable or disable Dns Proxy	To enable Dns proxy, check the box. To disable it, uncheck the box	Checked
Hostname of the modem	Default hostname of the modem.	MyRouter
Domain name of the LAN network	Default domain name of the LAN network.	Home

5.7.14 Interface Grouping

Object: This menu is used to host a service (Video, Data, SIP) on an interface (ETH or Wi-Fi) of your router.

- In the **Advanced Setup** menu, select **Interface Grouping**. The following screen opens:



Field	Meaning
Group Name	Group name (see Note).
Enable/Disable	Allows to enable / disable a group of interfaces.
WAN Interface	WAN interface used.
LAN Interfaces	Lists all your router's interfaces. Note: Only the "nas_8_50" interface is not resident on the router. It corresponds to a "Bridge" ATM interface.


Note






By default, all the interfaces are dedicated to data and are associated with the first VC (**V**irtual **C**hannel) existing or created.

Add

- Click on the **Add** button to display the following screen:




Field	Meaning
Group Name	Enter a name which represents the service you want to associate with a desired interface (for example "video_eth" if you want to associate the TV over UP service with the interface (Ethernet)).
WAN Interface used in the grouping	Select the WAN interface you want to use in the grouping.
Grouped LAN Interface	Displays the interfaces associated with a service you selected in the Available LAN Interfaces area then transferred with the  button.
Available LAN Interfaces	Lists all your router's interfaces. Note: Only the "nas_8_50" interface is not resident on the router. It corresponds to a "Bridge" ATM interface.

Button	Action
	Transfer the interfaces selected in the Available LAN Interfaces area to the Grouped LAN Interfaces area.
	Transfer the interfaces selected in the Grouped LAN Interfaces area to the Available LAN Interfaces area.

5 - Information / Configuration


To enable you to understand better, the following diagram shows the path of the "Video" and "Data" flows.



5.7.15 LAN Ports

Object: This menu is used to enable or disable the Virtual LAN ports feature.

- In the **Advanced Setup** menu, select **LAN Ports**.
The following screen opens:



- If the box is unchecked, the Ethernet 1 to 4 (ENET (1-4)) ports are gathered and seen like only one virtual port.
- When the box is checked, these ports are independently seen but a fall of the performances of the transfers between ports is noted.

By default, this feature is disabled (box not checked).

5.7.16 Certificate


This menu contains 2 sub-menus:

- Local (see subsection 5.7.16.1),
- Trusted CA (see subsection 5.7.16.2).

5.7.16.1 Local

Object: This menu is used to manage your router's identity certificates. These certificates, which are used by TR-69 (in SSL mode), enable the mutual authentication of the CPE and the ACS.

- In the **Advanced Setup** menu, select **Certificate** then **Local**.
The following screen opens:



Field	Meaning
Name	Name of the certificate.
In Use	Indicates whether the certificate can be used or not.
Subject	Summarises the main characteristics of the certificate.
Type	Indicates the status of the certificate (e.g.: request).
Action	Select the action from the list: view, load signed certificate, remove.

Create Certificate Request


- Click on the **Create Certificate Request** button to display the following screen:

The screenshot shows the SAGEM web interface for creating a new certificate request. The main content area is titled "Create new certificate request" and contains the following text: "To generate a certificate signing request you need to include Common Name, Organization Name, State/Province Name, and the 2-letter Country Code for the certificate." Below this text are five input fields: "Certificate Name:", "Common Name:", "Organization Name:", "State/Province Name:", and "Country/Region Name:". The "Country/Region Name" field is a dropdown menu currently showing "US (United States)". An "Apply" button is located below the "Country/Region Name" field. The left sidebar contains a navigation menu with items like "Device Info", "Internet Connection", "Advanced Setup", etc. The top right corner shows network status: "ADSL Down 19999 kbps", "Internet Up 1048 kbps", and "Connected." with "refresh" and "reboot" buttons. The SAGEM logo is in the top left and bottom left. A small image of a SAGEM device is in the bottom right. Copyright text "© 2005-2008 SAGEM Corporation. All rights reserved." is at the bottom center.

Field	Action
Name	Enter the name of the certificate.
Common Name	Enter the name of the certificate's owner.
Organization Name	Enter the name of the organisation which owns the certificate.
State/Province Name	Enter the name of the state or province.
Country/Region Name	Select the country from the scroll down list.

Import Certificate

- Click on the **Import Certificate** button to display the following screen:



Field	Action
Certificate Name	Enter the name of the certificate.
Certificate	Insert the certificate here.
Private key	Insert the private key here.

5.7.16.2 Trusted CA

Object: This menu is used to manage the identity certificates of the remote servers. These certificates, which are used by TR-69 (in SSL mode), enable the mutual authentication of the CPE and the ACS.

- In the **Advanced Setup** menu, select **Certificate** then **Trusted CA**. The following screen opens:

The screenshot displays the SAGEM web interface. At the top right, there is a status bar showing ADSL and Internet connection status, with download and upload speeds (19999 kbps down, 1048 kbps up) and buttons for 'refresh' and 'reboot'. The left sidebar contains a navigation menu with options like 'Device Info', 'Internet Connection', 'Advanced Setup', 'Layer2 Interface', 'WAN Service', 'LAN', 'IPv6 LAN Config', 'NAT', 'Security', 'Parental Control', 'Quality of Service', 'Routing', 'DNS', 'DSL', 'Upnp', 'Dns Proxy', 'Interface Grouping', 'LAN Ports', 'Certificate', and 'Local'. The 'Certificate' option is selected, leading to the 'Trusted CA' page. The main content area is titled 'Trusted CA (Certificate Authority) Certificates' and contains the following text: 'Add, View or Remove certificates from this page. CA certificates are used by you to verify peers' certificates. Maximum 4 certificates can be stored.' Below this text is a table with columns 'Name', 'Subject', 'Type', and 'Action'. An 'Import Certificate' button is located below the table. The SAGEM logo is visible in the bottom left corner, and a small image of a SAGEM device is in the bottom right corner. The footer contains the copyright notice: '© 2005-2009 SAGEM Corporation. All rights reserved.'

Import Certificate

- Click on the **Import Certificate** button to display the following screen:



Field	Action
Certificate Name	Enter the name of the certificate.
Certificate	Insert the certificate here.

5.8 Wireless

Object: This menu lets you activate a network and also allows you to configure all the basic and advanced parameters of a wireless network.

This section contains the following five menus:

- Basic (see subsection 5.8.1)
- Security (see subsection 5.8.2)
- MAC Filter (see subsection 5.8.3)
- Advanced (see subsection 5.8.4)
- Station Info (see subsection 5.8.5)

Important



These menus must only be accessed/modified by experienced users.

5.8.1 Basic

- In the **Wireless** menu, select **Basic**.
The following screen opens:

SAGEM

ADSL Down 19999 kbps
Up 1048 kbps refresh
Internet Connected. reboot

Wireless -- Basic

This page allows you to configure basic features of the wireless LAN interface. You can enable or disable the wireless LAN interface, hide the network from active scans, set the wireless network name (also known as SSID) and restrict the channel set based on country requirements. Click "Apply/Save" to configure the basic wireless options.

Enable Wireless
 Hide Access Point
 Clients Isolation
 Disable WMM Advertise
 Enable Wireless Multicast Forwarding (WMM)

SSID:
 BSSID:
 Country:
 Max Clients:

SAGEM

© 2005-2009 SAGEM Corporation. All rights reserved.

5.8.1.1 Wireless – Basic

Field	Action/Meaning	Default value
Enable Wireless	Check the box to activate the wireless network (Wi-Fi). Note: The steady "Wi-Fi" LED on the front of the router shows that the wireless network (Wi-Fi) is activated.	Checked
Hide Access Point	Check the box to mask the broadcast of the SS ID and prevent any Wi-Fi connection on your router. Note: When this box is checked, the router's SSID is absent from the Wi-Fi adaptor user's own list of monitored sites (Access Point).	Not checked
Clients isolation	Check the box to select the desired state: <ul style="list-style-type: none"> • Disabled: to not isolate the Access Point i.e. authorise machines connected to the router to communicate with each other. • Enabled: to isolate the Access Point, i.e. prohibit machines connected to the router to communicate with each other. 	Not checked
Disable WMM Advertise		
Enable Wireless Multicast Forwarding (WMF)		
SSID	Enter your router's SSID. Note: This is indicated on the label stuck to the box.	SAGEM
BSSID	This is the MAC address of the router's Wi-Fi interface (Access Point). In the "Structure" mode, this address identifies a cell (BSS in English B asic S ervice S et). This cell is a set formed by the access point and the stations located in its coverage area. You cannot modify this setting.	[Non modifiable]
Country	Select the country of your choice from the scroll down list.	FRANCE
Max Clients	Maximum number of wireless customers for your router.	16

Note



The router may or may not be secured, at the request of the customer. This level of security is indicated on the label pasted to the box.

This choice will modify the Wireless configuration screen

5.8.2 Security

Object: The purpose of this menu is to secure your wireless network (Wi-Fi). All types of ingenious solutions have been deployed to combat attacks from hackers. Encryption modes have been implemented to secure your wireless network. Among these, two are commonly used:

- WEP (**W**ired **E**quivalent **P**rotocol),
- WPA (**W**i-**F**i **P**rotected **A**ccess) and its derivatives (WPA-PSK, WPA2 etc.).

The WPA encryption mode is the most robust and the best adapted to correctly securing your wireless network.

- In the **Wireless** menu, select **Security**.
The following screen opens:

The screenshot displays the SAGEM web interface for wireless security configuration. The main content area is titled "Wireless -- Security" and includes the following elements:

- Wireless -- Security**: This page allows you to configure security features of the wireless LAN interface. You may setup configuration manually OR through WiFi Protected Setup(WPS).
- WSEC Setup**:
 - Enable WSEC:
- Manual Setup AP**:
 - You can set the network authentication method, selecting data encryption, specify whether a network key is required to authenticate to this wireless network and specify the encryption strength. Click "Apply/Save" when done.
 - Select SSID:
 - Network Authentication:
 - WEP Encryption:
 -

The left sidebar contains navigation links: Device Info, Internet Connection, Advanced Setup, Wireless, Basic, Security (highlighted), MAC Filter, Advanced, Station Info, Diagnostics, and Management. The top right corner shows network status: ADSL (Down 19999 kbps, Up 1048 kbps) and Internet (Connected). A small image of a SAGEM wireless router is visible in the bottom right corner of the interface.

Field	Action/Meaning	Default value
Enable WSC	Check the box to activate WSC.	Disabled
Select SSID	Select the "SSID" of your choice from the scroll down list (sagem or Guest).	SAGEM
Network Authentication	<p>From the scroll down list, select the security adapted to your router's wireless network.</p> <p>The list suggests the following choices:</p> <ul style="list-style-type: none"> • Open: There is no protection for the wireless network (Open System) • Shared • 802.1x : Activation of the 802.1x standard • WPA: Activation of WPA (Wireless Protected Access) • WPA-PSK: Activation of WPA-PSK • WPA2: Activation of WPA2 • WPA2-PSK: Activation of WPA2-PSK • Mixed WPA2/WPA: Activation of Mixed WPA2/WPA • Mixed WPA2/WPA-PSK: Activation of Mixed WPA2/WPA-PSK <p>This choice will modify the Wireless configuration screen.</p>	Open
WEP Encryption	<p>Select from the scroll down list:</p> <ul style="list-style-type: none"> • Disabled to not use WEP encryption. • Enabled to use WE encryption (see subsection WEP). 	Disabled

5.8.2.1 Network Authentication

Note

The scroll down list in the **Network Authentication** field shows the following possible authentication types:



- Open
- Shared
- 802.1x
- WPA
- WPA-PSK
- WPA2
- WPA2-PSK
- Mixed WPA2/WPA
- Mixed WPA2/WPA-PSK

A different screen appears for each authentication type.

Open

Object: The **Open System** authentication enables all users of the Wi-Fi network to authenticate themselves with the router. No restrictions concerning security are demanded.

In this authentication mode, only the WEP key may be used to encrypt data.


The screenshot displays the SAGEM router's web interface for configuring wireless security. The main content area is titled 'Wireless -- Security' and provides instructions for manual setup. Under the 'Manual Setup AP' section, the 'Network Authentication' dropdown menu is open, showing the following options: Open, Shared, 802.1X, WPA, WPA-PSK, WPA2, WPA2-PSK, Mixed WPA2/WPA, and Mixed WPA2/WPA-PSK. The 'WEP Encryption' field is also visible below the dropdown. The interface includes a sidebar with navigation options like 'Device Info', 'Internet Connection', and 'Wireless Setup'. A status bar at the top right shows network speed (19999 kbps down, 1048 kbps up) and connection status (Internet Connected).

Shared

Object: This level of security enables users of the Wi-Fi network to be authenticated using their SSID or their WEP key.

In this authentication mode, the WEP key is used to encrypt data.

- Select the **Shared** security from the scroll down list; the following screen appears:



Field	Action/Meaning	Default value
WEP Encryption	This field is always active (Enabled).	Enabled
Encryption strength	Select 64-bit or 128-bit for an encryption at 64 bits or 128 bits respectively.	128-bit
Current network key	Select a key from the four suggested. The emission key is used to encrypt the data sent by your computer.	2
Network Key x (1 to 4)	The WEP key is customised for your router. You may modify the keys by entering them directly into the boxes. The characters are "0" to "9" and "A" to "F".	12345678901234

Important



Store the key phrase and the keys in a safe location.
Do not write them in a file on your computer.

Important



The "Key phrase" can consist of up to 15 alphanumeric characters.

To manually configure the encryption key, enter five hexadecimal pairs of digits for each 64-bit key, or enter 13 pairs for the single 128-bit key (A hexadecimal digit is a number or letter in the range 0-9 or A-F). Note that the WEP key protects data transmitted between wireless nodes, but does not protect any transmissions over your wired network (LAN) or over Internet (WAN) using Internet Explorer 5.0 or above.

802.1x

Object: The "802.1x" standard is based on the EAP protocol (Extensible Authentication Protocol). This enables users of the Wi-Fi network to be authenticated using a "RADIUS" authentication server (Remote Authentication Dial-in User Service).

In this case, the WEP key is used exclusively for data encryption.


- Select the security according to the **802.1x** protocol from the scroll down list; the following screen appears:

Field	Action/Meaning	Default value
RADIUS Server IP Address	Enter the IP address of the "RADIUS" authentication server.	0.0.0.0
RADIUS Port	Enter the port used for the "RADIUS" authentication server.	1812
RADIUS Key	Enter the secret key shared between the authentication server and its clients	-
WEP Encryption	This field is always active (Enabled).	Enabled
Encryption Strength	Select 64-bit or 128-bit for an encryption at 64 bits or 128 bits respectively.	128-bit
Current Network Key	Select key 2 or 3.	2
Network Key x (1 to 4)	1 This field is empty or displays the key value entered earlier (greyed out)	[Not modifiable]
	2 Enter the encryption on the key you selected in the "Current Key".	12345678901234
	3 Enter the encryption on the key you selected in the "Current Key".	12345678901234
	4 This field is empty or displays the key value entered earlier (greyed out)	[Not modifiable]

WPA

Object: This encryption mode applies the functionalities of the WPA protocol and requires the use of a "RADIUS" authentication server.

- Select the **WPA** security from the scroll down list; the following screen appears:




Field	Action/Meaning	Default value
WPA Group Rekey Interval	Enter a value (in seconds) which determines the period after which the WPA key will be regenerated (Renewing) in broadcast / multicast (LAN broadcast).	0
RADIUS Server IP Address	Enter the IP address of the "RADIUS" authentication server.	0.0.0.0
RADIUS Port	Enter the port used for the "RADIUS" authentication server.	1812
RADIUS Key	Enter the secret key shared between the authentication server and its clients	-
WPA Encryption	Select the WPA encryption required from the scroll down list: <ul style="list-style-type: none"> TKIP (Temporal Key Integration Protocol) AES (Advanced Encryption Standard) TKIP+ AES 	TKIP
WEP Encryption	Select from the scroll down list: <ul style="list-style-type: none"> Disabled to use WPA encryption only. Enabled to use both WPA and WEP encryption. 	Disabled

WPA-PSK

Object: This encryption mode applies the functionalities of the WPA protocol with a pre-shared key, but does not require an authentication server. The key is regenerated after a period which can be configured (**WPA Group Rekey Interval**).

- Select the **WPA-PSK** security from the scroll down list; the following screen appears:




Field	Action/Meaning	Default value
WPA Pre-Shared Key	Enter the secret shared key. This may contain 8 to 63 ASCII characters or 64 hexadecimal symbols (256 bits). Click on the Save/Apply button to validate the entry. Note: You may display your secret phrase by clicking on Click here to display .	-
WPA Group Rekey Interval	Enter a value (in seconds) which determines the period after which the WPA key will be regenerated (Renewing) in broadcast / multicast (LAN broadcast).	0
WPA Encryption	Select the WPA encryption required from the scroll down list: <ul style="list-style-type: none"> • TKIP (Temporal Key Integration Protocol) • AES (Advanced Encryption Standard) • TKIP+ AES 	TKIP
WEP Encryption	Select from the scroll down list: <ul style="list-style-type: none"> • Disabled to use WPA encryption only. • Enabled to use both WPA and WEP encryption. 	Disabled

WPA2

Object: This encryption mode applies the functionalities of the WPA2 protocol and requires the use of a "RADIUS" authentication server.

- Select the **WPA2** security from the scroll down list; the following screen appears:




Field	Action/Meaning	Default value
WPA2 Re-auth Interval	Enter a value (in seconds) which determines the period after which the WPA key will be certified.	36000
WPA Group Rekey Interval	Enter a value (in seconds) which determines the period after which the WPA key will be regenerated (Renewing) in broadcast / multicast (LAN broadcast).	0
RADIUS Server IP Address	Enter the IP address of the "RADIUS" authentication server.	0.0.0.0
RADIUS Port	Enter the port used by the "RADIUS" authentication server.	1812
RADIUS Key	Enter the secret key shared between the authentication server and its clients.	-
WPA Encryption	Select the WPA encryption required from the scroll down list: <ul style="list-style-type: none"> • TKIP (Temporal Key Integration Protocol) • AES (Advanced Encryption Standard) • TKIP+ AES 	AES
WEP Encryption	Select from the scroll down list: <ul style="list-style-type: none"> • Disabled to use WPA encryption only. • Enabled to use both WPA and WEP encryption. 	Disabled

WPA2-PSK

Object: This encryption mode uses the WPA2 protocol with a pre-shared key, but does not require an authentication server. The key is regenerated after a period which can be configured (**WPA Group Rekey Interval**).

- Select the **WPA2-PSK** security from the scroll down list; the following screen appears:




Field	Action/Meaning	Default value
WPA2 Pre-Shared Key	Enter a secret phrase. This may contain 8 to 63 ASCII characters or 64 hexadecimal symbols (256 bits). Click on the Save/Apply button to validate the entry. Note: You may display your secret phrase by clicking on Click here to display .	-
WPA Group Rekey Interval	Enter a value (in seconds) which determines the period after which the WPA key will be regenerated (Renewing) in broadcast / multicast (LAN broadcast).	0
WPA Encryption	Select the WPA encryption required from the scroll down list: <ul style="list-style-type: none"> • TKIP (Temporal Key Integration Protocol) • AES (Advanced Encryption Standard) • TKIP+ AES 	AES
WEP Encryption	Select from the scroll down list: <ul style="list-style-type: none"> • Disabled to use WPA encryption only. • Enabled to use both WPA and WEP encryption. 	Disabled

Mixed WPA2/WPA

Object: This encryption mode applies the functionalities of the WPA2 and WPA protocols. It needs a "RADIUS" authentication server.

- Select the **Mixed WPA2/WPA** security from the scroll down list; the following screen appears:




Field	Action/Meaning	Default value
Network Re-auth Interval	Enter a value (in seconds) which determines the period after which the WPA key will be certified.	36000
WPA Group Rekey Interval	Enter a value (in seconds) which determines the period after which the WPA key will be regenerated (Renewing) in broadcast / multicast (LAN broadcast).	0
RADIUS Server IP Address	Enter the IP address of the "RADIUS" authentication server.	0.0.0.0
RADIUS Port	Enter the port used by the "RADIUS" authentication server.	1812
RADIUS Key	Enter the secret key shared between the authentication server and its clients.	-
WPA Encryption	Select the WPA encryption required from the scroll down list: <ul style="list-style-type: none"> • TKIP (Temporal Key Integration Protocol) • AES (Advanced Encryption Standard) • TKIP+ AES 	TKIP+ AES
WEP Encryption	Select from the scroll down list: <ul style="list-style-type: none"> • Disabled to use WPA encryption only. • Enabled to use both WPA and WEP encryption. 	Disabled

Mixed WPA2/WPA-PSK

Object: This encryption mode applies the functionalities of the WPA2-PSK and WPA-PSK protocols. It does not need a "RADIUS" authentication server.

- Select the **Mixed WPA2 /WPA-PSK** security from the scroll down list; the following screen appears:



Field	Action/Meaning	Default value
WPA2 Pre-Shared Key	Enter a secret phrase. This may contain 8 to 63 ASCII characters or 64 hexadecimal symbols (256 bits). Click on the Save/Apply button to validate the entry. Note: You may display your secret phrase by clicking on Click here to display .	-
WPA Group Rekey Interval	Enter a value (in seconds) which determines the period after which the WPA key will be regenerated (Renewing) in broadcast / multicast (LAN broadcast).	0
WPA Encryption	Select the WPA encryption required from the scroll down list: <ul style="list-style-type: none"> • TKIP (Temporal Key Integration Protocol) • AES (Advanced Encryption Standard) • TKIP+ AES 	TKIP+ AES
WEP Encryption	Select from the scroll down list: <ul style="list-style-type: none"> • Disabled to use WPA encryption only. • Enabled to use both WPA and WEP encryption. 	Disabled

5.8.3 MAC Filter

Object: The "MAC Filter" function is used to limit the number of computers which can access your wireless network.


- In the **Wireless** menu, select **MAC Filter**.
The following screen opens:



Field	Action/Meaning	Default value
MAC Restrict Mode	Select the command by checking the appropriate box: <ul style="list-style-type: none"> • Disabled: Deactivates the MAC filtering • Allow: Enables computers whose MAC address is in the list to use your wireless network • Denied: Refuses computers whose MAC address is in the list to use your wireless network. 	Disabled

Add

- Click on the **Add** button to add a MAC address to be filtered (address of a computer authorised to connect to a wireless network).



Note




The MAC address can be added automatically at the time of the Wi-Fi installation, by a short push on button "WLAN/WPS".

After approximately 5 minutes, the new address fits in the list and the router passes in mode of filtering (MAC Restrict Mode) "Allow" to authorize only the computers whose MAC address appears in the list to be connected to your router.

5.8.4 Advanced

Object: This menu is used to configure the essential parameters of your wireless network (WLAN) 802.11 and configure certain security parameters.

- In the **Wireless** menu, select **Advanced**.
The following screen opens:



Important



The table below indicates in more detail how to access your Wi-Fi port (or Access Point).

Nevertheless, it is best to leave the default values for easier usage.

Field	Action/Meaning	Default value
Band	Select the 2.4 GHz band for the IEEE 802.11g standard.	2.4GHZ
Channel	<p>This is the radio channel used by the router and its Wi-Fi clients to communicate with each other. This channel must be the same for the router and all its Wi-Fi clients.</p> <p>Select the channel you want from the scroll down list (auto, channels 1 to 13).</p> <p>Note: Channel 11 corresponds to frequency 2462 MHz.</p> <p>Note: If you select "Auto", the Wi-Fi equipment will select the access point channel (router) which will emit the strongest signal.</p> <p>Conform to the CE Declaration of conformity / Radio rules list in appendix B to paragraph B.2.</p>	Auto


Field	Action	Default value
Auto Channel Timer (min)	Configure the duration, in minutes, during which the router must seek the best wireless channel. This option is only available when the selection of the channel is configured in Auto (Automatic).	0
54g™ Rate	In the scroll down list, select the transmission rate at which the information (data or video) will be transmitted or received on your wireless network (Auto, 1, 2, 5.5, 6, 9, 11, 12, 18, 24, 36, 48 or 54 Mbps). Note: If you select "Auto", the information will be transmitted at an optimised rate which takes account of the transmission constraints.	Auto
Multicast Rate	From the scroll down list, select the transmission rate at which the "Multicast" packets are transmitted (Auto, 1, 2, 5.5, 6, 9, 11, 12, 18, 24, 36, 48 or 54 Mbps). Note: If you select "Auto", the information will be transmitted at an optimised rate which takes account of the transmission constraints. Video conferencing and teleconferencing are "Multicast" applications.	Auto
Basic Rate	From the scroll down list, select the basic rate at which the information will be transmitted or received over your wireless network (Default, All, 1 & 2 Mbps or 1 & 2 & 5.5 & 6 & 11 & 12 & 24 Mbps).	Default
Fragmentation threshold	This packet fragmentation mechanism is used to limit errors and repetitions. It is recommended not to reduce the packet size too much to avoid reducing the bandwidth. Enter a threshold value (in bytes) between 256 and 2347.	2346
RTS Threshold	The RTS/CTS protocol (Request To Send / Clear To Send) is used to reduce the probability of collisions between stations. Note: As packet size is set by default to 2346, the RTS/CTS protocol is inhibited as its value is set by default to 2347. Enter a threshold value (in bytes) between 1 and 2347.	2347
DTIM Interval	Enter a time interval value between two beacon signals which shows the activity of the wireless.	100
Global Max Clients	Enter the maximum number wireless customers for your router.	16
XPress™ Technology	From the scroll down list, select Enabled to apply the "XPress™" technology or Disabled to not apply it.	Disabled
54g™ Mode	In the scroll down list, select (54g Auto, 54g Performance, 54g LRS or 802.11b Only).	54g Auto
54g Protection	Select Auto to improve the quality in the mixed 802.11 environments (g and b for example) or Off to improve the quality only on the 802.11g environments but degrade it on other environments (802.11b for example).	Auto

Field	Action/Meaning	Default value
<p>Preamble Type</p>	<p>In the IEEE 802.11 standard, the "preamble" is used to synchronise the Emitter and Receiver correctly. The "long preamble" is generally commonly used. For reasons of bandwidth gain, this standard proposes reducing the length of the "preamble".</p> <p>"Preamble Type" defines the length of block CRC (Cyclical Redundancy Checking).</p> <p>If your network does not include any peripheral 802.11b, you can configure the type of preamble on short for an optimal result.</p> <p>The type of preamble long must be used if the peripherals 802.11g and 802.11b are both present on the network.</p> <p>In the scroll down list, select long to keep a 128 bit "preamble" or short to reduce it to 56 bits.</p>	<p>long</p>
<p>Transmit Power</p>	<p>If 802.11 h is selected, in the scroll down list select the cyclical emission ratio (20%, 40 %, 60 %, 80 % or 100 %) at which you want to transmit.</p> <p>Note: The power rate will be selected according to your environment.</p>	<p>100%</p>

5.8.5 Station Info

Object: This menu is used to display all the wireless stations certified, with their status.

- In the **Wireless** menu, select **Station Info**.
The following screen opens:



- Click on the **Refresh** button to refresh the screen.

Note



Only appear the MAC addresses (BSSIDs) of the computers associated with the router and/or authorized by this one to use your wireless network (see subsection 5.8.3 - MAC Filter).

5.9 Diagnostics

Object: This menu is used to display all the tests performed on the connections made from your router to your Internet Service Provider (ISP). These tests concern:

- connection to your local network (LAN),
- connection to your "DSL Service Provider",
- connection to your "Internet Service Provider".

Note



A hypertext link (help) enables the user to access context-related help. This help gives an explanation concerning the state of the connection (**PASS** in green, **DOWN** in orange and **FAIL** in red) and supplies the appropriate troubleshooting procedures.

The ADSL line translates the three statuses detailed in the table below.

State	Meaning
PASS	Indicates that the test was completed successfully.
DOWN	Indicates that an interface (ETH, Wi-Fi) has not been detected.
FAIL	Indicates that the test has failed, or that it is impossible to start a command.

If a test fails, proceed as follows:

1. Click on the corresponding **Help** link to access detailed information and problem-solving procedures.
2. Click on **Test** to check the problem is solved and resume the connection tests.

To access the Diagnostic tool:

- Select the **Diagnostics** menu.

The screenshot shows the SAGEM router's diagnostic page. At the top right, there are status indicators for ADSL (Down, 23162 kbps) and Internet (Connected, 1019 kbps). The main content area is titled "pppoe_0_8_35 Diagnostics" and contains the following information:

Your modem is capable of testing your DSL connection. The individual tests are listed below. If a test displays a fail status, click "Rerun Diagnostic Tests" at the bottom of this page to make sure the fail status is consistent. If the test continues to fail, click "Help" and follow the troubleshooting procedures.

Test the connection to your local network

Test your ENET(1-4) Connection:	PASS	Help
Test your Wireless Connection:	PASS	Help

Test the connection to your DSL service provider

Test ADSL Synchronization:	PASS	Help
Test ATM OAM F5 segment ping:	PASS	Help
Test ATM OAM F5 end-to-end ping:	FAIL	Help

Test the connection to your Internet service provider

Test PPP server session:	PASS	Help
Test authentication with ISP:	PASS	Help
Test the assigned IP address:	PASS	Help
Ping default gateway:	PASS	Help
Ping primary Domain Name Server:	FAIL	Help

Buttons for "Test" and "Test With OAM F4" are located at the bottom of the diagnostic area.

5.10 Management

Object: This menu lets you manage your router.

This section contains the following seven menus:

- Settings (see subsection 5.10.1)
- System Log (see subsection 5.10.2)
- TR-069 Client (see subsection 5.10.3)
- Internet Time (see subsection 5.10.4)
- Access Control (see subsection 5.10.5)
- Update Software (see subsection 5.10.6)
- Reboot (see subsection 5.10.7)

5.10.1 Settings

This menu contains the following three sub menus:

- Backup (see subsection 5.10.1.1)
- Update (see subsection 5.10.1.2)
- Restore Default (see subsection 5.10.1.3)

5.10.1.1 Backup


Object: This menu is used to backup the current configuration to a file with a .conf extension.

Important




It is recommended to save the current configuration on your computer to a file.

- In the **Management** menu, select **Settings** then **Backup**. The following screen opens:



- Click on the **Backup Settings** button; the following screen appears:



Save

- Click on the **Save** button to save the current configuration file, for example, on your computer.
- Select the directory where you want to save the "backupsettings.conf" configuration file.

Note




The process takes a few seconds.

5.10.1.2 Update

Object: This menu enables the router to recover a configuration which has already been saved to a file with a .conf extension.

- In the **Management** menu, select **Settings** then **Update**.
The following screen opens:



Proceed as follows for your router configurator to display a configuration which has already been saved:

- Enter the path then the name of the configuration file.
- or
- Click on the **Browse** button and select the path then the configuration file.
- Select the configuration file then click on the **Update Settings** button to recover a configuration which has already been saved.

Note



The process takes around 2 minutes.

5.10.1.3 Restore Default


Object: This menu is used to return to factory configuration.

Important




The existing configuration is completely overwritten.

- In the **Management** menu, select **Settings** then **Restore Default**. The following screen opens:



- Click on the **Restore Default Settings** button; the following screen appears:



- Click on the **OK** button if you really want to return to the factory configuration.

Note




All the LEDs go off except for the green “WLAN” - if the wired network is activated; the green POWER LED then all the LEDs and the process for returning to the factory configuration starts. It lasts for around 2 minutes.

Once the restore performed, the **Internet Connection** menu appears. Refer to paragraph 5.6.

5.10.2 System Log

Object: This menu is used to view and/or configure the events which occur on your router.

- In the **Management** menu, select **System Log**.
The following screen opens:




5.10.2.1 View System Log

- Click on the **View System Log** button to display the events with the severity you configured (see table in section **Configure System Log**).

System Log			
Date/Time	Facility	Severity	Message
Jan 1 00:00:27	daemon	crit	pppd[485]: PPP session established.
Jan 1 00:00:31	daemon	crit	pppd[485]: PPP LCP UP.
Jan 1 00:00:42	daemon	crit	pppd[485]: Received valid IP address from server. Connection UP.
Jan 1 00:00:47	daemon	err	user: tr69c: Unable to retrieve attributes in scratch PAD
Jan 1 00:00:47	daemon	err	user: Stored Parameter Attribute data is corrupt or missing
Jan 1 00:00:48	daemon	err	user: tr69c: Unable to read tr69c acs state data from scratch pad

5.10.2.2 Configure System Log

- Click on the **Configure System Log** button to configure the events which occur on your router.



Field	Action	Default value
Log	Select Enable to activate the saving of all the events to a log and display on screen or Disable to deactivate.	Disable
Log Level	Select the appropriate severity from the scroll down list. All the events with this severity, or a higher severity, will be saved to your router's volatile "flash" memory. The severities are classified in decreasing order of importance. <ul style="list-style-type: none"> Emergency Alert Critical Error Warning Notice Informational Debugging 	Debugging
Display Level	Select the appropriate severity from the scroll down list. All the events with this severity, or a higher severity, can be viewed by pressing the View System Log button. The displayed events are classified in decreasing order of importance.	Error


Field	Action	Default value
Mode	Select the destination ID from the scroll down list: <ul style="list-style-type: none"> • Local: All the events are returned to your router via a "Buffer" memory. • Remote: All the events are returned to the "Syslog" server. • Both : Both modes. 	Local
Server IP Address¹⁷	Enter the IP address of the "Syslog" address on which all the events will be saved.	0.0.0.0
Server UDP Port¹⁷	Enter the number of the port associated with the "Syslog" server.	514

¹⁷ These fields only appear when the mode selected is "Remote or "Both".

5.10.3 TR-069 Client

Object: The TR-069 protocol (WAN Management Protocol) is used, via a remote server (Auto-Configuration Server (ACS)) to auto configure your router, provide it with certain services and manage it by establishing "diagnostics".

- In the **Management** menu, select **TR-069 Client**.
The following screen opens:



Field	Action	Default value
Inform	Check the Enable box to activate the "TR-069" or Disable to deactivate it.	Disable
Inform Interval	Enter a time interval between two pieces of information sent from the router to the ACS server. This interval is a value (in seconds).	300
ACS URL	Enter the URL or the IP address of the "ACS" server.	-
ACS User Name	Enter the name of the user of the "ACS" server.	admin
ACS Password	Enter the "ACS" server password.	admin
WAN Interface used by TR-069 client	Select in the scroll down list the desired WAN interface.	Any_WAN
Display SOAP Messages on serial console	Check the Enable box to activate it or Disable to deactivate it.	Disable
Connection Request Authentication	Check the box to activate authentication or uncheck it to deactivate it.	Checked
Connection Request User Name	Enter the name of the user of your router.	admin
Connection Request Password	Enter your password for your router.	admin

- Click on the **Get RPCMethods** button to launch the auto-configuration procedure of your router.

5.10.4 Internet Time

Object: This menu lets you display the date and time in the **Date / Time** field of your HTTP configurer:

- either the one delivered by your router. The date and time when the router starts are set to: "Jan 1 / 00:00:00" (i.e. 1st January at 0 am).
- or the one delivered automatically by an Internet time server.
- In the **Management** menu, select **Internet Time**.
The following screen opens:



Field	Action	Default value
Automatically Synchronise with Internet time servers	<ul style="list-style-type: none"> • Uncheck the box so that the Date / Time field (which appears, for example in the "Management/System Log" screens) displays the date and time delivered by your router, <p>or</p> <ul style="list-style-type: none"> • Check the appropriate box so that the Date / Time field (which appears, for example, in the "Device Info/Summary" and "Management/System Log" screen) displays the date and time delivered by the NTP servers (Network Time Protocol) you selected. These servers display the date and time GMT (Greenwich Mean Time). <p>Note: For these events to be displayed and/or saved at an effective date and time, you should check this box.</p>	Not checked
First NTP time server	Select a first NTP server from the scroll down list.	Time.nist.gov
Second NTP time server	Select a second NTP server from the scroll down list.	ntp1.tummy.com
X NTP time server (third to fifth)	Select a NTP server from the scroll down list.	None
Time zone offset	In the scroll down list, select the appropriate correction (GMT+1 - Paris for example) to adjust the GMT time to that of the country where you live with the seasonal correction (Summer time or Winter time).	(GMT-08:00) Pacific Time, Tijuana


5.10.5 Access Control

This menu contains the following three sub menus:

- Passwords (see subsection 5.10.5.1).

5.10.5.1 Passwords

- In the **Management** menu, select **Access Control** then **Passwords**. The following screen opens:



Field	Action
User Name	Select a user name from the scroll down list: <ul style="list-style-type: none"> • Admin • Support • User Note: This list is established in increasing order of restriction.
Old Password	Enter your old password
New Password	Enter your new password
Confirm Password	Confirm your new password

Note




The password is a string of a maximum of 16 alphanumerical characters.

5.10.6 Update Software

Object: This menu lets you update the latest version of the router software.

- In the **Management** menu, select **Update Software**.
The following screen opens:



Proceed as follows to update your router's software version:

- Enter the path then the name of the software version file,
or
- Click on the **Browse** button and select the path then the software version file,
- Click on the **Update Software** button to update the software version.

Note



The process takes around 2 minutes.

The application of a new software version for the router does not modify the current configuration at all.

Important




Throughout the download procedure (up to five minutes), you must:

- not power down the router
- not disconnect from the ADSL line.

5.10.7 Reboot

Object: This menu lets you save all the modifications made to the current configuration and restart the router with its new parameters.

- In the **Management** menu, select **Reboot**.
The following screen opens:



Click on the **Reboot** button to restart the router.

Note



The process takes around 1 minute.

A countdown is displayed to tell the user how long is left to wait.

6. Internet access service


This section covers	➤ description of the Internet access service	P6-2
---------------------	--	------

6 - Internet access service

The router has been designed to enable you to access the Internet as simply as possible.

Most of the router's parameters are already set:

- It is configured by default as a DHCP server.
- It relays DNS queries from the local network to the Internet.



Using your installation CD-ROM you can quickly obtain Internet access.

Depending on your contract with your **Internet Service Provider (ISP)**, you can also have access to television on ADSL (see section 8).

The configuration parameters of your router are entered during installation (connection identifier, connection password). These parameters can also be entered or modified in the **Internet connection** menu of the HTTP configuration tool (PPP Username, PPP Password).

Observations

If the terminals are not DHCP clients, your local network then uses a static addressing plan.

Check that:

- the router belongs to this addressing plan,
- the default gateway of the equipment in the local network matches the address of your router,
- the DNS addresses are correctly configured in each terminal. The router enables DNS queries to be relayed.

7. TV over ADSL service

This section covers	➤ the introduction	§ 7.1
	➤ access to the optional TV over ADSL service	§ 7.2

7.1 Introduction

Your router is compatible with TV over ADSL technology.

7.2 Access to the optional TV over ADSL service

To access this service, you must have:

- made the connection in accordance with section 2.3.4,
- necessarily taken a subscription with your **Internet Service Provider (ISP)**
- configured one VC (**V**irtual **C**hannel) dedicated to video, and another VC dedicated to data (see screen below)

VPI/VCI	Con. ID	Category	Service	Interface	Protocol	Icmp	QoS	State	Remove	Edit
8/35	1	UBR	pppoe_8_35_1	ppp_8_35_1	PPPoE	Disabled	Enabled	Enabled	<input type="checkbox"/>	Edit
8/50	1	UBR	br_8_50	nas_8_50	Bridge	N/A	Disabled	Enabled	<input type="checkbox"/>	Edit

Note



In the example above, the ATM interface "ppp_8_35_1" is dedicated to data and the ATM interface "nas_8_50_1" is dedicated to video.

- configured accordingly "Port Mapping" in **Advanced Setup** (see section 5).

8. Updating the firmware

This section covers	➤ setting up the download.	P8-2
---------------------	----------------------------	------

8 - Updating the application

You can update the firmware using one of the following methods:

- via HTTP
- via TR69 protocol
- automatically: the new firmware version download is performed automatically on starting up the router.

Important



Throughout the download procedure (up to five minutes), **you must**:

- not power down the router,
- not disconnect from the ADSL line.

During the download, all the LEDs of your **router** light in turn except the  LED that stays on steady.

When the download is finished, your **router** restarts automatically to the new firmware version.

Note



To check that the new version has been correctly downloaded, select in the HTTP configuration tool the **Device info** menu; the **Software version** field displays the last software version installed.

HTTP update

You can download the new firmware to update your router using the **Management** menu in the HTTP configuration tool (see section 5).

TR69 protocol

Operators can use "TR69" protocol to upgrade the router's firmware from an HTTP or FTP server.

A. Annex A - Troubleshooting

This section covers	➤ checking the assignment of an IP address	§ A.1
	➤ Front panel LEDs	§ A.2
	➤ Supervision of your router	§ A.3
	➤ the "Diagnostics" tool	§ A.4
	➤ interpreting the lights	§ A.5
	➤ reinitialising your router	§ A.6
	➤ resetting factory configuration	§ A.7
	➤ Offline connection mode	§ A.8

A.1 Checking the assignment of an IP address

In Windows Vista, XP, 2000 and ME

1. Click on **Start > Run**, enter **cmd** and then click **OK**.
The command prompt screen appears.
2. Enter **ipconfig** then press **Enter**.
3. Check that the entry IP Address contains a value other than **0.0.0.0** (for example **192.168.1.10**).

Note



If no IP address is displayed, enter **ipconfig /release** then enter **ipconfig /renew**.

Note



All the troubleshooting procedures described below are undertaken in **Windows® XP**. These procedures in other Windows operating systems® (98, ME and 2000) can be slightly different.

Many sources of information are available to help you identify and resolve issues you may experience:

- the LEDs on the front panel of the router.
- the HTTP configuration tool.


For step-by-step and advanced problem-solving procedures, use the **Diagnostic tool** available in the HTTP configuration tool.





A.2 Front panel LEDs

Note



When the router is switched on, the  LED is green.


If no connection is made, the  LED is red.

LED	Status	Meaning
 Power	Off	Power Off
	Green	Power On
	Red	Router in rescue mode
 ADSL	Off	ADSL Down
	Green steady	ADSL Up
	Green blinking	ADSL Synchronisation in progress
 Internet	Off	<ul style="list-style-type: none"> • Power Off or <ul style="list-style-type: none"> • The Internet account must be configured
	Green steady	<ul style="list-style-type: none"> • The Internet account is configured or <ul style="list-style-type: none"> • Bridge mode
	Green blinking	Tx/Rx traffic
	Red	Invalid or unauthorised Internet account
LAN x (1 to 4)	Off	No link detected on the Ethernet port
	Green steady	Ethernet port has detected a link with 100 Mbps device
	Green blinking	Tx/Rx traffic at 100 Mbps
 WLAN	Off	Wi-Fi deactivated
	Green steady	Wi-Fi activated
	Green blinking	Wi-Fi Tx/Rx

A.3 Supervising your router

You can monitor the router’s activity and status using the router’s built-in “DSL Router” HTTP controller, available in the HTTP configuration tool.

The router’s activity status is always visible at the top right corner of the HTTP configuration tool.



You can perform the following actions:

- click on **Refresh** to update the data displayed
- click on **Reboot** to restart your router

ADSL information

The following table presents the possible states of the **ADSL** field:

Status	Meaning
Green	ADSL line synchronised
Yellow	ADSL line synchronising
Red	ADSL line not connected

The **Down** field displays the nominal downlink bit rate.

The **Up** field displays the nominal uplink bit rate.

Internet information

The following table presents the possible states of the **Internet** field:

Status	Status	Meaning
Off	ADSL Down	ADSL line not connected or not activated
	Not configured	The Internet account must be configured
	Router rebooting	Router is rebooting
Green	Connected	The Internet account is configured
Yellow	Waiting for ISP	ADSL line synchronising
Red	Access denied	Incorrect Internet account

A.4 Diagnostics tool

To access the Diagnostic tool:

1. Open your browser.
2. Enter the router's IP address or enter the following URL: `http://myrouter`.
3. In the login screen that appears, enter your username and password.
Default values are:
 - User name: **admin**
 - Password: **admin**
4. The welcome page of the HTTP configuration tool appears.
5. Select the **Diagnostics** menu.

SAGEM

ADSL ● Down 23162 kbps Up 1019 kbps refresh
Internet ● Connected. reboot

pppoe_0_8_35 Diagnostics

Your modem is capable of testing your DSL connection. The individual tests are listed below. If a test displays a fail status, click "Rerun Diagnostic Tests" at the bottom of this page to make sure the fail status is consistent. If the test continues to fail, click "Help" and follow the troubleshooting procedures.

Test the connection to your local network

Test your ENET(1-4) Connection:	PASS	Help
Test your Wireless Connection:	PASS	Help

Test the connection to your DSL service provider

Test ADSL Synchronization:	PASS	Help
Test ATM OAM F5 segment ping:	PASS	Help
Test ATM OAM F5 end-to-end ping:	FAIL	Help

Test the connection to your Internet service provider

Test PPP server session:	PASS	Help
Test authentication with ISP:	PASS	Help
Test the assigned IP address:	PASS	Help
Ping default gateway:	PASS	Help
Ping primary Domain Name Server:	FAIL	Help

Test Test With OAM F4

SAGEM

6. Click on **Test**. The connections to the LAN, to your DSL Service Provider and to your Internet Service Provider are tested step-by-step:
 - successful tests are marked as a pass.
 - unsuccessful tests are marked as a fail.

Note



Status **DOWN** means that an interface was not detected (LAN or Wi-Fi).

Note



FAIL test

Depending on the nature of the test, it is possible that operation of the router or access to the Internet may not be prejudiced. For example if you do a "Ping" either to an ATM OAM F5 segment or to a DNS primary address.

7. If a test fails, click on the corresponding **Help** link to access detailed information and problem-solving procedures.
8. Click on **Test** to check the problem is solved and resume the connection tests.

If none of the above helps you solve the problem, and you are still having trouble connecting to the Internet, we recommend that you restart your router (cf.A.6) and eventually reset the factory configuration (cf. § A.7). You will then need to re-configure your router as a first-time setup.

A.5 Interpreting the LEDs

A.5.1 The "ADSL" LED blinks slowly

1. Check the connection of your ADSL filters. Each telephone socket of your installation which is used must be equipped with an ADSL filter.
2. Check that the RJ11 type line cord delivered with your router is connected to one of your sockets. It is recommended that no telephone extension is used.
3. Finally, check with your ISP that the ADSL service is available on your telephone line.

A.5.2 "Wi-Fi" LED off

If this LED is off, this indicates that the WLAN interface of the router is not active.

To activate the wireless network, access the HTTP configuration tool and check the box "Enable Wireless" in the **Wireless** menu (see section 5).

A.5.3 All LEDs are off

1. Check that the type of power available in your premises is compatible with the mains voltage required for powering your router.
2. Check that the delivered power cord is properly connected at one end to the mains power network.
3. Check that the power connector is inserted correctly in the corresponding connector (power) of the router.






A.6 Restarting your router

We recommend that you restart your router if you notice that the router does not operate properly:

To restart your router, use one of the following methods:

- Press the **Power** button located on the rear panel of the router. Press it again to switch it back on.
- Click on the **Reboot** action of the HTTP configuration tool.

During restarting, the status of the LEDs is the following:

The  LED will light up first, followed by the four Ethernet LEDs (1 to 4), then these last four LEDs will be off. The  and Ethernet (which corresponds to the connected interface) LEDs should be steady and the  LED blinks during the establishment of the ADSL link, then steadies like the  LED. The  LED should be steady and turn from "Red" to "Green" when a PPP session has been created.

Note



The powering up process lasts around one minute.

A.7 Resetting factory configuration

If you lose your password or if, after having entered new parameters in your router, you cannot access the Internet nor the HTTP configuration tool, you can restore the normal operation with the "factory" parameters via the **Restore Default** procedure.

When the procedure is finished you will have to enter again your connection ID and connection password delivered by your Internet Service Provider (see Internet Connection – section 5.6)

To reset the default settings and therefore restore the router to its factory configuration, use one of the following methods:

Important



This operation deletes the entire personalised configuration of your router: Password, Configuration, etc.

After a factory configuration reset, it is **necessary to install your router again** using the installation CD-ROM, or to enter again the ADSL connection data supplied by your Internet Service Provider (ISP) (see Internet Connection section 5.6).

- Press and hold for about 10 seconds the **Reset** button located on the rear panel of the router.
- In the HTTP configuration tool, select **Management > Settings > Restore default**.

A.8 Offline mode

To start configuring the router in HTTP mode, the browser opens, the default IP address of the router's LAN interface appears in the browser's Address field **but the home screen does not appear**.

The screen opposite appears.

Click 



The screen opposite appears.

Click 



The screen opposite appears.

Select the **Connections** tab and then the **Never dial a connection**¹.

Click  to confirm your choice.



In the menu bar, select the **File** menu then deselect the **Work Offline** command.

Click **OK** in the browser's **Address** field to display the home screen.

¹ When the router is installed, this box is checked.

B. Annex B - Warnings for safety

This section covers	➤ Warnings for safety	§ B.1
	➤ the EC compliance declaration	§ B.2

B.1 Warnings for safety

The router is in compliance with standard EN 60950 Ed December 2001.
The safety levels in the sense of this standard are as follows:

B.1.1 Safety levels in relation to the case

Connecteurs	Position	Safety level
Adaptator	Primary Power Supply port	HPV ¹
PWR	DC Power Supply port	SELV ²
LINE	ADSL port	TNV3 ³
LAN1 to LAN4	Ethernet port	SELV ²

B.2 EC compliance declaration



The CE marking certifies that the product complies with the essential requirements of the Directive 1999/5/EC concerning radio equipment and telecommunication equipment, and of Directives 2006/95/EC concerning safety and 2004/108/EC concerning electromagnetic compatibility, defined by the European Parliament and Council to reduce electromagnetic interferences and protect the health and safety of users.

The product named SAGEM F@st™ 1704 can be operated in the European Union without restrictions indoor but cannot be operated in France in the whole of the band until further notice.

The CE declaration of conformity can be viewed in the support section of the Sagem Communications site www.sagem-communications.com, or it can be obtained from the following address:

Sagem Communications SAS - Customer relations department
250, Route de l'Empereur
92500 RUEIL MALMAISON - FRANCE

¹ Hazardous Primary Voltage circuit

² Safety Extra Low Voltage Circuit

³ Level 3 Telecommunication Network Voltage

C. Annex C - Environment

This section covers	➤ directive E 2002/96/CE	§ C.1
---------------------	--------------------------	-------

C.1 Directive E 2002/96/CE

ENVIRONMENT

Preservation of the environment as part of a sustainable development logic is an essential concern of **Sagem Communications SAS**.

Sagem Communications SAS' aim is to operate systems safeguarding the environment and consequently it has decided to integrate environmental performance considerations in the life cycle of its products, from manufacturing to commissioning, use and disposal.



PACKAGING

The presence of the logo (green dot) means that a contribution is paid to an approved national organization to improve packaging recovery and recycling infrastructures.

To facilitate recycling, please respect the sorting rules set up locally for this kind of waste.

BATTERIES

If your product contains batteries, they must be disposed of at appropriate collection points.



THE PRODUCT

The crossed-out waste bin marked on the product or its accessories means that the product belongs to the family of electrical and electronic equipment.

In this respect, the European regulations require you to dispose of it selectively:

- At sales points on purchasing similar equipment,
- At the collection points made available to you locally (drop-off center, selective collection, etc.).





In this way, you can participate in the re-use and upgrading of **Electrical Electronic Equipment Waste**, which can have an effect on the environment and health.

D. Annex D - Technical Characteristics

This section covers	➤ mechanics and displays	§ D.1
	➤ the characteristics of the different interfaces	§ D.2
	➤ environmental characteristics	§ D.3
	➤ the application and the protocols	§ D.4

D.1 Mechanics; Display

Mechanical characteristics	
Dimensions (mm)	• Width : 164 mm
	• Depth : 135 mm
	• Thickness : 34.8 mm
Weight of router	: 268 g

Display		
Marking	Abbreviation	Meaning
	PWR	• Green Power LED
	ADSL	• Green ADSL LED
	Wi-Fi	• Green WLAN LED
	Internet	• Green/Red Internet LED

D.2 Characteristics of the different interfaces

ADSL / ADSL2 / ADSL2+ Interface	
Standards supported	<ul style="list-style-type: none"> G.992.1 (ADSL), G.992.3 (ADSL2), G.992.5 (ADSL2+), G.994.1 (G.Handshake)
Transmission Code	<ul style="list-style-type: none"> DMT
Maximum upward transmission rate	<ul style="list-style-type: none"> 24,5 Mbit/s
Maximum downward transmission rate	<ul style="list-style-type: none"> 1,3 Mbit/s
Latence	<ul style="list-style-type: none"> Simple (Fast or interleaved)
TX Power	<ul style="list-style-type: none"> 12,5 dB
Access Impedance	<ul style="list-style-type: none"> 100 Ω
Range	<ul style="list-style-type: none"> According to standard G.992.1 table Annexe G
Connection technology	<ul style="list-style-type: none"> RJ11

Interface LAN Ethernet	
Rate	<ul style="list-style-type: none"> 10 Mbit/s or 100 Mbit/s, self-configurable
	<ul style="list-style-type: none"> Half / Full Duplex
Standard	<ul style="list-style-type: none"> IEEE 802.3
Connection technology	<ul style="list-style-type: none"> RJ45 Type MDI or MDI-x self-detecting port Crossed or straight cord

Wireless Interface	
Standard	<ul style="list-style-type: none"> • IEEE 802.11b DSSS
Frequencies band	<ul style="list-style-type: none"> • 2412 MHz to 2472 MHz (ISM band)
Transmission rate	<ul style="list-style-type: none"> • 1/2/5.5/11 Mbit/s
Modulation method	<ul style="list-style-type: none"> • DBPSK, DQPSK, CCK
Safety	<ul style="list-style-type: none"> • WEP 64 / 128 bits
	<ul style="list-style-type: none"> • Filtering by list of MAC addresses
	<ul style="list-style-type: none"> • WPA (encryption mode: TKIP or AES)
Range	<ul style="list-style-type: none"> • Up to 300 m in free space
	<ul style="list-style-type: none"> • 10 to 100 m inside buildings
Standard	<ul style="list-style-type: none"> • IEEE 802.11g OFDM
Frequencies band	<ul style="list-style-type: none"> • 2412 MHz to 2472 MHz (ISM band)
Transmission rate	<ul style="list-style-type: none"> • 6 / 9 / 12 / 18 / 24 / 36 / 48 / 54 Mbit/s
Modulation method	<ul style="list-style-type: none"> • OFDM, CCK
Safety	<ul style="list-style-type: none"> • WEP 64 / 128 bits
	<ul style="list-style-type: none"> • Filtering by list of MAC addresses
	<ul style="list-style-type: none"> • WPA (encryption mode: TKIP or AES)
Range	<ul style="list-style-type: none"> • 200 m in free space
	<ul style="list-style-type: none"> • 30 m inside buildings

Mains Power Supply	
Type	<ul style="list-style-type: none"> • Plug-in external adapter unit
Class	<ul style="list-style-type: none"> • II
Input voltage	<ul style="list-style-type: none"> • 100 to 240 V, 50 Hz / 60 Hz
Power absorbed	<ul style="list-style-type: none"> • < 9 W
Output voltage	<ul style="list-style-type: none"> • 12 V
Mains Connection technology	<ul style="list-style-type: none"> • Europlug type A socket
Use Connection technology	<ul style="list-style-type: none"> • Cord 2 m + jack diam. 3.5 mm

DC Power Supply Input of router	
Input Voltage	<ul style="list-style-type: none"> • 11 V - 13 V
Power absorbed	<ul style="list-style-type: none"> • < 7 W
Connection technology	<ul style="list-style-type: none"> • Miniature jack fixed connector diam. 3.5 mm

D.3 Environmental characteristics

Climatic and mechanical environment	
Storage	<ul style="list-style-type: none"> • ETS 300 019-1-1 Category T1.2
Transport	<ul style="list-style-type: none"> • ETS 300 019-1-2 Category T2.3
Operation	<ul style="list-style-type: none"> • ETS 300 019-1-3 Category T3.2 Temperature : -5°C / +45°C
Electrical robustness	
Standard	<ul style="list-style-type: none"> • UIT-T K21 Ed 2000 : basic level
Electromagnetic compatibility	
Transmission	<ul style="list-style-type: none"> • EN 55022 (January 1999) Class B
Harmonic currents	<ul style="list-style-type: none"> • EN 61000-3-2
Flicker and fluctuations of voltage	<ul style="list-style-type: none"> • EN 61000-3-3
Immunity	<ul style="list-style-type: none"> • EN 55024
Radio part for pour ISM band at 2.4 GHz	
Transmission 802.11g/b	<ul style="list-style-type: none"> • ETR 300 328-2 Ed. Juillet 2000

D.4 Application and protocols

IP characteristics	
TCP-IP, UDP, ICMP, ARP	<ul style="list-style-type: none"> • Server, Relay
DHCP	<ul style="list-style-type: none"> • Relay
DNS	
Routing (LAN et WAN)	<ul style="list-style-type: none"> • Static
NAT / PAT	<ul style="list-style-type: none"> • RFC 1631
Firewall	<ul style="list-style-type: none"> • By protocol
	<ul style="list-style-type: none"> • By IP address
	<ul style="list-style-type: none"> • By port
	<ul style="list-style-type: none"> • Statefull / Stateless
IP QoS	<ul style="list-style-type: none"> • DiffServ

ATM characteristics	
Signalling	<ul style="list-style-type: none"> • PVC
Adaptation layer	<ul style="list-style-type: none"> • AAL5
Number of VCI	<ul style="list-style-type: none"> • 8
Quality of service	<ul style="list-style-type: none"> • UBR, VBR, nrtVBR, VBRrt, CBR
Signalling	<ul style="list-style-type: none"> • RFC 2516
self-configuration	<ul style="list-style-type: none"> • Detection of VPI/VCI
	<ul style="list-style-type: none"> • Detection of encapsulation
	<ul style="list-style-type: none"> • Detection of PPPoE / PPPoA
	<ul style="list-style-type: none"> • Detection of PAP / CHAP

Encapsulation protocols	
PPP over ATM	<ul style="list-style-type: none"> • RFC 2364
PPP over ETH over ATM	<ul style="list-style-type: none"> • RFC 2516, RFC 1483/2684
IP over ATM	<ul style="list-style-type: none"> • RFC 1483/2684
ETH over ATM	<ul style="list-style-type: none"> • RFC 1483/2684

Configuration	
HTTP	<ul style="list-style-type: none">• LAN or WAN port (with specific option)
Management	<ul style="list-style-type: none">• From ETH, USB and WAN (with specific option)
Downloading of version	<ul style="list-style-type: none">• Client by http mode
CLI	<ul style="list-style-type: none">• Telnet
TR69	<ul style="list-style-type: none">• Via a ACS server

E. Annex E - Default configuration

This section covers	➤ the default username and password	§ E.1
	➤ the default configuration for the local network (LAN)	§ E.2
	➤ the default configuration for the local wireless network (WLAN)	§ E.3

This section details the values of the default parameters of your SAGEM F@st™ 1704 when it leaves the factory.

These default parameters can be modified by a particular preconfiguration of your SAGEM F@st™ 1704.

E.1 Default username and password

Username: admin
Password: admin

Note



The **Username** and **Password** can be different according to the ISP (Internet Service Provider).

E.2 Default configuration for the local network(LAN)

The following table details the values of the principal LAN parameters of your router (LAN1 to LAN4):

LAN characteristics	Value	State
LAN1 IP address ()	192.168.1.1/24	Internet and HTTP configuration tool access (bridged)
LAN2 IP address ()		
LAN3 IP address ()		
LAN4 IP address ()		
BROADCAST, ARP, MULTICAST	–	Activated
Router	–	The LAN traffic is routed to your ISP
NAT/PAT	–	Activated

E.3 Default configuration for the local wireless network (WLAN)

The following table supplies the principal default WLAN parameters of your router.

Characteristics (Wi-Fi)	Value
IP address	192.168.1.1/24
Enable Wireless	Box checked
SSID	Sagem1704
Channel	Auto
Network Authentication	No

F. Annex F - Glossary

Glossary

ACL	Access Configuration List
ACS	Auto Configuration Server
ADSL	Asynchronous Digital Subscriber Line
AP	Access Point
ARP	Address Resolution Protocol
CC	Continuity Check
CCK	Complimentary Code Keying
CHAP	Challenge Handshake Authentication Protocol
CLI	Command Line Interface
CPE	Customer Premises Equipment
CTS	Clear To Send
DBPSK	Demodulator Baseband Phase Shift Keying
DHCP	Dynamic Host Configuration Protocol
DNS	Domain Name Server
DQPSK	Differential Quadrature Phase Shift Keying
DSSS	Direct Sequence Spread Spectrum
DTIM	Delivery Traffic Indication Message
ESSID	Extended Service Set Identifier
FHSS	Frequency Hopping Spread Spectrum
FTP	File Transfer Protocol
HTML	Hyper Text Markup Language
HTTP	Hyper Text Transfer Protocol
IAD	Integrated Access Device
ICMP	Internet Control Message Protocol
IEEE	Institute of Electrical and Electronics Engineers
IEEE 802.11b/g	Specifications which use the MAC protocol suitable for the wireless local network (WLAN) in the 2.4 GHz band
IGMP	Internet Group Membership Protocol
IMAP	Internet Message Access Protocol
IP	Internet Protocol

ISDN	Integrated S ervice D igital N etwork
ISP	Internet S ervice P rovider
L2TP	Layer 2 T unneling P rotocol
LAN	Local A rea N etwork
LCP	Link C ontrol P rotocol
LLC	Logical L ink C ontrol
MAC	M edium A ccess C ontrol
MDI	M edia D ependent I nterface
MER	M AC E ncapsulation R outing
MTU	M aximum T ransfer U nit
NAPT	N etwork A ddress P ort T ranslation
NAT	N etwork A ddress T ranslation
OAM	O peration, A dministration and M aintenance
PAP	P assword A uthentication P rotocol
PCI	P eripheral C omponent I nterconnect
PCM	P ulse C ode M odulation
PCMA	P ulse C ode M odulation L oi A
PCMCIA	P ersonal C omputer M emory C ard I nternational A ssociation
PCMU	P ulse C ode M odulation L oi u
PID	P rotocol I Dentifier
PING	P acket I nter N et G roper
PLC	P aquet L oss C oncealment
POP3	P oste O ffice P rotocol version 3
POTS	P lain O ld T elephone S ervice
PSTN	P ublic S witching T elephonic N etwork
PPP	P oint to P oint P rotocol
PPPoE	PPP over E thernet
PVC	P ermanent V irtual C ircuit
QoS	Q uality of S ervice
RADIUS	R emote A uthentication D ial-In U ser S ervice
RFC	R equest F or C omments
RNIS	R éseau N umérique I ntégration de S ervices
RIP	R outing I nformation P rotocol
RTCP	R eal T ime C ontrol P rotocol


RTP	Real-time Transport Protocol
SCR	Sustained Cell Rate
SMTP	Simple Mail Transfer Protocol
SNDCP	Sub Network Dependent Convergence Protocol
SNAP	SubNetwork Attachment Point
SNMP	Simple Network Management Protocol
SOAP	Simple Object Access Protocol
SSID	Service Set Identifier
STB	Set Top Box
TCP	Transmission Control Protocol
TELNET	TELEcommunication NETWORK
TFTP	Trivial File Transfer Protocol
UBR	Unspecified Bit Rate
UDP	User Datagram Protocol
UPnP	Universal Plug and Plug
URL	Uniformed Resource Locator
UTP	Unshielded Twisted Pair
VBR-nrt	Variable Bit Rate - non real time
VBR-rt	Variable Bit Rate - real time
VC	Virtual Channel
VCC	Virtual Channel Connection
VCI	Virtual Channel Identifier
VC MUX	VC MultipleXing (encapsulation without header)
VP	Virtual Path
VPI	Virtual Path Identifier
VPN	Virtual Private Network
WAN	Wide Area Network
WEB	Meshed network of information servers
WEP	Wired Equivalent Privacy
WFQ	Weighted Fair Queuing
Wi-Fi	Wireless Fidelity (wireless network)
WLAN	Wireless Local Area Network
WPA	Wireless Protected Access

G. Annex G - Connector Technology

This section covers	➤ pinouts of the LINE connector	§ G.1
	➤ pinouts of the PWR connector	§ G.2
	➤ pinouts of the LAN1 , LAN2 , LAN3 and LAN4 connectors	§ G.3

G.1 Pinouts of the LINE connector

The equipment is connected to ADSL using a RJ11 fixed connector (6 pins).



Contact N°	Signal	Meaning
3	LINE-A	Line A signal
4	LINE-B	Line B signal
1	NC	Not connected
2	NC	Not connected
5	NC	Not connected
6	NC	Not connected

G.2 Pinouts of the PWR connector


The mains unit is connected to the equipment using the miniature fixed connector of the case.



Contact No	Signal	Meaning
Intérieur	+12 V	Connexion DC "+"
Extérieur	Masse	Connexion DC "-"

G.3 Pinouts of the LAN1, LAN2, LAN3 and LAN4 connectors

The Ethernet interface is connected to the equipment using a RJ45 fixed connector (8 pins).



Contact No	Signal	Meaning
1	TXD+	(+) Emission to terminal
2	TXD-	(-) Emission to terminal
3	RXD+	(+) Reception of terminal
4	NC	Not connected
5	NC	Not connected
6	RXD-	(-) Reception of terminal
7	NC	Not connected
8	NC	Not connected

Note



The Ethernet port is self-detecting. You can use either straight or crossed cables. An emission or reception signal is detected automatically.



Sagem Communications SAS
Broadband and Residential Terminals Business Unit
Headquarters: 250, route de l'Empereur
92500 Rueil-Malmaison - FRANCE
www.sagem-communications.com